

HUNTER OWNER'S MANUAL

TABLE OF CONTENTS

<i>INTRODUCTION</i>	<i>PAGE</i>
• Warranty Registration Form.....	1
• Hunter Warranty.....	2-3
• Brief History.....	4
• Glossary of Sailing Terms.....	5-8
• Explanation of Symbols and Labels.....	9
 <i>GENERAL HANDLING AND OPERATION</i>	
• Safe Boating Tips.....	10-11
• Pre-Departure Checklist.....	12
• Float Plan.....	13
• After Sailing Check List.....	14
• Docking and Anchoring.....	15
• Diesel Engine and Motoring.....	16-17
• Electrical System.....	17-18
• Cook Stove.....	19
• Toilet.....	19
• Opening Hull Ports.....	19
• Pumps.....	20
• Water System Operation.....	20
• Waste Discharge.....	21
• Environmental Considerations.....	22
 <i>MAINTENANCE</i>	
• Instructions for Preparation for Bottom Painting.....	23
• Engine, Transmission, and Drive train.....	24-25
• Compasses.....	26
• Steering Systems.....	26
• Electrical Systems.....	26
• Plumbing Systems.....	27
• Fuel Systems.....	27
• General Care.....	28-29
• Fabric Care.....	29
• Electrolysis and Galvanic Protection.....	30
• Teak Care.....	30
• Storage/Winterization.....	31-33
• Certification Details.....	34
• Lightning Warning.....	35

HUNTER OWNER'S MANUAL

TABLE OF CONTENTS (CONT'D)

<i>DESCRIPTION OF MODEL</i>	<i>PAGE</i>
• Profile with Rig and Sail Dimensions.....	36
• Dimensions, Capacities, etc.....	37
• Deck Plan and Hardware.....	38
• Deck Hardware Parts Listing.....	39
• Accommodation Plan.....	40A-40C
• Dinette Table Operation.....	41A
• Lifting Points.....	41B
• Running Rigging Layout.....	42A-1&2
• Mainsheet Rigging.....	43
• Arch Installation.....	44
• Boom and Reefing Details.....	45
• Running Rigging Specifications.....	46
• Rig Description.....	47
• Standing Rigging Layout.....	48
• Spreader Details.....	49
• Standing Rigging Specifications.....	50
• Standing Rigging Attachments.....	51
• Rig Tuning Instructions.....	52-53
• Spinnaker Details.....	54
• Engine Compartment Details.....	55
• Shaft and Propeller.....	56
<i>SYSTEMS AND CIRCUITS</i>	<i>PAGE</i>
• Potable Water System.....	57
• Waste System.....	58
• Bilge Pumping System.....	59
• Through Hulls, Seacocks, and Valves.....	60
• Fuel System.....	61
• Propane System.....	62
• Electrical System (See Electrical System Table Of Contents)	63A-1
• Steering System.....	66-68
• Anchoring Arrangement.....	69
• Index.....	70

Welcome to **THE HUNTER MARINE FAMILY**

Congratulations on your new sailing yacht manufactured by Hunter Marine. We have engineered and constructed your boat to be as fine a yacht as any afloat. In order to get the best performance and most enjoyment from your boat you should be familiar with its various elements and their functions. For your sailing pleasure and safety, please take time to study this manual.

We stand behind the quality of your boat with a warranty, which you should review. To insure the validity of your warranty, please complete the attached card and send it to us within ten (10) days of the purchase date. Section 15 of the U.S. Federal Boat Safety Act requires registration of a boat's first owner. The warranty data should also be recorded in the space below for your own reference.

This manual has been compiled to help you operate your craft with safety and pleasure. It contains details of the

craft; equipment supplied or fitted, systems, and information on operation and maintenance. Please read it carefully, and familiarize yourself with the craft before using it. If this is your first sailboat or you are changing to a type of craft you are not familiar with, please ensure that you obtain proper handling and operating experience before you assume command of the craft. Your dealer or national sailing federation or yacht club will be pleased to advise you of local sea schools or competent instructors.

PLEASE KEEP THIS MANUAL IN A SAFE PLACE AND HAND IT OVER TO THE NEW OWNER IF YOU SELL THE CRAFT.

You should also complete the warranty cards for your engine, stove, head, electric water pump and other accessories. These are enclosed in the manufacturers' manuals that are packaged with your owner's manual.

OWNER INFORMATION CARD

HULL IDENTIFICATION NUMBER IS ON THE STARBOARD AFT SIDE OF THE HULL OR TRANSOM.
THIS NUMBER MUST BE GIVEN IN ALL NECESSARY CORRESPONDENCE.

HULL NO. _____ *DATE DELIVERED TO OWNER* _____

YACHT NAME _____

OWNER NAME _____

STREET ADDRESS _____

CITY _____ *STATE/COUNTRY* _____ *ZIP CODE* _____

HOME PORT _____

ENGINE MODEL _____ *SERIAL NO.* _____ *PROPELLER SIZE* _____

DEALER _____ *PHONE* _____

STREET ADDRESS _____

CITY _____ *STATE/COUNTRY* _____ *ZIP CODE* _____

CUSTOMER SERVICE / WARRANTY

The following warranties apply to all 2004 Model Year boats produced by HUNTER MARINE CORPORATION:

LIMITED ONE-YEAR WARRANTY

Hunter Marine warrants to the first-use purchaser and any subsequent owner during the warranty period that any part manufactured by Hunter will be free of defects caused by faulty workmanship or materials for a period of twelve (12) months from the date of delivery to the first-use purchaser under normal use and service. During this period, Hunter will repair or replace any part judged to be defective by Hunter, after it is reviewed by the selling dealership.

LIMITED FIVE-YEAR HULL STRUCTURE AND BOTTOM BLISTER WARRANTY

Hunter warrants to the first-use purchaser and any subsequent owner during the warranty period that the hull of each boat will be free from structural defects in materials and workmanship for a period of five (5) years from the date of delivery to the first-use purchaser under normal use and service.

This limited warranty applies only to the structural integrity of the hull and the supporting pan/grid or stringer system. Hulls, pan/grid or stringers modified in any way or powered with engines other than the type and size installed or specified by Hunter are not covered by this limited warranty. The obligation of Hunter under this limited warranty is limited to the repair or replacement of hulls that it determines to be structurally defective. This is your sole and exclusive remedy.

Hunter also warrants to the first-use purchaser and any subsequent owner during the warranty period that the boat will be free from gel-coat blistering on underwater surfaces of the hull, excluding the keel and rudder, for a period of five (5) years from the date of delivery to the first-use purchaser under normal use and service. During this period, Hunter will supply or reimburse an authorized Hunter dealer for all of the parts and labor required to repair a blistered underwater surface of the hull. The labor cost reimbursement will be based on the Labor Allowance Schedule established by Hunter from time to time, however if the repair is performed by a non-Hunter dealer, the repair cost must be authorized by Hunter in advance and be based on a reasonable number of hours as determined by Hunter. Hunter will not pay transportation, hauling, launching, bottom paint, storage, dockage, cradling rental, rigging and derigging, or other similar costs. It is recommended that the repair be done during a seasonal haul out for service or storage.

The following circumstances will void the bottom blister limited warranty:

- (1) If the gel-coat has been sanded, sandblasted, or subjected to abrasion or impact.
- (2) If the instructions provided in the Hunter Owner's Manual are not followed according to Hunter's required bottom preparation procedures.

RESTRICTIONS APPLICABLE TO WARRANTIES

These limited warranties **do not cover:**

- (1.) Paint, window glass, Gelcoat, upholstery damage, plastic finishes, engines, engine parts, bilge pumps, stoves, blowers, pressure water pumps, propellers, shafts, rudders, controls, instruments, keels and equipment not manufactured by HUNTER. Any warranty made by the manufacturer of such items will be, if possible, given on to the first use purchaser.
- (2.) Problems caused by improper maintenance, storage, cradling, blocking, normal wear and tear, misuse, neglect, accident, corrosion, electrolysis or improper operation.
- (3.) Boats used for commercial activities including charter.

THESE LIMITED WARRANTIES ARE YOUR SOLE AND EXCLUSIVE REMEDIES AND ARE EXPRESSLY IN LIEU OF ANY AND ALL OTHER REMEDIES AND WARRANTIES EXPRESSED AND IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHETHER ARISING BY LAW, CUSTOM, CONDUCT, OR USAGE OF TRADE. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. IN THE EVENT THAT IMPLIED WARRANTIES ARE FOUND TO EXIST UNDER THE LAW OF A PARTICULAR STATE, NOTWITHSTANDING THE EXCLUSION CONTAINED HERIN, THE DURATION OF ANY SUCH IMPLIED WARRANTY SHALL BE LIMITED TO THE DURATION OF THE APPLICABLE LIMITED WARRANTY STATED HEREIN. THE PURCHASER ACKNOWLEDGES THAT NO OTHER REPRESENTATIONS WERE MADE TO HIM OR HER WITH RESPECT TO THE QUALITY OR FUNCTION OF THE BOAT. ANY ORAL STATEMENT OR PRINTED MATERIAL ADVERTISING THE BOAT WHICH SPEAKS TO ANY PERFORMANCE CHARACTERISTIC OF THE BOAT OR ANY OF ITS COMPONENTS SHALL BE CONSIDERED AND CONSTRUED AS AN ESTIMATED DESCRIPTION ONLY AND SHOULD NOT BE RELIED UPON AS AN EXPRESS WARRANTY OR AS THE BASIS OF THE BARGAIN FOR THE BOAT OR ANY OF ITS COMPONENTS.

ANY CONSEQUENTIAL, INDIRECT OR INCIDENTAL DAMAGES WHICH MAY BE INCURRED ARE EXCLUDED AND PURCHASER'S REMEDY IS LIMITED TO REPAIRS OR REPLACEMENT OF ANY PART(S) JUDGED DEFECTIVE BY HUNTER MARINE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL OR INDIRECT DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

WARRANTY REGISTRATION

These limited warranties shall not be effective unless the HUNTER Warranty Registration Form and Pre-Delivery Service Record, which are furnished with each new boat, are filled out completely and returned to HUNTER within ten (10) days of delivery.

Return of the Warranty Registration Form to HUNTER, signed by both Dealer and Owner, is critical. Warranty coverage cannot be initiated until the completed form is received at HUNTER.

All repairs and/or replacements will be made by an authorized Hunter dealer, or at the option of Hunter, at the Hunter plant. If the repairs are of such a nature that the warranty work must be performed at the HUNTER plant, transportation costs to and from the HUNTER plant shall be paid by the owner. The labor cost reimbursement will be based on a Labor Allowance Schedule established by HUNTER and where not applicable, on a reasonable number of hours as determined by HUNTER. Any repairs and replacements must be approved in advance by an authorized HUNTER service representative.

TRANSFER OF LIMITED WARRANTIES

For 1995 and later hull numbers, the limited warranties will be transferred to a subsequent purchaser of the boat if:

(1) A notice of the transfer of ownership of the boat is given by the subsequent purchaser in writing to Hunter within thirty (30) days of the transfer.

(2) The notice shall include the name, address and telephone number of the subsequent purchaser, the date of purchase, the hull number and the name of the seller of the boat.

Hunter will mail to the subsequent purchaser notice of the expiration dates of the limited warranties. (see form letter, attached) The transfer of the ownership of the boat will not extend the expiration dates of the limited warranties.

CUSTOMER SATISFACTION SURVEYS

During the first year of ownership, the first purchaser will receive two Customer Satisfaction Surveys - the first (CSS#1) will be received shortly after taking delivery and focuses on the dealer's ability to sell and commission the boat, and the Owner's initial satisfaction. The second survey (CSS#2), nine to ten months into ownership, "measures" dealer service capability and allows the owner to evaluate most of the boat's functional systems and characteristics. Both surveys are dependent upon receipt of the first purchaser's Warranty Registration Form.

SAMPLE FORM LETTER

March 12, 1997

Mr. John Smith
1456 Joy Street
Sarasota, FL 34266

Dear Mr. Smith,

Thank you for providing written notice of transfer of ownership. We are pleased you have selected a Hunter sailboat and we will make every effort to assure Hunter ownership will be a satisfying experience for you.

Based on the information you have provided, we are pleased to notify you of the expiration dates of the limited warranties.

- The limited **one-year** New Boat warranty expires (d)_____.
- The limited **five-year** Hull Structure and Bottom Blister warranty expires (d)_____.

_____.

Should you require assistance at any time during ownership, we encourage you to contact your Hunter dealer or to call us directly at 386-462-3077.

Please confirm the information at the bottom of the page and advise us if any corrections are required.

Customer Service Manager

Hull No: HUN_____ Model:_____

Telephone: (H)_____ (B)_____

Date of Purchase:_____

Purchased From: Name:_____

Address:_____

City/State_____ Zip_____

() Private Owner

() Dealer

Warranty Procedure

Following is a detailed outline of the Hunter Warranty Policy. Please read it carefully. The major points are:

- Always refer to the hull number
- Phone or fax us for authorization on warranty work over a \$200 USD estimate.
- Send in the warranty claim within thirty (30) days of the repair.

1) All customer warranty problems must be handled through the selling dealer.

- a) Boats must be returned to the selling dealer.
- b) Dealer will contact Hunter Marine and give a brief description of the problem and an estimate of time and cost to correct problem (include complete hull #).
- c) All warranty involving associated equipment--engines, bilge pumps, stoves, pressure water pumps, instrument panels, etc.-- will be handled direct with the manufacturer of said equipment on an exchange basis.

2) For any problem that the dealer cannot correct, the dealer will contact Hunter Marine who will take corrective measures immediately. The repairs may be of such a nature that the customer will have to return the boat to manufacturer at his cost.

3) Hunter Marine will not pay for warranty items that should have been covered in a Pre-Delivery Service check. (See Pre-Delivery Service Check Record.)

4) Hunter Marine will not be responsible for inconveniences, or for losses incurred as a result of defect. Hunter Marine will take measures to correct only the defect.

5) Hunter Marine will apply a base labor rate of \$38.00 per hour for warranty repairs, providing all documentation on sold boats has been submitted to Hunter Marine. If you or your employee(s) have attended the recent Hunter Service Training Program and received a Certificate of Training and all documentation has been submitted, the labor rate will be \$54.00 per hour on boats your dealership has sold (\$60.00 per hour if a boat your dealership DID NOT sell). Hunter Marine will allow \$5.00 per foot to haul-out, if necessary and approved.

6) Hunter will not assume any responsibility or liability for parts replaced or any work done by others, without written authorization from Hunter.

7) Photographs are required on all fiberglass warranty work.

8) Warranty work under \$200.00 can be done without prior authorization. Any work estimates at more than \$200.00 must have prior approval and receive an authorization number for our records.

9) Warranty claims must be sent in duplicate and must contain the **complete** hull number and a brief description of work performed. Labor, parts, materials, and haul-outs must be listed separately. Claims for warranty must be sent to Hunter Marine not more than thirty (30) days after completion of work, or they may not be honored.

HUNTER MARINE'S OWNER AND FOUNDER WARREN R. LUHRS

BRIEF BACKGROUND

Warren Luhrs was born in East Orange, New Jersey in 1944 into a family with an established tradition in the maritime and transportation industries. His great-grandfather, Henry, was a railroad and clipper-shipping pioneer in America, while his great-uncle John helped build the famous St. Petersburg to Moscow railroad for Czar Alexander II.

Henry Luhrs owned shares in twenty-two different ocean-going vessels – barks, brigs, and schooners - and was the principal owner of the bark *Sophia R. Luhrs*, named for his wife. He was also a partner with Albert Sprout, who managed the shipyard where the *Sophia R. Luhrs* was built in Melbridge, Maine.

Warren Luhrs' father Henry worked at a small boat manufacturer in Morgan, New Jersey, and later started his own company, continuing the Luhrs' family sea tradition during the great depression. During World War II he repaired boats and installed ice sheathing on their bows for the Coast Guard.

After the War, Henry built 27-foot fishing boats and in 1948 began to construct custom-built pleasure craft. He then turned to skiffs and in 1952 incorporated as Henry Luhrs Sea Skiffs, where he constructed lapstrake sea skiffs using assembly-line techniques. Henry personally "shook down" his prototypes on family trips up the Hudson River to Lake Champlain.

The sea skiff is a class of boat that has been very popular, owing to its seaworthiness. It features a sharp bow, which reduces pounding in surf or

choppy seas, and a hull whose forward section is rounded below the waterline to increase stability in rough water or a following sea. Such skiffs can either be smooth sided or of a lapstrake construction.

Inspired by Henry Ford, Henry Luhrs' aimed to give the average man the opportunity to enjoy the luxury of boating by building an affordable and reliable boat. He was both designer and engineer, and his progressive new models exhibited his talent for innovation. He successfully changed the line of the bow from straight to curved at a time when the industry trend was a straight square effect, and he is believed to be the first designer-builder to popularize a small boat with a fly bridge.

In 1960, Luhrs acquired the Ulrichsen Boat Company of Marlboro, New Jersey. It was here that Luhrs' Alura fiberglass division was located. In 1965, Henry sold his company to Bangor Arrostook Railroad, which was to become the recreational conglomerate Bangor-Punta. It was also during this period that Silverton of Tom's River, New Jersey was purchased by John and Warren Luhrs.

Today, Warren R. Luhrs and his brother John own the Luhrs Group of marine manufacturers, which consists of Silverton Marine, Mainship Motor Yachts, and Luhrs Fishing Boats with its Alura division, as well as Hunter Marine, which exclusively manufactures sailboats.

In January of 1996, the Luhrs family transferred a portion of the Luhrs Group to its employees through an ESOP program.

GLOSSARY OF SAILING TERMS

A

Aback: describes a sail when the wind strikes it on the lee side.

Abaft: towards the boat's stern.

Abeam: at right angles to the *centerline* of the boat.

Aft: at or near the stern.

Amidships: the center of the boat, *athwartships* and fore and aft.

Anti-fouling: a poisonous paint compound used to protect the underwater part of a hull from marine growths.

Apparent wind: The direction and speed of the wind felt by the crew. It is a combination of *true wind* and that created by the movement of the boat.

Astern: behind the boat; to go astern is to drive the boat in reverse.

Athwartships: at right angles to the fore and aft line of the boat.

B

Back: when a wind backs, it shifts anticlockwise.

Back a sail: to sheet it to windward so that the wind fills on the side that is normally to *leeward*.

Backstay: a stay that supports the mast from aft and prevents its forward movement.

Ballast: extra weight, usually lead or iron, placed low in the boat or externally on the keel to provide stability.

Ballast keel: a mass of ballast bolted to the keel to increase stability and prevent a keel boat from capsizing.

Batten: a light, flexible strip fed into a batten pocket at the *leech* of the sail to support the *roach*.

Beam: 1, the maximum breadth of a boat; 2, a transverse member that supports the deck; 3, on the beam means that an object is at right angles to the centerline.

Bear away: to steer the boat away from the wind.

Bearing: the direction of an object from an observer, measured in degrees true or magnetic.

Beat: to sail a *zigzag course* towards the wind, *close-hauled* on alternate *tacks*.

Delay: to make fast a rope around a *cleat*, usually with a figure-of-eight knot.

Bend: 1, to secure a sail to a spar before hoisting; 2, to moor a boat; 3, a sleeping place on board.

Bight: a *bend* or loop in a rope.

Bilge: the lower, round part inside the hull where the water collects.

Block: a pulley in a wooden or plastic case, consisting of a *sheave* around which a rope runs. It is used to change the direction of pull.

Boot-topping: a narrow colored stripe painted between the bottom paint and the *topside* enamel.

Bottlescrew: see Rigging screw.

Broach: when a boat *running* downwind slews broadside to the wind and *heels* dangerously. It is caused by heavy following seas or helmsman's error.

Broad reach: the point of sailing between a beam *reach* and a *run*, when the wind blows over a quarter.

Bulkhead: a partition wall in a boat normally fitted *athwartships*

C

Caulk: to make the seams between wooden planks watertight by filling with cotton, oakum or a compound.

Cavitation: the formation of a vacuum around a propeller, causing a loss in efficiency.

Center-board: a board lowered through a slot in the *keel* to reduce *leeway*.

Center-line: center of the boat in a fore and aft line.

Center of effort (COE): the point at which all the forces acting on the sails are concentrated.

Center of lateral resistance (CLR): the underwater center of pressure about which a boat pivots when changing *course*.

Chain pawl: a short lug which drops into a toothed rack to prevent the anchor chain running back.

Chain plate: a metal plate bolted to the boat to which the *shrouds* or *backstays* are attached.

Chart datum: reference level on a chart below which the tide is unlikely to fall. Soundings are given below chart datum. The datum level varies according to country and area.

Chine: the line where the bottom of the hull meets the side at an angle.

Cleat: a wooden, metal or plastic fitting around which rope is secured.

Clevis pin: a locking pin through which a split ring is passed to prevent accidental withdraw.

Clew: the after, lower center of a sail where the foot and *leech* meet.

Close-hauled: the *point of sailing* closest to the wind; see also *beat*.

Close reach: the *point of sailing* between *close-hauled* and a beam reach, when the wind blows forward of the *beam*.

Close-winded: describes a boat able to sail very close to the wind.

Coaming: the raised structure surrounding a hatch, cockpit, etc., which prevents water entering.

Cotter pin: soft, metal pin folded back on itself to form an eye.

Course: the direction in which a vessel is steered, usually given in degrees; true, magnetic or compass.

Cringle: 1, a rope loop, found at either end of a line of reef points; 2, an eye in a sail.

D

Dead run: running with the wind blowing exactly aft, in line with the *centerline*.

Deviation: the difference between the direction indicated by the compass needle and the magnetic *meridian*; caused by object aboard.

Displacement: 1, the weight of water displaced by a boat is equal to the weight of the boat; 2, a displacement hull is one that displaces its own weight in water and is only supported by buoyancy, as opposed to a planing hull which can exceed its hull, or displacement, speed.

Downhaul: a rope fitted to pull down a sail or spar.

Draft: the vertical distance from the waterline to the lowest point of the keel.

Drag: 1, an anchor drags when it fails to hold; 2, the force of wind on the sails, or water on the hull, which impedes the boat's progress.

Drift: 1, to float with the current or wind; 2, US the speed of a current

GLOSSARY OF SAILING TERMS

(rate UK); 3, UK: the distance a boat is carried by a current in a given time.

Drogue: a sea anchor put over the stern of a boat or life raft to retard *drift*.

Drop keel: a retractable *keel* which can be drawn into the hull, when entering shallow waters and recovering on to a trailer.

E

Eye of the wind: direction from which the true wind blows.

F

Fair: well-faired line or surface is smoother with no bumps, hollows or abrupt changes in directions.

Fairlead: a fitting through which a line is run to alter the lead of the line.

Fathom: the measurement used for depths of water and lengths of rope. 1 fathom = 6 ft. or 1.83m.

Fid: a tapered tool used for *splicing* heavy rope and for sail-making, often hollow.

Fiddle: a raised border for a cabin table, chart table etc., to prevent objects falling off when the boat *heels*.

Fix: the position of the vessel as plotted from two or more position lines.

Forestay: the foremost stay, running from the masthead to the stemhead, to which the headsail is hanked.

Freeboard: vertical distance between the *waterline* and the top of the deck.

G

Genoa: a large headsail, in various sizes, which overlaps the mainsail and is hoisted in light to fresh winds on all points of *sailing*.

Gimbals: two concentric rings, pivoted at right angles, which keeps objects horizontal despite the boat's motion, e. g. compass and cooker.

Go about: to turn the boat through the *eye of the wind* to change tack.

Gooseneck: the fitting attaching the boom to the mast, allowing it to move in all directions.

Goosewing: to boom-out the headsail to windward on a run by using a *whisker pole* to hold the sail on the opposite side to the mainsail.

Ground tackle: general term used for anchoring gear.

Guard rail: a metal rail fitted around the boat to prevent the crew falling overboard.

Gudgeon: a rudder fitting. It is the eye into which the *pintle* fits.

Guy: a steadying rope for a spar; a spinnaker guy controls the fore and aft position of the spinnaker pole; the foreguy holds the spinnaker pole forward and down.

Gybe: to change from one *tack* to another by turning the stern through the wind.

H

Halyard: rope used to hoist and lower sails.

Hank: fitting used to attach the *luff* of a sail to a stay.

Hatch: an opening in the deck giving access to the interior.

Hawes pipe: see *Navel pipe*.

Head-topwind: when the bows are pointing right into the wind.

Headfoil: a streamlined surround to a *forestay*, with a groove into which a headsail *luff* slides.

Heads: the toilet.

Headway: the forward movement of a boat through the water.

Heave-to: to *back* the jib and lash the tiller to *leeward*; used in heavy weather to encourage the boat to lie quietly and to reduce *headway*.

Heaving line: a light line suitable for throwing ashore.

Heel: to lean over to one side.

I

Isobars: lines on a weather map joining places of equal atmospheric pressure.

J

Jackstay: a line running fore and aft, on both sides of the boat, to which safety harnesses are clipped.

Jury: a temporary device to replace lost or damaged gear.

K

Keel: the main backbone of the boat to which a *ballast keel* is bolted or through which the *centerboard* passes.

Kicking strap: a line used to pull the boom down, to keep it horizontal, particularly on a reach or run.

L

Lanyard: a short line attached to one object, such as a knife, with which it is secured to another.

Leech: 1, the after edge of a triangle sail; 2, both side edges of a square sail.

Leehelm: the tendency of a boat to bear away from the wind.

Lee shore: a shore on to which the wind blows.

Leeward: away from the wind; the direction to which the wind blows.

Leeway: the sideways movement of a boat off its *course* as a result of the wind blowing on one side of the sails.

Lifeline: a wire or rope rigged around the deck to prevent the crew falling overboard.

Limber holes: gaps left at the lower end of frames above the *keel* to allow water to drain to the lowest point of the *bilges*.

List: a boat's more or less permanent lean to one side, owing to the improper distribution of weight, e.g., *ballast* or water.

Log: 1, an instrument for measuring a boat's speed and distance traveled through the water; 2, to record in a book the details of a voyage, usually distances covered and weather.

Luff: the forward edge of a sail. To luff up is to turn a boat's head right into the wind.

Luff groove: a groove in a wooden or metal spar into which the *luff* of a headsail is fed.

Lurch: the sudden roll of a boat.

M

Marlin spike: a pointed steel or wooden spike used to open up the strands of rope or wire then splicing.

Mast Step: the socket in which the base of the mast is located.

Measured mile: a distance of one nautical mile measured between buoys or *transits/ranges* ashore, and marked on the chart.

GLOSSARY OF SAILING TERMS

Member: a part of the skeleton of the hull, such as a *stringer* laminated into fiberglass hull to strengthen it.

Meridian: an imaginary line encircling the Earth that passes through the poles and cuts at right angles through the Equator. All lines of longitude are meridians.

Mizzen: 1, the shorter, after-mast on a *ketch* or *yawl*; 2, the fore and aft sail set on this mast.

N

Navel pipe: a metal pipe in the fore-deck through which the anchor chain passes to the locker below.

Noon Sight: a vessel's latitude can be found, using a sextant, when a heavenly body on the observer's *meridian* is at its greatest altitude. The sight of the sun at noon is the one most frequently taken.

O

Off the wind: with the sheets slacked off, not *close-hauled*.

On the wind: *close-hauled*.

Out haul: a rope used to pull out the foot of a sail.

Overall length (LOA): the boat's extreme length, measured from the foremost part of the bow to the aftermost part of the stern, excluding bowsprit, self-steering gear etc.

P

Painter: the bow line by which a dinghy, or *tender*, is towed or made fast.

Pintle: a rudder fitting with a long pin that fits into the *gudgeon* to form a hinged pivot for the rudder.

Pitch: 1, the up and down motion of the bows of a boat plunging over the waves; 2, the angle of the propeller blades.

Point of sailing: the different angles from which a boat may sail; the boat's *course* relative to the direction of the wind.

Port: the left-hand side of the boat, looking forward (opp. of *starboard*).

Port tack: a boat is on a port tack when the wind strikes the port side first and the mainsail is out to *starboard*. A boat on the port tack gives way to a boat on a starboard tack.

Position line/ Line of position: a line drawn on a chart, as a result of taking a bearing, along which the boat's position must be i.e. Two position lines give a fix.

Pulpit: a metal *guard rail* fitted at the bows of a boat to provide safety for the crew.

Pushpit: a metal *guard rail* fitted at the stern.

Q

Quarter: the portion of the boat midway between the stern and the beam; on the quarter means about 45 degrees *abaft* the beam.

R

Rake: the fore and aft deviation from the perpendicular of a mast or other feature of a boat.

Range: 1, see *transit*; 2, of tides, the difference between the high and low water levels of a tide; 3, the distance at which a light can be seen.

Rating: a method of measuring certain dimensions of a yacht to enable it to take part in handicap races.

Reach: to sail with the wind approximately on the *beam*; all sailing points between running and *close-hauled*.

Reef: to reduce the sail area by folding or rolling surplus material on the boom or *forestay*.

Reefing pennant: strong line with which the *luff* or leech *cringle* is pulled down to the *boom* when reefing.

Rhumb line: a line cutting all *meridians* at the same angle; the *course* followed by a boat sailing in a fixed direction.

Riding light to anchor light: an all-around white light, usually hoisted on the *forestay*, to show that a boat under 50 ft. (15m.) is at anchor. It must be visible for 2 mls. (3 km.).

Rigging screw: a deck fitting with which the tensions of standing rigging, e.g. stays, shrouds, etc. are adjusted.

Roach: the curved part of the *leech* of a sail that extends beyond the direct line from head to *clew*.

Run: to run with the wind *aft* and with the *sheets* eased well out.

Running rigging: all the moving lines, such as *sheets* and *halyards*,

used in the *setting* and *trimming* of sails.

S

Scope: the length of rope or cable paid out when *mor* anchoring.

Scuppers: 1, holes in the toe rail that allow water to drain off the deck; 2, drain cockpit through hull.

Seacock: a valve that shuts off an underwater inlet or outlet passing through the hull.

Seize: to bind two ropes together, or a rope to a *spar*, with a light line.

Serve: to cover and protect a *splice* or part of a rope with twine bound tightly against the lay.

Serving mallet: tool with a grooved head, used when serving a rope to keep the twine at a constant and high tension.

Set: 1, to hoist a sail; 2, the way in which the sails fit; 3, the direction of tidal current or steam.

Shackle: a metal link with a removable bolt across the end; of various shapes: D, U.

Sheave: a grooved wheel in a *block* or *spar* for a rope to run on.

Sheet: the rope attached to the *clew* of a sail or to the boom, enabling it to be controlled or *trimmed*.

Shrouds: ropes or wires, usually in pairs, led from the mast to the *chain plates* at deck level to prevent the mast falling sideways; part of the standing rigging.

Sloop: a single-masted sailing boat with a mainsail and one head sail.

Spar: a general term for any wooden or metal pole, e.g., mast or boom, used to carry or give shape to sails.

Spindrift: spray blown along the surface of the sea.

Spinnaker: a large, light, balloon shaped sail set when *reaching* or *running*.

Splice: to join ropes or wire by unlaying the strands and interweaving them.

Split pin: see *cotter pin*.

Spreaders: horizontal struts attached to the mast, which extends to the *shrouds* and help to support the mast.

GLOSSARY OF SAILING TERMS

Stall: a sail stalls when the airflow over it breaks up, causing the boat to lose way.

Stanchion: upright metal post bolted to the deck to support guardrails or lifelines.

Standing part: the part of a line not used when making a knot; the part of a rope that is made fast, or around which the knot is tied.

Standing rigging: the shrouds and stays that are permanently set up and support the mast.

Starboard: right-hand side of a boat looking forward (opp. of *port*).

Starboard tack: a boat is the starboard tack when the wind strikes the starboard side first and the boom is out to the *port*.

Stay: wire or rope which supports the mast in a fore and aft direction; part of the *standing rigging*.

Steerage way: a boat has steerage way when it has sufficient speed to allow it to be steered, or to answer the helm.

Stem: the timber at the bow, from the keel upward, to which the planking is attached.

Sternway: the backward, stern-first movement of a boat.

Stringer: a fore and aft member, fitted to strengthen the frames.

T

Tack: 1, the lower forward corner of a sail; 2, to turn the boat through the wind so that it blows on the opposite sides of the sails.

Tacking: working to windward by sailing *close-hauled* on alternate *courses* so that the wind is first on one side of the boat, then on the other.

Tack pennant: a length of wire with an eye in each end, used to raise the tack of a headsail some distance off the deck.

Tackle: a purchase system comprising of rope and *blocks* that is used to gain mechanical advantage.

Tang: a strong metal fitting by which *standing rigging* is attached to the mast or other *spar*.

Tender of dinghy: a small boat used to ferry stores and people to a yacht.

Terminal fitting: fitting at the end of a wire rope by which a *shroud* or stay can be attached to the mast, a *tang* or a *rigging screw/turnbuckle*.

Tide: the vertical rise and fall of the oceans caused by the gravitational attraction of the moon.

Toe rail: a low strip of metal or molding running around the edge of the deck.

Topping lift: a line from the masthead to a spar, normally the boom, which is used to raise it.

Topsides: the part of a boat's hull that is above the waterline.

Track: 1, the course a boat has made good; 2, a fitting on the mast or boom into which the slides on a sail fit; 3, a fitting along which a traveller runs, used to alter the angle of the sheets.

Transit: two fixed objects are in transit when seen in line; two transit give position fix.

Traveller: 1, a ring or hoop that can be hauled along a *spar*; 2, a fitting that slides in a *track* and is used to alter the angle of the *sheets*.

Trim: 1, to adjust the angle of the sails, by means of *sheets*, so that they work most efficiently; 2, to adjust the boat's load, and thus the fore and aft angle at which it floats.

True wind: the direction and speed of the wind felt when stationary, at anchor or on land.

Turnbuckle: see *Rigging screw*.

U

Under way: a boat is under way when it is not made fast to shore, at anchor or aground.

Uphaul: a line used to raise something vertically, e.g., the spinnaker pole.

V

Veer: 1, the wind veers when it shifts in clockwise direction; 2, to pay out anchor cable or rope in a gradual, controlled way.

W

Wake: the disturbed water left *astern* of a boat.

Waterline: the line along the hull at which a boat floats.

Waterline length (WL): the length of a boat from *stem* to *stern* at the *waterline*. It governs the maximum speed of *displacement hull* and effects a boat's *rating*.

Weather helm: (opp. of *lee helm*).

Weather side: the side of a boat on which the wind is blowing.

Wetted surface: the area of the hull under water.

Whisker pole: a light pole used to hold out the *clew* of a headsail when *running*.

Winch: a mechanical device, consisting usually of a metal drum turned by a handle, around which a line is wound to give the crew more purchasing power when hauling taut a line, e.g. a *jib sheet*.

Windage: those parts of a boat that increase *drag*, e.g., rigging, spars, crew, etc.

Windlass: a *winch* with a horizontal shaft and a vertical handle, used to haul up the anchor chain.

Windward: the direction from which the wind blows; towards the wind (opp. of *leeward*).

Y

Yawl: a two masted boat with a mizzen stepped aft of the rudder stock/post.

EXPLANATION OF SAFETY PRECAUTIONS

This manual contains safety precautions that must be observed when operating or servicing your boat.

Review and understand these instructions.

DANGER

Denotes an extreme intrinsic hazard exists which would result in high probability of death or irreparable injury if proper precautions are not taken

WARNING

Denotes a hazard exists which can result in injury or death if proper precautions are not taken

CAUTION

Denotes a reminder of safety practices or directs attention to unsafe practices which could result in personal injury or damage to the craft or components

SAFE BOATING TIPS

BE PREPARED

Take a safe boating course. In the U.S., contact your local Boating Industry for details.

Carry all safety equipment required by the laws that apply to your area. Requirements are generally available from the Coast Guard or your local boating industry.

 WARNING
As the owner of the craft, obtaining and maintaining necessary safety equipment is your responsibility. For more information about equipment required, contact local boating authorities

MINIMUM RECOMMENDED SAFETY EQUIPMENT

- Required life saving equipment, including life vests and throwables
- Required fire extinguishing equipment
- First Aid kit
- Emergency Position Indicating Radio Beacon (EPIRB)
- Manual bailing device
- Anchor with sufficient line and/or chain
- Flashlight with good batteries
- Binoculars
- VHF radio
- Appropriate navigational charts
- Flares
- Fog bell
- Noise emitting device
- Radar reflector
- Sufficient food and water provisions
- Auxiliary starting battery
- Spare fuses and bulbs
- Sunglasses and block
- Blanket

The legally required on-board safety equipment may vary by region or body of water. Please check with local authorities prior to departure for a safety examination.

LIFE JACKETS

A life jacket may save your life, but only if you wear it. Keep jackets in a readily accessible place – not in a closed compartment or stored under other gear. Remove them from any packaging, and keep throwable floatation devices ready for immediate use.

 WARNING
It is very important that children, handicapped people, and non-swimmers wear lifejackets at all times. Make sure all passengers are properly instructed in use of life saving gear

FIRE EXTINGUISHERS

Approved fire extinguishers are required on most boats, local authorities can provide details. All passengers should know the location and operating procedure of each fire extinguisher. Fire extinguishers are normally classified according to fire type. Be familiar with the type of fire extinguishers you have on board.

Some boats have been equipped with an Automatic Fire Extinguisher). In the event of a fire in your engine compartment, this unit will automatically discharge. Please read your SEA-FIRE manual for operating instructions, maintenance and precautionary information.

SAFE BOATING TIPS

FLARES

Most boats operating on coastal waters are required to carry approved visual distress signals, therefore check with your local authorities as to which types are required.

 WARNING
FIRE/EXPLOSION HAZARD; Pyrotechnic signaling devices can cause injury and property damage if not handled properly. Follow manufacturer's directions regarding the proper use of signaling devices.

DRUGS AND BOATING

Consumption of alcohol while boating is not recommended. The combination of noise, sun, wind, and motion act to produce fatigue on the water, and can exaggerate the effects of alcohol.

 WARNING
IMPAIRED OPERATION HAZARD Operating any boat while is intoxicated or under the influence of drugs is both dangerous and illegal. Impaired vision or judgment on the water can lead to accidents and personal injury

BEFORE GETTING UNDERWAY

- Leave a float plan (example on p. 13)
- Perform a pre-departure checklist (example on p. 12)
- Check the weather. Do not venture out if the weather is, or will be, threatening.

WHILE UNDERWAY

- Keep a good lookout. Keep a watch to the leeward under the headsail. Keep away from swimmers, divers, and skiers.
- Know and obey local boating laws.
- Respect bad weather, and be prepared for quickly changing conditions.

 WARNING
COLLISION HAZARD Use extra caution in shallow water or where underwater/floating objects may be present. Hitting an object at speed or severe angle can seriously injure people and damage your boat

PRE-DEPARTURE CHECKLIST

- Check bilge for extra water
- Check weather conditions and tides
- Check food supply
- Foul weather gear
- Linen, sleeping bags
- Fuel
- Water
- Sunscreens and sunglasses
- Tools
- Docking and anchor gear
- Check radio operations
- Navigation charts and instruments
- Float plans to a friend or Coast Guard** (*see next page*)
- Fuel for stove
- Cooking and eating utensils
- Check battery water level
- Oil level, tight Vp-belts
- Check for loose electrical connections in engine compartment
- Secure tools or any loose equipment in engine compartment so as not to get fouled in engine
- AC systems off; electrical cord stowed
- Doors and drawers secured
- Check steering lock to lock
- Check mast for rigging irregularities and tightness
- Halyards and sheets are clear and ready to run
- No lines or other obstructions near propeller or bow
- Anchor ready to run
- Check lifelines for tightness
- Turn on fuel and waterlines
- Stow all loose gear
- Open engine cooling water intake thru-hull valve

FLOAT PLAN

1. Name of person reporting and telephone number:

2. Description of boat

NAME	TYPE	
MAKE	LENGTH	REGISTRATION#
HULL COLOR	STRIPE COLOR	DECK COLOR
OTHER DISTINGUISHING MARKS		

3. Number of Persons aboard

NAME	AGE	PHONE #
ADDRESS		
NAME	AGE	PHONE #
ADDRESS		
NAME	AGE	PHONE #
ADDRESS		

4. Engine

TYPE	H.P.	FUEL CAPACITY
------	------	---------------

5. Safety equipment

PFDs	<input type="checkbox"/>	Flares	<input type="checkbox"/>	Mirror	<input type="checkbox"/>	Flashlight	<input type="checkbox"/>
Food	<input type="checkbox"/>	Water	<input type="checkbox"/>	EPIRB	<input type="checkbox"/>	Raft/Dinghy	<input type="checkbox"/>

6. Radio

TYPE	FREQUENCIES
------	-------------

7. Trip Expectations

DEPARTURE TIME	DATE	FROM
DESTINATION	RETURN DATE	NO LATER THAN

8. Automobile:

LICENSE #	STATE	MAKE
COLOR	PARKED AT	

9. If not returned by-

Contact the Coast Guard or-

CALL - _____ AT- _____

AFTER SAILING CHECKLIST

When leaving your Hunter at the dock for more than a short time, it is a good idea to review the following checklist to make sure everything is in order. This

will help protect the various parts of your boat and add considerably to their attractiveness and usable life.

- Flake or furl mainsail and cover, or remove and bag.
- Remove and stow all portable deck hardware such as snatch blocks, winch handles, etc.
- Secure the boom to the topping lifts and set it firmly amidships with the main sheet purchase. (It is also a good idea to rig a line from the steering wheel or tiller to a convenience cleat to keep the rudder from swinging back and forth with the motion of the water or employ the wheel brake if so equipped.)
- Attach the shackle ends of all halyards to convenient fittings and take up slack. Find a location leading away from the mast to keep the halyard from slapping the mast.
- Coil and stow all lines in line lockers
- Cover the winches and steering pedestal when leaving the boat for several days or more
- Close all fuel lines and seacocks
- Switch off the electrical system
- Pump out the bilge
- Check air vents, secure ports and hatches, swab the deck, and clean deck stainless, particularly if you have operated in saltwater.
- Make a final check of mooring lines, chafing gear, fenders, etc.

SAFE BOATING TIPS

DOCKING

Docking your boat should be handled carefully to avoid potential damage. Under normal wind and water conditions, the following considerations should be made:

1. Whenever possible, your approach should be made against the prevailing wind and current to assist in stopping the boat. Where these conditions are contrary, the strongest should be used to determine approach.
2. Approaching the dock: dock lines should be at ready, loose gear stowed and decks cleared. Determine the direction of the wind and current and when you decide which side of the boat will be against the dock, rig dock lines and

fenders on the appropriate side. One dock line should be attached to the bow cleat, another to the stern cleat opposite the side that will lie against the dock.

NOTE: If the boat is to lie against a piling, rig a fender board across two or more pilings.

3. Tying up: attach bow and stern lines to dock, hauling boat in with fenders against dock. Rig crossing spring lines to limit motion forward and aft. Be sure to allow some slack in all lines to compensate for tidal activity if present. Never use bow rail, stern rail, or stanchions to secure a vessel, even for brief periods. For other types of moorings, or for abnormal wind or water conditions, consult an approved boating guide.

ANCHORING

Your Hunter comes with an on deck anchor well and a Danforth type anchor as standard equipment. The anchor is selected to suit the size and weight of your boat under normal anchoring conditions, and is most effective in muddy or sandy bottoms.

When anchoring, pay particular attention to the scope of your anchor rode (the relationship between of the water and the length of the rode). A good rule of thumb is to allow a scope of about 7:1 (a rode seven times as long as the vertical distance from the bow to the bottom). A helpful aid is to mark the rode every 20 feet or so with knots or other types of indicators. Before dropping anchor, make sure the bitter end is secured to the cleat in the anchor well. Also, be sure to consider wind direction, currents,

mean low tide depths and other local conditions when anchoring, as well as positions of any boats already anchored nearby.

To weigh anchor, motor or sail (under main only) forward slowly. When at a point directly above the anchor, a quick tug should free it from the bottom. Take care not to damage the topsides when hauling.

 WARNING
Anchoring in unusual water/ and or weather conditions will require additional precautions. Consult an approved guide for suggestions

SAFE BOATING TIPS

DIESEL ENGINE

An engine owner's manual is supplied with your boat and should be read thoroughly. It contains technical specifications, running instructions and a maintenance schedule on lubricants and fluids. For long engine life, follow routine maintenance schedules.

You should check engine oil, transmission fluid and coolant levels. Water, rust, scale and dirt will cause serious damage to the injectors on diesel engines. You should check your filters frequently and change when necessary. Check fuel line connections for proper tightness.

 WARNING
EXPLOSION/FIRE HAZARD – Fuel system connections that are to loose or to tight can leak, resulting in fuel loss, environmental pollution and explosion/fire hazard.

FUELING YOUR DIESEL ENGINE

 WARNING
EXPLOSION/FIRE HAZARD <ul style="list-style-type: none">•Store flammable material in safety-approved containers. Keep containers in a locker designed by the boat manufacturer for that purpose. Never store flammable material in a non-vented space.•Observe “No-Smoking” while fueling.•Run exhaust blower at least 4 minutes before starting engine. Check bilge and engine compartments for fumes.•Keep ventilation system free of obstructions. Never modify the vent system.•Fill less than the rated capacity of the tank. Allow for fuel expansion.•If fuel enters bilge, do not start engine. Determine cause and severity. Contact a knowledgeable marine service to remove fuel. Do not pump overboard. Contact Coast Guard for additional advice (See Environmental Considerations Fuel & Oil Spillage.)• Inspect fuel system regularly for leaks.

 DANGER
EXTREME HAZARD: carbon monoxide gas (CO) is colorless, odorless and extremely dangerous. All engines and fuel burning appliances produce CO as exhaust. Direct and prolonged exposure to CO will cause BRAIN DAMAGE or DEATH. Signs of exposure to CO include nausea, dizziness and drowsiness. Refer to BOATING SAFETY for more information.

When you start your engine, run it a minimum of 15 minutes to bring it up to operating temperature. This insures that any condensation is evaporated. Your engine should “run out” at $\frac{3}{4}$ throttle at least once a month to clean out carbon buildup and moisture.

 CAUTION
Follow engine manufacturer’s recommendations for types of fuel and oil. Use of improper products can damage the engine and void the warranty.

Notice: Use fresh fuel. Fuel that has been in a tank too long can form gum and varnish, which may affect performance.

Inspect diesel fuel filters regularly. Diesel fuel must be kept as clean as possible. Keep fuel tank full.

SAFE BOATING TIPS

STARTING YOUR DIESEL ENGINE

1. Visually check engine compartment to see that the throttle linkage, shifting controls, electrical connections and fuel lines are properly secured.
2. **Before each start** check oil in engine and transmission.
3. Insure that the engine shut-off cable is properly secured and operating.
4. Place the shift lever in the neutral position. Pull out the button beside the shift lever to disengage the shift. On single lever controls, lift the collar under the shift lever knob and move the lever forward to advance the throttle for neutral warm-up.
5. Insert the starter key and turn to the "on" position.
6. Press the starter button and hold until engine starts, then release. The buzzer and/or light should then go off. **Press the starter button no longer than 5 seconds continuously.**
7. Allow cold engine to warm up a minimum of five minutes.
8. When warm-up is completed, return the hand lever to neutral position, and push

the button back to re-engage the shift. The shift is ready for shift and throttle operation.

9. Check that the lube oil pressure warning light and the charge lamp go off. If any of the warning lamps do not go off above 1,000 rpm, the engine is malfunctioning and should be stopped immediately. Consult your nearest engine dealer.

NOTE: The H386 and below are equipped with an "engine stop" pull lever. When pulled all the way out, this will stop the engine at any time.



CAUTION

Follow engine manufacturer's recommendations for types of fuel and oil. Use of improper products can damage the engine and void the warranty.

MOTERING YOUR DIESEL ENGINE

Before departure, remember to unplug the shore power. When the engine is warm, but prior to releasing the dock lines, move the shift lever to forward and to reverse to insure that it is working properly. To increase RPMs, push throttle lever forward and pull back to decrease RPMs.

IMPORTANT: When sailing, it is best to start the engine before the sails are lowered. This way, it is possible to maneuver if the engine should not start.



CAUTION

Your rigging will conduct electricity. Always check for overhead high tension wires before proceeding. Once clear, you may increase your speed in a reasonable and safe manner as desired.

ELECTRICAL SYSTEM

Your Hunter is fitted with an electrical system designed for both AC and DC. While in port, you can operate any tool, appliance or other device designed to function on regular house current simply by plugging your dockside power cord into a convenient outlet on shore and turning your AC main breaker on.



WARNING

ELECTROCUTION HAZARD: If polarity is reversed, DO NOT use the shore power source. Immediately turn off the power source and disconnect the shore power cord. Reversed polarity is a dangerous and potentially lethal condition that may cause shock, electrocution, or death.

SAFE BOATING TIPS

ELECTRICAL SYSTEM (continued)

To minimize shock hazard, connect and disconnect cable as follows:

1. Turn off the boat's shore power connection before connecting or disconnecting shore power cable.
2. Connect shore power cable at the boat first.
3. If polarity warning indicator is activated, immediately disconnect cable and have the fault corrected by a qualified electrician.
4. Disconnect shore power cable at shore outlet first.
5. Close inlet cover tightly.

DO NOT ALTER SHORE POWER CABLE CONNECTORS.

Storage: Your shore power cable set is intended for use outdoors. To prolong the life of the set, store indoors when not in use.

General: The metallic parts of your cable set are made to resist corrosion. In a salt-water environment, periodically wiping the exposed parts with fresh water, drying and spraying with a moisture repellent can increase life of the product. A soiled cable can be cleaned with a grease cutting household detergent. A periodic application of vinyl protector to both ends will help to maintain cables original appearance.

In case of salt water immersion, rinse plug end and/or connector end thoroughly in fresh water, shake or blow out excess water and allow to dry. Spray with moisture repellent before re-use.

 WARNING
Do not allow your dockside power cord to come in contact with the water. Never operate any AC power tool or other electrical equipment while you or the device are in contact with the water, as this may cause electrocution resulting in shock or death.

When leaving port, disconnect the dock-side power cord and turn the main DC breaker on. This allows you to use the ship's lights and other equipment designed to operate on direct current. Keep in mind that your DC power source is a 12-volt battery, just as with your automobile, and it must be charged regularly by operating the engine (or by running the battery charger, if you have that option installed). Unless a state of charge is maintained, there may not be enough power to operate the starter motor. Dangerous situations can result if the engine cannot be started when needed.

Make a regular visual check of batteries to insure proper water level and inspect terminals for signs of corrosion. If your boat sits for long periods without use, it is often a good idea to remove the batteries and attach them to a trickle charger to keep them fully charged and ready to use.

 WARNING
EXPLOSION/FIRE HAZARD – ensure adequate ventilation of battery to prevent buildup of gases, especially hydrogen.

 WARNING
WHEN CHARGING THE BATTERY: <ul style="list-style-type: none">•Battery electrolyte contains sulfuric acid. Protect your eyes, skin and clothing. In case of contact, flush thoroughly with water and get prompt medical attention, especially if your eyes are affected.•Batteries generate hydrogen gas that can be highly explosive. Do not smoke or allow flames or sparks near a battery, especially during charging.•Charge the battery in a fully ventilated place.

SAFE BOATING TIPS

ELECTRICAL SYSTEM (continued)

Hunter Marine recommends that on all boats with either/both a house and start battery, the cables be disconnected during winter storage or any time the boat is out of the water for an extended period of time. Because of the continuous electrical drain placed on the 12 volt system by certain electrical components such as stereos and CO monitors you will be preserving your batteries life expectancies.

We recommend that owners who leave their boats in the water during the sailing season charge the boats internal batteries at least once every seven days during the sailing season (we do not recommend leaving power connected to

the boat if it is unattended). Completely depleting a batteries internal charge can drastically shorten its life span. This includes gel cell and glass mat batteries.

For owners who live aboard or wish to leave their boat battery switches in the on position while unattended (again, we do not recommend this) should consider installing a N20504W Nicro Solar vent to reduce the chances of the CO monitor's sounding. Only exchanging the air inside the boat on a regular basis or leaving the battery switches in the off position totally eliminates the false sounding of the monitors while 12-volt systems are operating.

COOKING STOVE

 WARNING
EXPLOSION/FIRE/ASPHYXIATION HAZARD
<ul style="list-style-type: none">•Open flame cooking appliances consume oxygen. This can cause asphyxiation or death.•Maintain open ventilation.•Liquid fuel may ignite, causing severe burns.•Use fuel appropriate for type of stove.•Turn off stove burner before filling.•Do not use stove for comfort heating.•Use special care with flames or high temperatures near urethane foam. Once ignited, it burns rapidly, producing extreme heat, releasing hazardous gasses and consuming a large amount of oxygen.

Carefully read and understand the manufacturer's instructions prior to operating your stove. Save the instructions for review, and also to pass on to any subsequent owners.

Use only the fuel recommended by the manufacturer, and store the fuel in an approved container.

Do not smoke while working with fuel.

Immediately clean up any spilled fuel.

SAFE BOATING TIPS

TOILET

IMPORTANT: When not in use, lever must be left in the “dry” position to prevent flooding.

Before using, place the lever in the “wet” position and pump slowly to partly fill and wet the inside of the bowl. Return to the “dry” position.

After using, return the lever to the “wet” position for flushing and pump until the bowl is thoroughly cleaned. Continue with several more full strokes to flush discharge lines. Return lever to “dry” position and pump slowly until bowl is empty.

- There is a possibility of being fined for having an operable direct overboard discharge of waste in some waters. Removing seacock handle, in closed position, or other means must be used to avoid fine.
- It is illegal for any vessel to dump plastic trash anywhere in the ocean or navigable waters of the United States.

 CAUTION
Do not place facial tissue, paper towels or sanitary napkins in head. Such material can damage the waste disposal system and the environment.

OPENING HULL PORTS

If your boat is equipped with opening hull ports, they must remain closed and secured while under sail. Your boat could take on water when it heels, causing damage to the interior due to flooding or even possible sinking of your vessel.

 CAUTION
All hull ports must remain closed and secure while sailing.

PUMPS

All pumps should be checked frequently to insure proper operation. This is an especially important regular maintenance item since a properly operating pump could save your vessel from serious damage.

tight. Check that the bilge pump impeller area is clean and free of obstructions. Inspect electrical wiring for corrosion. Ensure that the float switch functions properly.

 CAUTION
Run pump only as long as necessary to remove water. Dry running can damage the pump motor

 WARNING
SINKING HAZARD – Ensure proper bilge pump operation.

Inspect all bilge pump hoses for chafing and dry rot. See that all hose clamps are

SAFE BOATING TIPS

WATER SYSTEM OPERATION

Fill fresh water tank at deck fill. The tank filler cap will be marked "water". When tank is full, water will back up through the vent hose and exit through a vent located on the side of the hull. Use tank gauge for filling. D.C. main should be turned on first.

To activate the water system, turn on D.C. main, flip the "water pressure" switch on the electrical panel. This will start the pump and pressurize the system. When the pressure builds, the pump will shut off. With continued use of fresh water the pressure in the system is reduced, automatically restarting the pump. Make sure there is water in the system while pump is in operation to prevent damage to the motor. The pump will also run if a leak develops in the system.

NOTE: Intermittent operation of the fresh-water pump while all faucets are closed usually indicates a leak somewhere in the lines. Trace the lines to locate the leak and repair.

 CAUTION
Run pump only as long as necessary to remove water. Dry running can damage the pump motor

The water heater operates either on 120 or 240 volts AC or when the engine is running. To obtain hot water from the engine, it must run a minimum of one-half hour.

Pressure water pumps are the demand type. Once the circuit breaker switch is on, opening the faucet will produce water flow.

To operate shower, turn on hot and cold faucets until desired temperature is reached, while the showerhead is retracted at sink. Pull the showerhead out and use. The faucets must be turned off to prevent system drainage.

Opening the faucet will allow the pump to empty the tank. Flushing the tank and lines will be necessary for winterization. Refer to Maintenance & Winterization section for more information.

 WARNING
SINKING HAZARD –To ensure the safety of your vessel, always disconnect shore water and power connections when leaving your boat unattended.

WASTE DISCHARGE

The Hunter is equipped with a head waste holding tank, hose lines, and thru-fittings for either overboard discharge, using the standard equipped hand pump, deck pump out at dockside or Macerator Pump. Tank levels will be indicated on the gauge located below the

main electrical panel. Familiarize yourself with the locations of the deck pump out, overboard discharge thru-hull, and vent locations pictured in the Waste Water System section, as well as your local boating regulations concerning the overboard discharge of raw sewage.

ENVIRONMENTAL CONSIDERATIONS

FUEL AND OIL SPILLAGE

The spilling of fuel or oil into our waterways contaminates the environment and is dangerous to wildlife. Never discharge or dispose of fuel or oil into the water. It is dangerous and unlawful. Two common types of accidental discharge are overfilling the fuel tank and pumping contaminated bilge water into the sea.

 WARNING
EXPLOSION/FIRE/POLLUTION HAZARD: Fill fuel tank to less than rated capacity. Overfill forces fuel out the tank vents, which can cause explosion fire, or environmental pollution. Also allow for fuel expansion

DISCHARGE AND DISPOSAL OF WASTE

Waste means all forms of garbage, plastics, recyclables, food wood, detergents, sewage, and even fish parts in certain waters. We recommend that you bring back everything you take out with you for proper disposal ashore.

Your marine holding tank (if so equipped) must, in many areas, be pumped out by an approved pump-out facility normally found at marinas.

EXHAUST EMISSIONS

Hydrocarbon exhaust emissions pollute our water and air. Keep your engine

properly tuned to reduce emissions and improve performance and economy.

ANTI-FOULING PAINTS

The use of anti-fouling paints is common for boats kept in water. Be aware of environmental regulations that may govern your paint choice. These regulations may affect which paint may be used, and also the application or removal. Contact your local boating authorities for more information

 WARNING
EXPLOSION/FIRE/HAZARD: Ventilate when painting or cleaning. Ingredients may be flammable and/or explosive.

CLEANING CHEMICALS

Cleaning chemicals should be used sparingly and not discharged into waterways. Never mix cleaners and be sure to use plenty of ventilation in enclosed areas. Do not use products that contain phosphates, chlorine, solvents, non-biodegradable or petroleum-based products.

Common households cleaning agents may cause hazardous reactions. Fumes can last for hours, and chemical ingredients can attack people, property and the environment.

INSTRUCTIONS FOR PREPARATION FOR BOTTOM PAINTING

WARNING!

Do not use any sanding, sandblasting or other abrasive reparation of the bottom, as this will void your hull

blistering warranty. See the warranty information at the beginning of this manual.

BOTTOM PAINTING

Choose a bottom paint system that suits the environment in your area. Follow the procedure recommended by the manufacturer of the paint, while making sure not to void the Hunter Hull Blistering Warranty. The

procedure for preparing and painting the bottom varies between paint manufacturers, but should always include dewaxing, etching and sometimes priming of the surface.

EPOXY BARRIER COAT

Sanding of the gel coat bottom surface will be permitted should a customer wish to have an epoxy barrier coat applied to the hull, (example Interlux Interprotect 1000, 2000, West System or VCTar). This will not void the Five-Year Blister Warranty.

Hunter Marine refers to epoxy barrier coatings as mentioned above, not epoxy primer paints.

If an epoxy barrier coat is applied to a Hunter vessel, it must be registered with the Warranty Department

prior to application of the product. If the dealer applies bottom paint only, sanding **will not** be allowed and the no sanding system must be used.

 WARNING
Cleaning agents and paint ingredients may be flammable and/or explosive, or dangerous to inhale. Be sure to use adequate ventilation, and appropriate safety clothing. (gloves, safety glasses, respiration, etc)

ENGINE, TRANSMISSION & DRIVETRAIN

ENGINE

Follow the fuel and lubrication requirements in the Engine Manual. Check the engine oil level before and after operation and use a quality motor oil (refer to Engine Manual). Be certain the proper amount of oils is in the crankcase at all times

Engine Alignment: the engine should be aligned by experienced marine service personnel. Final alignment should be done after launching, with all normal gear aboard. A description of the procedure follows:

The coupling flanges must come together evenly at all points, a feeler gauge is used to check the gap. If adjustment is necessary, the engine is tilted up or down and/or side-to-side until the flanges meet evenly. Severe vibration will result from misalignment and can cause strut bearing and shaft damage. Alignment should be checked again after several weeks of use. Routine checks of coupling bolts are a must to ensure they are tight.

Shaft Alignment:

1. Separate the coupling, move the shaft end back to clear the pilot in the center.

2. Establish the shaft in the center of the shaft log by raising the shaft until it touches the top of the log – note position – lower the shaft until it touches the bottom of the log – note position – repeat sideways and locate shaft in the center; block shaft in this position, using a block of wood under the shaft packing gland.

3. Now, adjust the engine mounts to allow the pilot on the coupling halves to slip together without moving shaft up down or sideways.

4. Adjust the engine mounts as necessary until a .004" feeler gauge will not enter anywhere along the edge of the flange between the faces.

5. Tighten the locks on the adjustable mounts

6. Recheck coupling with feeler, readjust if necessary.

7. Check stuffing box (allow to drip 3 to 5 drops per minute).

Any questions or problems concerning the engine, please contact the U.S. distributor, Mastery Marine at (727) 522-9471, or your local Yanmar service agent.

TRANSMISSION

Follow the lubrication requirements of the engine manual. The oil level should be

checked immediately after operation.

STUFFING BOX


The stuffing box is held to the stern bearing by a rubber hose secured with hose clamps. (See the Shaft and Propeller section). The clamps should be tight and no water should leak from this location. While underway a slight drip from the stuffing box at the shaft exit is necessary (three to five drops a minute) and is normal. To adjust, loosen the locknut, tighten the gland nut one-quarter

turn, a retighten the locknut. If excessive water flow persists after adjustment, replace the packing with 3/16" (or 5mm) square flax packing and then adjust as above.


NOTE: Some models use a packless sealing system. Page 56 or Pages 56A, B, C, reflects the type of stuffing box used on this model.

ADJUST THE VERTICAL & HORIZONTAL ENGINE MOUNTS AS NECESSARY TO OBTAIN A MAXIMUM GAP OF 0.004" (.10 MM) BETWEEN THE COUPLING FLANGE FACES. USE A 0.004" FEELER GAUGE ALL THE WAY AROUND THE COUPLING TO ESTABLISH THE CORRECT TOLERANCE.

CHECK FOR THE COUPLING GAP WITHOUT THE COUPLING BOLTS IN PLACE.



0.004" FEELER GAUGE



ENGINE VERTICAL ADJUSTMENT

ENGINE HORIZONTAL ADJUSTMENT

MAINTENANCE

COMPASSES

A boat compass rarely exists in an environment that is completely free from magnetic materials or influences.

The compass on your boat should be adjusted by a certified compass adjuster and have a deviation table made for it.

If you must depend solely on your compass for navigation, make a quick check for any objects near the compass that may cause additional, unmeasured deviation. Typical objects that may fall in this category include: knives, small radios, flashlights or other tools.

STEERING

Refer to the manufacturer's instruction for maintaining pedestal steering system. Routinely inspect steering system components.



WARNING

CONTROL HAZARD – Inspect and maintain steering system regularly. An improperly maintained system may fail, causing sudden loss of steering control, resulting in personal injury and property damage.

ELECTRICAL SYSTEMS

The electrical system is a 12-volt, negative ground installation, plus a shore power system of either 120v or 220v. The owner should inspect batteries, terminals and cables weekly for signs of corrosion, cracks, and electrolyte leakage. Battery terminals are to be kept clean and greased. Refer to separate instructions on batteries, wiring diagram, and electronics.



WARNING

SHOCK/FIRE HAZARD

Replace breaker or fuse with the same amperage device. Never alter over current protection.



WARNING

SHOCK/FIRE HAZARD

- Disconnect electrical system from its power source before performing maintenance. Never work on the electrical system while it is energized.
- Electrical appliances must be within the rated amperage of the boats circuits.
- Observe boat carefully while the electrical components that can be left unattended are the automatic bilge pump, fire protection and alarm circuits.
- Only a qualified marine electrical technician may service the boat's electrical system.



CAUTION

- Turn off engine before inspecting or servicing battery.
- Disconnect battery cables before working on electrical system to prevent arcing or damage to alternator.

MAINTENANCE

PLUMBING SYSTEMS

All pumps should be checked frequently to insure proper operation. This is an especially important regular maintenance item since proper functioning of a pump could save your vessel from serious damage in the future.

Inspect all hoses for chafing and deterioration. See that hose clamps are tight. Check that the pump impeller area is clean and free of obstructions.

Inspect electrical wiring for corrosion. Make sure float switches move freely and are making an electrical connection.

The owner should become familiar with the layout of the water and waste sys-

tems by walking through the boat with the diagrams provided in this manual. It is especially important that the owner knows all the thru-hull valve locations and inspects for leaks frequently. Refer to plumbing diagrams in Specifications and Technical section of this manual.

General Thru-hull Lists (varies from boat to boat---see diagrams in Systems and Circuits section).

- 1) Engine cooling system
- 2) Galley sink
- 3) Head sink
- 4) Head toilet (water intake)
- 5) Holding tank discharge
- 6) Scupper drains

FUEL SYSTEMS

The owner should inspect the condition of fuel lines for cracks or leaks. A primary source of fuel-related problems is water in the system. The owner should use only well maintained fueling facilities and make sure fuel fill caps are tightly secured after filling. Check and maintain

fuel filters periodically. Refer to your Engine Manual for additional information. Periodically, add biocide to prevent bacteria and fungi from contaminating diesel fuel that may contain some water. Carefully follow manufacturer's instructions and clean filter regularly.

MAINTENANCE

CLEANING FIBERGLASS SURFACES

Fiberglass surfaces should be cleaned regularly. Normal accumulations of surface dirt can be removed simply by occasional rinsings with water. If you operate your boat in salt water, more frequent rinsing will be required. To remove stubborn dirt, grease or oil, use a mild detergent and a soft brush. Rinse with fresh clean water. Avoid the plexiglass companionway slider, windshield, deck hatches and fixed ports when using a deck brush, since these surfaces can scratch.

It is a good idea to wax the fiberglass once or twice a year to maintain a deep, glossy appearance. Your local marine supply should be able to provide an appropriate wax.



WARNING

EXPLOSION/FIRE HAZARD

Cleaning agents and paint ingredients may be flammable and/or explosive, and dangerous to inhale. Be sure to use adequate ventilation, and appropriate safety clothing (gloves, safety glasses, respirator, etc.)

CLEANING ACRYLIC

Use only mild soap and water to clean acrylics. Do not use products containing solvents such as ammonia, which is found in many window cleaners.



CAUTION

Use care when cleaning acrylic. Dry cloth and many glass cleaners will scratch. Solvents will attack the surface.

SAIL CARE

Sunlight is a sail's worst enemy, so **cover the mainsail when not in use**. An ultraviolet guard, fitted down the leech of a roller headsail will protect the exposed part from the weathering effect of the sun and from dirt and grit.

Mildew, can be prevented by storing sails dry and by hand washing twice a season. Check all sails regularly for chafe, particularly where they chafe on deck fittings or rig-

ging, at reef points, batten sleeves and the foot of the headsail. Sail batten pockets should be inspected on a regular basis.

To stow the mainsail, start at the leech and flake it onto the boom, left and right, in about 18-in. (46 cm) folds, while pulling the leech aft. Secure with a sail tie and continue to the luff. Lash to the boom with sail ties or shock cord.

GENERAL HARDWARE MAINTENANCE

Check all fittings regularly to be sure screws are tight. Occasionally lubricate (use silicone lubricants) all moving parts on such fittings as blocks, turnbuckles and cam cleats, as well as the locking pins of snatch blocks, track slides, spinnaker poles, etc. Inspect cleat and fairleads for roughness and smooth with

fine-grained emery paper if necessary. Also, replace any missing or damaged cotter pins in turnbuckles and shackles, and either tape them or use them or use protective covers manufactured for that purpose. Grease winches a minimum of once yearly.

WINCH MAINTENANCE

Follow the maintenance instructions prescribed by winch manufacturer.

We recommend a minimum of an annual cleaning and light greasing.

VINYL CARE

These patterns, like all upholstery fabrics and vinyl, require a regularly scheduled cleaning program. A thorough cleaning should be administered on a daily, weekly or monthly basis depending on use and exposure to dirt and/or staining agents. It is important to begin treatment of a stain as soon as possible after a spill. It is important that efforts begin immediately after a spill to remove any potential staining agent. It is advisable to clean these products as soon as the first signs of dinginess occur, otherwise, delaying clean up will require a much greater effort to restore the product to its original appearance.

Regular cleaning requires the use of a mild cleaner such as Murphy's Oil soap and water. In situations where the vinyl has not been washed regularly and there is a build up of dirt, stronger vinyl cleaners such as Simonize's Tuff Stuff or Turtle Wax's vinyl/fabric cleaner are recommended. We do not recommend the use of any other cleaners. The use of cleaners other than

those recommended may result in irreparable damage to the product.

In order for the above listed cleaning solutions to work effectively on stubborn stains, please allow time for the cleaning solution to soak in thoroughly. Be sure to remove the cleaning solution before it has time to dry. Regardless of the type of cleaner used, it is necessary to finish up with a thorough rinse using fresh water on a clean sponge or rag. A soft bristled nylon or natural fiber brush can be used to remove built-up dirt and staining agents.

Finally, please remember that all our fabric grain vinyls require a greater cleaning effort to maintain than comparable smooth grain vinyls. These products will provide an attractive and durable alternative to conventional fabrics and vinyls if properly maintained. One must realize that the proper installation and use of our fabric grain vinyls require additional attention to the establishment and maintenance of a well thought out cleaning program.

CAUTION

Do not use acetone or other harsh cleaners on the vinyl soft headliner. Use soapy water or other mild detergent to avoid damage to the vinyl.

FABRIC CARE

Vinyl: Clean with mild soap and water. Wipe with vinyl or upholstery cleaner monthly, and especially before and after storage.

Leather: Mild soap water. Blot dry. Do not scrub as this will stretch and scratch. Wipe with leather cleaner/oil to preserve and help prevent cracks before and after storage.

Fabric: Blot dry. Do not machine wash. Use only mild soap and water. Wipe with a clean white cloth. If stain persists, dry clean. Be sure to treat cleaned surfaces with scotch

guard. Stretched or loose covers may be steam cleaned. If foam is removed, it will restuff more easily if wrapped with thin plastic.

Storage: Cover with airflow fabric to reduce dust build up. Do not use plastic, as this will cause cushions to sweat and mildew.

Cushions: If wet, prop cushions vertically to promote airflow around each cushion. Cushions can be cleaned by most dry cleaners.

Dry clean only.

REPAIR OF POLYURETHANE (MINWAX) FLOORS

Surface Scratches: Sand floor with 220 grit sandpaper. Remove all dust with clean cotton cloth or blow off with air. Apply one coat of minwax evenly over sanded floor. Let dry completely, at least 24 hours

Deep Scratches: Remove all blemishes by sanding floor with 220, until all minwax is removed and you have a raw floor. Remove all dust with clean cloth or blow off with air. Apply one coat evenly over floor. Let dry four to six hours. Repeat steps one and four. Apply third coat of minwax only if needed by repeating steps one and four.) After final coat, let floor dry completely at least one day.

ELECTROLYSIS AND GALVANIC PROTECTION

Salt water allows electric current to flow from anodic to cathodic material. For any two metals from two components, their relative positions in the galvanic rating table, will determine which loses material (the anode) and which remains largely undisturbed (the cathode). The distance between the two metals on the galvanic table determines the rate of wear. Thus a sacrificial zinc anode is often fitted to the underwater area of a boat to attract any destructive currents away from bronze or steel propeller shafts, for example. It is not enough to know that your boat does not suffer from electrolysis; a newcomer in the adjacent marina berth may start a too-

friendly association with metal components on it. An easy place to fit an anode is on the propeller shaft, or covering the propeller nut. The anode should not be painted; this would render it ineffective.

To prevent electrolysis in seawater, the difference between the voltages of the two adjacent metals should not exceed 0.20 V. For example, zinc and carbon steel used together risk corrosion, while lead and active stainless steel are compatible. Metals with a high voltage corrode faster and need a larger area to diffuse the electrochemical reaction.

TEAK CARE (240,260,and 270 ONLY)

Teak wood is a high quality, extremely durable wood with high oil content. In order to help you protect the original beauty of your teak interior, we have sealed the wood with a 3 to 4 coat system of high quality Seafin Teak Oil, manufactured by Dalys. This material is penetrating oil that dries to a low sheen to seal and protect the wood from

moisture and weathering. It creates a durable, nonslip surface to repel water and resist wear. It won't chip, peel or blister. It reduces work and maintenance cost because it is easy to repair and maintain and repair. With proper maintenance it will outlive urethane varnish on interior and even exterior surfaces

MAINTENENCE

When oiled surfaces require renewing, simply wipe the surface area free of loose dirt, dust or other contaminants. Dampen a cloth with the

Seafin Teal Oil and wipe on. Let stand for 5-15 minutes, then polish dry. If your dinette table has an epoxy finish, clean with furniture polish

REPAIRS

When woodwork is damaged from scrapes or abrasions that go into or thru the finish, take the following steps:

1. Take 180 to 200 grit wet/dry sand paper to smooth out rough spots.
2. Wipe clean of dust and dirt with a clean rag. Note: before applying oil, wood surface must be dry.
3. Wipe or brush on oil, allow to penetrate 5-15 minutes while surface is still wet.
4. Sand until smooth with 400A wet/dry sandpaper.
5. Wipe dry with a clean rag. Allow 8-12 hours drying time.

6. Apply second coat, sand, and repeat procedure.

This procedure may be repeated as many times as needed to bring damaged area back to its original finish. If you have trouble with getting the same sheen, you may use a soaked and wrung out cloth to apply a very light coat to get an even sheen.

For more information about the product contact:

Dalys
3525 Stoneway North
Seattle, WA 98103
(206) 633-4200

INTERIOR FURNITURE & BULKHEAD SPRAY FINISH

TEAK CARE

Teak wood is a high quality, extremely durable wood with a high oil content. In order to help you protect the original beauty of your teak, we have sealed the interior with a (3 to 4) spray coat finish, using sealer and varnish for marine cabinets. The materials are

manufactured by "Chemcraft International Inc". This material will seal and protect the wood from moisture and weathering. It is easy to maintain and reduces work and maintenance costs.

REPAIRS

When woodwork is damaged from scrapes or abrasions (that go into or through the finish), take the following steps:

- 1) Sanding with the grain, take 320 grit sand paper to smooth out rough spots. If the spot is down to the raw wood, rag (100% cotton) wipe the spot with acetone and allow to dry. (Note: acetone only needs to be applied to the raw teak).
- 2) Reseal raw wood with Mohawk Spray Sealer (aerosol can) and allow to dry.
- 3) Lightly sand with 320 grit, sanding larger than original spot.
- 4) Wipe clean of dust and dirt with a clean rag.
- 5) Using Mohawk touch up and repair supplies, use clear lacquer spray (aerosol can). Apply (1) coat on the spot evenly and allow to dry.
- 6) This process (steps 3 – 5) may be repeated as many times needed to bring damaged area back up to its original finish. On your final spraying, be sure to feather into existing finish.

SOP FOR POLYURETHANE (MINWAX) FLOORS

SURFACE SCRATCHES

- 1) Sand floor with 220 grit sandpaper until all scratches are removed.
- 2) Remove all dust with a clean cotton cloth or blow off with an air gun, then wipe down with a tack cloth.
- 3) Apply one coat of minwax evenly over the sanded area.
- 4) Let the minwax dry completely (at least one day)

DEEP SCRATCHES

- 1) Sand floor with 220 grit sandpaper until all the minwax is removed and down to raw wood, removing all blemishes.
- 2) Remove all dust with a clean cotton cloth or blow off with an air gun then wipe down with a tack cloth.
- 3) Apply one coat of minwax evenly over the floor.
- 4) Let minwax dry 4-6 hours
- 5) Repeat steps 1-4, light sand
- 6) Apply a 3rd coat if needed by repeating steps 1-4.
- 7) Let the minwax dry completely (at least one day)

Chemcraft International

Telephone: 910-723-1846

U.S. Watts: 1-800-334-8556

Mohawk Finishing Products, Inc.

U.S. Watts: 1-800-545-0047

STORAGE/WINTERIZATION

IMPORTANT

Winter storage is recommended to be done in one of the following three ways, either: 1) by blocking the boat via a cradle 2) with chained stands on level ground; or 3) by storing the boat in the water with a bubbler system to prevent icing. Damage to your boat, including engine misalignment caused by twisting, is not covered by the warranty.

SAILS

Sails should be properly folded and stowed in a dry, well-ventilated place. Many sailboat owners send their sails back to the sail manufacturer at the end of each season. The sailmaker will check the stitching and sailcloth for wear and store the sails until the start of the next season.

ELECTRICAL

Remove battery from boat (Refer to Engine Manual) and charge. It is a good idea to also remove the electronics (radio, radar, etc) and store in a safe place.

CUSHIONS

Cushions should be removed and stored at home if possible. If not, prop them vertically to promote air flow around each cushion. *Dry clean only!*

HATCHES

Tenting the deck during storage will help prevent ice from forming and damaging hatches and deck fittings. The installation of a passive vent will help with ventilation while the boat is in storage.

WATER SYSTEM

Open a faucet and allow the pump to empty the tank. Then add approximately two gallons (7.6L) of non-toxic antifreeze solution to the tank and repeat the pumping out procedure.

A second method is to disconnect the hoses at the pump, allowing

them to drain. Find the lowest point in the system and disconnect the fitting. Open all faucets to allow the lines to drain. If possible, use a short section of hose on the faucet to blow through the lines to clear all water. A diluted solution with baking soda will help freshen the system.

WATER SYSTEM

Open valve and drain fully leave valve open during lay-up time.

TOILET AND HOLDING TANK

Drain and flush toilet. Using non toxic antifreeze in a 50/50 mixture with water, pump through toilet and into holding tank.

OUTBOARD ENGINE

Take it home and store it in a safe place. Be very careful storing the gas tank as the gasoline is very flammable. Refer to Engine Manual for specific maintenance schedule.

INBOARD ENGINE

Winterizing Fresh Water Cooled Diesel Engines

1. Drain crankcase and transmission and refill with fresh lubricant as specified in Engine Manual.
2. Drain and clean all fuel filters and change elements, gaskets, and seals. Bleed all air from fuel systems.
3. Start engine and bring up to operating temperature.
4. Close the sea cock, remove the raw water pickup hose from the raw water pump and immerse one end into a 5-gallon (19L) bucket of anti-freeze solution. Start engine and run

STORAGE/WINTERIZATION

until antifreeze solution comes out exhaust stack or until bucket is empty. Attach the raw water pickup hose to the raw water pump. Tighten all clamps. **NOTE: This procedure bypasses the sea strainer to prevent antifreeze from crystallizing in sea strainer, which warranty will not cover.**

5. Loosen water pump and alternator belts to lessen tension on belts during winter.

6. For engines equipped with a hand crank: pull compression release levers and turn engine slowly with the hand crank. Slowly pour about 2 ounces of engine oil into the intake pipe or manifold while hand cranking the engine. This will allow for a thin coat of oil on the valves and upper cylinder. **DO NOT USE** starter to turn engine or serious engine damage may result.

7. Tape the openings of the intake and exhaust manifolds with duct tape to help prevent corrosion of the upper cylinder during layup.

8. Scrape all rust or corrosion from exposed metal parts and surfaces. Scrub all metal surfaces with detergent and rinse thoroughly. Paint any bare metal.

9. Place a dust cover over engine. Do not leave the engine exposed to rain and sea breeze.

10. Disconnect the battery cables; remove the battery from the boat. Clean the terminal ends and battery with a solution of baking soda and water, and then rinse thoroughly with clean water. Apply a light coat of grease on the terminal end of the battery and cables. Store the battery in a cool dry place. Use a trickle charger to keep battery charged. Do

not charge battery near any open flame or a confined area.

CAUTION: Wear safety goggles and rubber gloves to protect your skin.

Winterizing Raw Water Cooled Diesel Engines

1. Drain crankcase and transmission and refill with fresh oil as specified in the engine manual. Change oil filters.

2. Close seacock, remove raw water pickup hose from water pump, attach 4-foot (1.2m) length of hose to water pump and immerse in a 5 gallon(19L) bucket of anti freeze solution. Remove hose from engine or manifold that leads to exhaust elbow. Attach about a 4-foot length of hose and immerse one end in the bucket of antifreeze solution. Start engine and run until water begins to warm up (about 3-5 min.) and the thermostat opens. Stop engine. Replace hose that leads to exhaust elbow. Start engine and let run till water comes out exhaust pipe. Stop engine, remove hose from water pump to bucket, attach hose from seacock to water pump and tighten all hose clamps. **NOTE: this procedure bypasses the sea strainer to prevent antifreeze from crystallizing sea strainer, which warranty will not cover.**

3. Loosen water pump and alternator to lessen tensions on belts during winter.

4. Drain and clean all fuel filters and change elements, gaskets and seals. Bleed all air from fuel systems.

5. Pull compression release lever and turn engine slowly with hand crank. Slowly pour about 2 ounces of

STORAGE/WINTERIZATION

engine oil into the intake pipe or manifold while engine is turning.

DO NOT USE the starter to turn engine or serious engine damage may result.

6. Tape the openings of the intake and exhaust manifolds with duct tape to help prevent corrosion of the upper cylinder during lay-up.

7. Scrape all rust or corrosion from exposed metal parts and surfaces.

Scrub all metal surfaces with detergent and rinse thoroughly. Paint any bare metal.

8. Place a dust cover over engine. Do not leave engine exposed to rain and sea breeze.

9. Disconnect the battery cables; remove the battery from the boat.

Clean the terminal ends and battery with a solution of baking soda and water and rinse thoroughly with clean water. Apply a light coat of grease on the terminal end of the battery and cables. Store the battery in a cool dry place. Use a trickle charger to keep battery charged. Do not charge battery near any open flame or in a confined area.

CAUTION: Wear safety goggles and rubber gloves to protect your eyes and skin.

DEPARTURE FROM THE BOAT

The check list for leaving a boat unattended is very important because items overlooked often will not be remembered until you are far from the boat and corrective actions are impractical or impossible.

Primary choices for this list are items relating to the safety and security of the unattended craft: turning off fuel valves, properly setting electrical switches, pumping out bilge and leaving the switch on automatic (or arrange for periodic pumping out). **It is recommended that the power be turned off when leaving the boat.** Other departure checklist items are securing ports, windows, hatches and doors.

ROUTINE MAINTENANCE

Routine maintenance checklists should include items based on how much the boat is used (usually in terms of engine hours) and on calendar dates (weekly, monthly or seasonal checks). Typical of the former are oil level checks and changes, and oil and fuel filter changes.

On a calendar basis the lists should note such matters as electrolyte levels in storage batteries, pressure gauges on dry chemical fire extinguishers, and all navigation lights. Check the operation of automatic bilge alarms or pump switches by running water into the boat. Periodically close and open

sea cocks several times to ensure their free and easy operation in case they are needed in an emergency. Equipment and supplies carried on board for emergencies should be inspected for any signs of deterioration.

CE CERTIFIED

Your Hunter has been manufactured in the United States and has been certified by the IMCI to be in compliance with the relevant parts of the Recreational Craft Directive 94/25/EC from the European Parliament. The CE mark means your craft meets or exceeds all current International Organization for Standardization (ISO) standards and directives in effect at time of manufacture. The builder's plate, affixed to your boat, describes various parameters involved in the design of your boat. Please refer to it regularly when operating your boat.

Following are the Design Categories, established by the Recreation Craft Directive, which is to be considered a guideline of use application as per the Directive's criteria. Hunter Marine Corporation does NOT establish these criteria, and the category indicated is only a reference to the assigned category. The safety of the captain and crew of any vessel is not measurable by such categories, and you should not interpret these categories as an indication of your safety in such condition. The skill of your captain and crew, together with proper preparation, appropriate safety equipment for the given conditions and a well maintained vessel are critical to safe sailing.

CE CRAFT DESIGN CATEGORIES

Category A – “Ocean”: Craft designed for extended voyages where conditions may exceed wind force 8 (Beaufort Scale) and include significant wave heights of 4m, for vessels that are largely self-sufficient.

Category B - “Offshore”: Craft designed for offshore voyages where conditions include winds up to and including wind force 8 and significant wave heights up to and including 4m may be experienced.

Category C – “Inshore”: Craft designed for voyages in coastal waters, large bays, estuaries, lakes and rivers, where conditions up to and including wind force 6 and significant wave heights up to and including 4m may be experienced.

Category D – “Sheltered Waves”: Craft designed for voyages on small lakes, rivers and canals, where conditions up to and including wind force 4 and significant wave heights up to and including 0.5m may be experienced.

For additional information, contact


International Marine Certification Institute (IMCI)
Treves Centre, rue de Treves 45
1040 Brussels, Belgium
FX: (32) 2238-7700

NMMA CERTIFIED

Your Hunter has been judged by the National Marine Manufacturers Association (NMMA) to be in compliance with the applicable federal regulations and American Boat and Yacht Council (ABYC) standard and recommended practices in effect at the time of manufacture.

For additional information, contact:


National Marine Manufacturers Association
200 E. Randolph Dr., Suite 5100
Chicago, IL 60611
PH: (1) 312-946-6200 FX: (1) 312-946-0388



LIGHTNING STORM WARNING:


- 1. ALL WHIP ANTENNAS SHOULD BE TIED DURING STORM, UNLESS PART OF THE LIGHTNING PROTECTION SYSTEM.**
- 2. PRECAUTIONS: DURING LIGHTNING STORMS: A. THE SHIPS OCCUPANTS SHOULD TAKE SHELTER INSIDE A CLOSED AREA OF THE BOAT. EXAMPLE: BELOW DECK. B. OCCUPANTS SHOULD NOT HAVE ANY BODY PARTS IN THE WATER. C. AVOID CONTACT WITH ANY COMPONENTS OF THE L.P.S. AND D. AVOID ALL CONTACT WITH ANY METAL OBJECTS.**
- 3. SEE DIAGRAM BELOW FOR INFORMATION ON THE LIGHTNING PROTECTION ZONE.**
- 4. IF LIGHTNING SHOULD STRIKE THE SHIP, INSPECT ALL ELECTRONICS, ELECTRIC GEAR, COMPASS AND L.P.S. SYSTEM FOR POSSIBLE DAMAGE. RECALIBRATE AS NECESSARY. NOTE: BEGIN CHECKING ELECTRONICS AFTER THE THREAT OF LIGHTNING HAS PASSED.**

FAILURE TO FOLLOW PRECAUTIONS MAY RESULT IN SEVERE INJURY OR DEATH



MAST HEIGHT (40.25 ft. / 12.27 m)
(FROM DETERMINED WATER LINE)

$I = 32' 0'' (9.75 \text{ m})$
 $J = 11' 0'' (3.35 \text{ m})$
 $P = 29' 08'' (8.9 \text{ m})$
 $E = 12' 0'' (3.66 \text{ m})$



This document contains information for which HUNTER MARINE CORP. has proprietary rights.


HUNTER

H306 STANDARD SAIL PLAN

DESIGN NO.	3068036A	REVISION NO.	NONE
DATE	3/18/99	ENGINEERING DEPT.	

MAST HEIGHT (44.25 ft. / 13.56 m)
(FROM DETERMINED WATER LINE)

$I = 32' 0'' (9.75 m)$
 $J = 11' 0'' (3.35 m)$
 $P = 32' 8'' (9.96 m)$
 $E = 12' 0'' (3.66 m)$



This document contains information for which HUNTER MARINE CORP. has proprietary rights.



HUNTER



PROJECT TITLE	H306 OPTIONAL FURLING SAIL PLAN		
DRAWING NO.	3068036B	REVISION NO.	NONE
DATE		DATE	3/18/99
ENGINEERING DEPT.			

DIMENSIONS, CAPACITIES, ETC.

HUNTER 306

LENGTH OVERALL (LOA).....	29' 11"	9.12m
LENGTH OF WATERLINE (LWL).....	26' 11"	8.19 m
BEAM (MAX).....	10' 9"	3.28 m
DRAFT (SHOAL).....	3' 10"	1.17m
DRAFT (DEEP).....	5' 4"	1.63m
DISPLACEMENT (SHOAL).....	7,150 lbs	3,246 kg
BALLAST (SHOAL KEEL).....	2,130 lbs.	966 kg
BALLAST (DEEP KEEL).....	2,292 lbs.	1,040 kg
SAIL AREA (100% TRIANGLES).....	349.5 sq. ft.	32.47 sq.m
SAIL AREA (ACTUAL W/STANDARD SAILS).....	400 sq. ft.	37.16 sq.m
I.....	32' 0"	9.75 m
J.....	11' 0"	3.35 m
P.....	29' 1"	8.90 m
E.....	12' 0"	3.66 m
MAST HEIGHT (FROM WATERLINE).....	42' 6"	12.95 m
HEADROOM.....	6' 2"	1.88 m
WATER CAPACITY.....	40 U.S. gal.	151 liters
HOLDING TANK CAPACITY.....	20 U.S. gal.	76 liters
FUEL TANK CAPACITY.....	20 U.S. gal.	76 liters
LPG TANK CAPACITY.....	5 lbs.	2.28 kg
WATER HEATER CAPACITY.....	6 U.S. gal.	23 liters
BATTERY CAPACITY.....	DEALER SUPPLIED	
ELECTRICAL VOLTAGES.....	12 V.D.C.	110 A.C.
INBOARD ENGINES.....	SELECT OVERSEAS MODELS 220 V	
PROP SIZE.....	YANMAR 2GM20F (18 hp)	13.4 kw
	(15 X 12 R.H.)	
MAXIMUM LOADING.....	9 PEOPLE	1165 kg (INCLUDING LUGGAGE)
LIFTING POINTS.....	INDICATED BY "SLING" LABELS ON HULL	






This document contains information for which HUNTER MARINE CORP. has proprietary rights.

HUNTER

H306 OPTIONAL DECK HDWR LAYOUT

REVISED NO.	3068038b	REVISION NO.	NONE
DATE	3/20/99	ENGINEERING DEPT.	

REVISION #	10/22/2003					
HUNTER 306 DECK HARDWARE						
	GEN.DESCR.	LOC. & TYPE	VENDOR	MDL/NAME/#	#REQ.	PART #
1	HATCH	FWD CABIN TOP	LEWMAR	SIZE 60	1	300950
	SCREEN	SCREEN	LEWMAR		1	300954
	TRIM RING	TRIM RING	LEWMAR?	IVORY	1	300670
2	HATCH	MAIN CABIN TOP	LEWMAR	OCEAN SIZE 10	2	300210
	SCREEN	SCREEN	LEWMAR		2	300220
	TRIM RING	TRIM RING	LEWMAR	IVORY	2	300230
3	HATCH	CABIN SIDE	LEWMAR	TRIMPORT 03	2	300180
	TRIM RING	CABIN SIDE	HUNTER	IVORY	2	300200
4	HATCH	CABIN SIDE	LEWMAR	SIZE 41	2	300180
	SCREEN	CABIN SIDE	LEWMAR		2	300190
	TRIM RING	CABIN SIDE	HUNTER	IVORY	2	300200
5	PORTLIGHT	PORT COCKPIT SIDE		WHITE 4x10	1	300390
	SCREEN			4x10	1	300410
6	FIXED HULL WINDOW	HULL SIDES	PLEX H310/340		2	422060
	TRIM RING	HULL WINDOWS	VACU-FORM	BEIGE	2	300310
7	BOW EYE	STEM		7/16" U-BOLT	1	318010
8	BOW STRAP	HEADSTAY FITTING		ST STL TO PRINT	1	305620
9	BOW ROLLER	STEM			1	304220
10	FURLING UNIT	HEADSTAY	FURLEX	106-12 W/RIG SCR	1	401265
11	BOW RAIL				1	307480
12	BOW LIGHT	ON BOW PULPIT		62246B	1	255806
13	ANCHOR HATCH	NEW	HUNTER		1	
	ANCHOR LATCH (HANDLE)	ANCHOR WELL	HUNTER		1	315700
	STRIKER PLATE	ANCHOR WELL	HUNTER		1	306120
	HINGE	ANCHOR WELL		3"x1.5" SS POLISH	2	314900
	EYE STRAP	ANCHOR WELL		1242-000 CHROME	2	315590
	BUNGEE CORD	ANCHOR WELL		20" 650240-1	1	318530
14	MAST STEP	H310			1	403096
15A	VANG BLOCK					
15B	VANG BLOCK					
16	STBD CABIN SIDE PLEXI	CABIN SIDE FWD				
17	PORT SIDE PLEXI	CABIN SIDE FWD				
18	WINCH	CABIN TOP AFT	LEWMAR	16 CST	2	308590
19A	SHEET STOPPER	CABIN TOP PT AFT	SPINLOCK	XA3	1	304000
19B	SHEET STOPPER	CABIN TOP STBD AFT	SPINLOCK	XA2	1	304000
20	CLEAT	FWD MOORING		ALUM 8" 4-HOLE	3	P2820
21	CLEAT	MIDSHIPS SPRING		ALUM 8" 4-HOLE	2	P2820
22	CLEAT	AFT MOORING		ALUM 8" 4-HOLE	2	P2820
23	CLEAT (FURL)	COCKPIT COAMING	SCHAEFER	5" ALUMNIUM	1	303360
24	JIB TRACK	CABIN TOP	SCHAEFER	1"16"	2	301950
25	JIB CARS	JIB TRACK	SCHAEFER	#32-88	2	302900
26	JIB TRACK ENDS		SCHAEFER	#74-35-G	4	302890
27	DK. ORGANIZER (TRIPLE)	CABIN TOP		505-81	2	303490
28	CHEEK BLOCK (JIB SHEET)	CABIN TOP AFT CORNERS	SPINLOCK	JK/50X	2	303500
29	LIFE LINES					
30	STANCHION W/ BASE	ON TOERAIL	HUNTER	C/O 310	4	305140
32	CHAIN PLATE	ON HULL AMIDSHIPS			1	SET
33	FILL PLATE	DIESEL		PL1126	1	356181
34	FILL PLATE	WATER		PL1130	1	356199
35	FILL PLATE	WASTE		PL1140	1	356217
36	STEERING CONSOLE	IN COCKPIT	HUNTER		1	
37	WHEEL	ON CONSOLE	WITLOCK	32"	1	310825
38	STEERING SYSTEM	IN COCKPIT	WITLOCK			
	"		CONNECT ROD			
39	SHIFT CONTROL					
40	QUAD COVER					
	EMERG.TILL ACCESS	IN QUAD COVER		DP40-W	1	300520
41	GRABRAIL, AFT CONSOLE					
42	GRAB HANDLE, CONSOLE				1	307130
43	COCKPIT TABLE					
44	TABLE DRINK HOLDER	COCKPIT TABLE		C/O 310 ?		
45	STARBOARD	COCKPIT TABLE		C/O 310 ?		
46	ANCHORWELL U-BOLT	ANCHOR WELL			1	318030



This document contains information for which HUNTER MARINE CORP. has proprietary rights.

HUNTER

H306 INTERIOR LAYOUT

REVISED NO.	2868041A	REVISION NO.	NONE
DATE	3/18/99	DATE	
ENGINEERING DEPT.			

TABLE INSTRUCTIONS

TO LOWER THE TABLE:


1. LIFT UP ON THE TABLE TO RELIEVE PRESSURE ON THE QUICK PIN SUPPORTING THE TABLE BRACKET.
2. CONTINUE SUPPORTING THE TABLE AND REMOVE THE QUICK PIN BY TURNING IT IN A CLOCKWISE MOTION 1/2 TURN AND PULL STRAIGHT OUT. (STORE THE QUICK PIN IN THE KEEPER PROVIDED)
3. SLOWLY LOWER THE TABLE UNTIL IT COMES TO REST ON THE DINETTE SETTEE TOP.

TO RAISE THE TABLE:

1. RAISE THE TABLE AND BRACKET UP PAST THE PROVIDED HOLE IN THE COMPRESSION POST
2. CONTINUE SUPPORTING THE TABLE AND REPLACE THE QUICK PIN THRU THIS HOLE. ENSURE THE QUICK PIN IS LOCKED IN PLACE USING THE "SAFETY" SLOTS PROVIDED ON THE QUICK PIN.
3. SLOWLY LOWER THE TABLE UNTIL THE BRACKET COMES TO REST ON THE QUICK PIN.
4. ROTATE THE TABLE BACK AND FORTH UNTIL IT "DROPS" INTO PLACE. THIS HAPPENS WHEN THE ENGAGED QUICK PIN AND THE SLOT ON THE TABLE BRACKET SLEEVE LINE UP AND LOCK INTO PLACE.

①

THE DINETTE TABLE SHOULD BE SUPPORTED AT BOTH ENDS SIMULTANEOUSLY, WHEN EITHER RAISING OR LOWERING. DUE TO THE WEIGHT OF THE TABLE, TWO OR MORE PEOPLE ARE REQUIRED TO SAFELY COMPLETE THIS JOB.



FILLER CUSHIONS TO
CONVERT TABLE TO BERTH
PROVIDED WITH THE BOAT.



This document describes information for which HUNTER MARINE CORP. has proprietary rights.

HUNTER





H306 DINETTE TABLE OPERATION

DRAWING NO.	3068041B	REVISION NO.	NONE
DATE	6/8/99	ENGINEERING DEPT.	

NOTE: TO AVOID DAMAGING THE RUBRAIL WHEN LIFTING THE BOAT, A 14" X 4" X 4" WOOD STRAP SHOULD BE PLACED IN BETWEEN THE LIFTING STRAP AND THE HULL. JUST BELOW THE RUBRAIL



SELDEN STANDARD



NOTE:

SEE PAGE 42B-1 & 2 FOR VANG DETAILS





ALL BLOCKS RUTGERSON SERIES 500 W/ SPRINGS

ISSUE FILE:
306 RUN. RIG & MAST STEP DETAIL (STD)
DRAWING NO. 3068042A-1 DESIGNER NO. NONE
ENGINEERING DEPT. DATE 5/10/99

HUNTER

This document describes information for which HUNTER MARINE CORP. has proprietary rights.

SELDEN FURLING



NOTE:


ALL BLOCKS RUTGERSON SERIES 500 W/ SPRINGS
JIB HALYARD IS LOCKED OFF @ PORT
SIDE SHEET STOPPER. (FURLING MASTS)

WORKING FILE:
H306RUM RIG & MAST STEP DETAIL (FURLING)

DRAWING NO.	3068042A-2	DESIGNER NO.	NONE
ENGINEERING DEPT.		DATE	4/13/99

This document describes information for which HUNTER MARINE CORP. has proprietary rights.






1. FROM COIL THRU LOWER JAM CLEAT
2. FROM LOWER VANG TOGGLE SHEAVE UP AROUND UPPER BOOM SHEAVE AS SHOWN
3. FROM UPPER BOOM SHEAVE DOWN(OUTSIDE) AROUND LOWER VANG TOGGLE SHEAVE AS SHOWN (OUTSIDE)
4. FROM LOWER VANG TOGGLE SHEAVE UP AROUND UPPER BOOM SHEAVE AS SHOWN (INSIDE)
5. FROM UPPER BOOM SHEAVE DOWN TO LOWER VANG TOGGLE SHEAVE BECKET AS SHOWN (INSIDE)

This document contains information for which HUNTER MARINE CORP. has proprietary rights.

HUNTER

H306 ROPE VANG DETAILS (STANDARD)	
REVISED NO.	3068042B-1
EXTENSION NO.	NONE
DATE	4/16/99
ENGINEERING DEPT.	



MAST

BOOM



- ① BOOM VANG BALE
- ② VANG
- ③ VANG CABLE
- ④ UPPER VANG BLOCK, SCHAEFFER 03-13
- ⑤ VANG LINE 5/16" X 45" (7.9mm x 13.7m)
- ⑥ LOWER VANG BLOCK, SCHAEFFER 03-13
- ⑦ VANG TOGGLE

PLEASE NOTE:
H306 RIGID VANG DETAILS (FURLING OPTION)
 DRAWING NO. 3068042B-2
 NONE
 DATE 11/03/99
 ENGINEERING DEPT.

HUNTER

This document contains information for which HUNTER MARINE CORP. has proprietary rights.

JIB FURLING SYSTEM



SEE FURLING MANUAL FOR LINE ATTACHMENT TO DRUM

FWD. TO FURLING DRUMS (1) (THRU BLOCKS ON STANCHIONS)

JIB FURLING LINE

AFT TO JIB FURLING CLEAT ON COCKPIT COAMING

TYPICAL FURLING BLOCK/ STANCHION DETAIL

BLOCK
STANCHION
JIB FURLING LINE STANCHION AFT THRU NEXT CLEAT TO JIB FURLING CLEAT
JIB FURLING LINE DRUM
FWD TO FURLING DRUM

DRAWING TITLE: **H306 JIB FURLING LINES LAYOUT**
 DRAWING NO.: 3068042C
 REVISION NO.: NONE
 DATE: 4/14/99
 ENGINEERING DEPT.

This document describes information for which HUNTER MARINE CORP. has proprietary rights.

HUNTER


ARCH INSTALLATION: NOTES AND TOOL LIST

NOTES:

1. **IMPORTANT: COMPLETELY READ ALL OF THE INSTALLATION INSTRUCTIONS BEFORE BEGINNING.**
2. **THIS JOB REQUIRES THREE PEOPLE. IT IS IMPORTANT THAT THE ARCH CONTINUE BEING SUPPORTED ONCE IT HAS BEEN SET IN PLACE, UNTIL BEING FULLY SECURED TO THE DECK.**
3. **WHEN INSTALLING ARCH: TO AVOID POSSIBLE INJURY, ORIENT THE DIRECTION OF THE ARCH (LEANING FORWARD) PRIOR TO BEGINNING THE INSTALLATION PROCESS.**
4. **SEE BELOW FOR A LIST OF TOOLS SUGGESTED FOR THE INSTALLATION PROCESS**
5. **IMPORTANT: REMEMBER TO CHECK ALL THE ARCH BOLTS / NUTS AFTER THE INITIAL SEA TRIAL AND RETIGHTEN AS NECESSARY**


SUGGESTED TOOL LIST:

- 3/8" DRIVE RATCHET
- 6" EXTENSION
- 9/16" DEEP & REGULAR SOCKET
- 9/16" WRENCH
- SCREW DRIVER--PHILLIPS HEAD
- RATCHET STRAP
- CAULK GUN
- TUBE OF SEALANT (3M 5200)
- NEVER SEIZE (BOLT LUBE)
- RAZOR KNIFE
- RAGS
- ALCOHOL / CLEAN UP



1. REMOVE ALL ACCESSORIES STOWED IN THE COCKPIT LOCKERS. THIS WILL ALLOW EASIER ACCESS TO FASTEN THE ARCH BOLTS.
2. REMOVE ANY SEALANT IN THE ARCH PRE DRILLED HOLES.
3. CLEAN AROUND THE MOUNTING HOLES USING ALCOHOL.
4. APPLY A GENEROUS AMOUNT OF 3M 5200 SEALANT AT THE ARCH MOUNTING FOOT DECK MOUNTING HOLE LOCATIONS.
5. TO AVOID POSSIBLE INJURY, ORIENT THE ARCH (LEANING FORWARD) PRIOR TO PLACING IT ON THE BOAT.
6. PLACE THE ARCH ON THE DECK OF THE BOAT. ALIGN THE FORWARD MOST ARCH FOOT HOLE WITH THE MATCHING PRE DRILLED FWD MOST DECK COAMING HOLE.
7. INSERT A (2.0"(50.8mm)) STAINLESS STEEL BOLT THRU THE FWD MOST ARCH FOOT INTO THE COAMING.
8. ACCESS THE UNDERSIDES OF THE DECK AT THE ARCH FOOT LOCATIONS AS FOLLOWS:
 PORT FWD: THRU ACCESS PANEL IN THE PT. SIDE AFT STATEROOM HEADLINER.
 PORT AFT: THRU PORT SIDE GULLWING LOCKER
 STBD FWD: THRU STBD. SIDE EURO LOCKER
 STBD. AFT: THRU PORT SIDE GULLWING LOCKER
9. INSTALL THE (1/4" (6.4mm)) BACKING PLATE ON THE INSIDE OF THE COAMING. THEN INSTALL THE S.S. WASHER, LOCK WASHER AND THE S.S. NUT AS WELL. (NOTE: THERE EXISTS CASES WHERE A BACKING PLATE IS NOT ABLE TO BE INSTALLED. IF THIS IS ENCOUNTERED, USE (1/4" 6.4mm)) S.S. FENDER WASHERS INSTEAD. (IT IS IMPORTANT TO APPLY A SMALL AMOUNT OF NEVER SEIZE TO THE BOLT TO PREVENT "GAULING" OF THE THREADS.)
10. COMPLETELY TIGHTEN THE FORWARD MOST BOLT.
11. REPEAT THIS PROCEDURE FOR THE REMAINING THREE FEET. INSERTING ONLY ONE BOLT AT FIRST AND COMPLETELY TIGHTENING IT DOWN STARTING WITH THE ARCH FOOT DIRECTLY ACROSS FROM THE BOLT ALREADY INSTALLED. REPEAT THIS FOR THE NEXT TWO.
12. NOTE: IT MAY BE NECESSARY TO USE A RATCHET STRAP TO "PULL" THE ARCH INTO ALIGNMENT WITH THE REMAINING MOUNTING HOLES.
13. INSERT THE REST OF THE S.S. FASTENERS INTO THE MOUNTING HOLES. INSTALL ALL THE S.S. BACKING PLATES, WASHERS AND NUTS FROM THE UNDERSIDE OF THE DECK. (AT THIS TIME, BE SURE TO INSTALL THE ARCH GROUNDING WIRE, LOCATED IN THE HEADLINER ACCESS PANEL. SEE DIAGRAM FOR INSTALLATION DETAILS.)
14. RECHECK THE ARCH FIT ONTO THE DECK.
15. SECURELY TIGHTEN ALL THE NUTS AND BOLTS USING A CROSS TIGHTENING PATTERN. (DO NOT FORGET TO USE A SMALL AMOUNT OF LUBRICANT FOR THE BOLTS).
16. CLEAN OFF THE EXCESS SEALANT AROUND THE ARCH FEET AND COAMING AREAS USING ALCOHOL.
17. RECHECK THE BOLTS AFTER THE INITIAL SEA TRIAL AND TIGHTEN AS NECESSARY.

TYPICAL ARCH FOOT




H3306 ARCH INSTALLATION INSTRUCTIONS CONT

FORMING FILE:	DESIGN NO.:	NONE
DATE:	DATE:	6/8/99
ENGINEERING DEPT.:		

This document contains information for which HUNTER WARE CORP. has proprietary rights.





END BOOM
MAINSHEET BLOCK
(BOOM NOT SHOWN
FOR CLARITY)
HARKEN #001


MAINSHEET
HALYARD, FROM
MAST STEP. (SEE
PAGE 42 & 43B
FOR FURTHER
DETAILS)

PORT MAINSHEET
BLOCK HARKEN #011
(MOUNTED TO ARCH
PORT SIDE)

MAINSHEET PURCHASE
(ARCH NOT SHOWN FOR CLARITY)


STBD MAINSHEET
BLOCK HARKEN #011
(MOUNTED TO ARCH
STBD SIDE)

BOOM
BALE



SEE PG 43C FOR DETAILS

SEE PAGE 43A FOR
MAIN SHEET LINE RUNS




THIS DOCUMENT CONTAINS INFORMATION FOR WHICH HUNTER MARINE CORP. HAS PROPRIETARY RIGHTS.

HUNTER

DRAWING TITLE: H306 OPT. TRAV. CONTROL LINE DETAILS	
DRAWING NO. 3068043B-2	REVISION NO. NONE
ENGINEERING DEPT.	DATE: 6/19/99.

NOTE: ARCH & TRAVELER BAR NOT SHOWN FOR CLARITY.
 STARBOARD SIDE SHOWN, PORT SIDE IS MIRROR IMAGE
 SEE PREVIOUS PAGE FOR MORE DETAILS




- ① SECURE END OF CONTROL LINE TO BECKET ON CONTROL BLOCK
- ② LEAD LINE AROUND FWD. SIDE OF AFT TRAVELER CAR SHEAVE AS SHOWN
- ③ LEAD LINE FROM AFT SIDE OF AFT TRAVELER CAR SHEAVE TO AFT SIDE OF CONTROL BLOCK SHEAVE
- ④ LEAD LINE FROM FWD. SIDE OF CONTROL BLOCK SHEAVE TO AFT SIDE OF FWD. TRAVELER CAR SHEAVE
- ⑤ LEAD LINE FROM FWD. SIDE OF FWD. TRAVELER CAR SHEAVE TO STAND UP SHEAVE
- ⑥ LEAD LINE AROUND STAND UP SHEAVE THEN DOWN THRU ARCH AND AROUND LOWER SHEAVE TO CAM CLEAT

HUNTER
 H306 OPTIONAL TRAVELER LAYOUT

DESIGN NO. 3068043C
 DATE 6/6/99
 ENGINEERING DEPT.

This document describes information for which HUNTER MARINE CORP. has proprietary rights.





1. BOOM BALE (MANSHEET PURCHASE END TIE OFF)
2. ARCH BRIDLE / (OPT TRAVELER CAR SHEAVE)
3. BOOM BALE AND MANSHEET BLOCK
4. MANSHEET PURCHASE
5. MANSHEET EXIT
6. MANSHEET RUN INSIDE BOOM
7. MANSHEET SHEAVE INSIDE FWD BOOM END
8. MANSHEET BLOCK AT MAST STEP (SEE PG 42A-1)
9. MANSHEET RUN AFT TO COCKPIT



This document contains information for which HUNTER MARINE CORP. has proprietary rights.

BOOM TOPPING LIFT CONNECTS
TO BOOM USING A 1/4" (6.4mm)
D-SHACKLE.


REEF TACK CLEW
(1ST REEF)

REEF #2 (RUNS THE SAME AS REEF #1)

REEF #1

OUTHHAUL

1ST REEF LINE
TO DECK ORGANIZER
(SEE PAGE 42A-1)



This document describes information for which HUNTER MARINE CORP. has proprietary rights.




H306BOOM AND REEF LAYOUT			
PROJECT FILE	3068044A	REVISION NO.	NONE
DATE	4/14/99	DESIGNED BY	ENGINEERING DEPT.

h306

1. LAZYJACK WIRE ATTACHMENT @ UPPER SPREADER
2. LAZYJACK UPPER FIXED CABLE
3. RING OR BLOCK ON FIXED CABLE
4. 5/16" (7.9mm) LAZYJACK LINE (THRU THIMBLE / BLOCK).
5. AFT BOOM BAIL (SECURE L.J. LINE END)
6. LAZYJACK CLEAT ON BOOM (SECURE FWD L.J. LINE TO CLEAT)

NOTE: BE AWARE THAT THE LAZYJACK LINES PASS THRU THE GROMMETS PROVIDED ON THE SAIL COVER COVER WHEN INSTALLING THE LAZYJACK SYSTEM. SEE PG 44B FOR INFO.



FIXED WIRE @
SPREADER.

5/16" (7.9mm)
LAZYJACK LINE

This document describes information for which HUNTER MARINE CORP. has proprietary rights.

HUNTER

H306 LAZYJACK INSTALLATION INSTRUCTIONS


SCALE	NONE
DRAWING NO.	3068044B
DATE	6/9/99
ENGINEERING DEPT	

SLIDE THE BOLTROPE ON THE TWO HALVES OF THE COVER INTO THE BOLTROPE TRACKS (1) ON BOTH SIDES OF THE BOOM. START FROM THE AFT END AND MAKE YOUR WAY FORWARD.

INSTALL THE PVC BATTENS (2) INTO EACH HALF OF THE SAIL COVER. THERE ARE POCKETS (3) THAT OPEN TOWARDS THE FRONT, ON THE INSIDE OF THE COVER. SLIDE THE BATTENS INTO PLACE FROM THE FRONT, AND ROLL THE INSIDE LIP OF THE POCKET BACK IN ORDER TO HOLD THE BATTENS STATIONARY.

FEED THE LAZYJACK LINES (4) DOWN THROUGH THE GROMMETS/RINGS (5) IN THE SAIL COVER, STARTING AT THE TOP AND COMING OUT AT THE BOTTOM OF THE COVER. DEAD END THE LINES TO THE BAILS ON THE UNDERSIDE OF THE BOOM (6).

TIE THE AFT END OF THE SAIL COVER UP TO THE TOPPING LIFT LINE USING THE PIECE OF STRING PROVIDED (7). USE HALF HITCH KNOTS TO SECURE THE COVER IN PLACE AT THE OUTER END OF THE BOOM. THE REEF LINES RUN OUT THROUGH THE COVER SLOTS (8) AND TIE OFF.



SAIL COVER ONLY OFFERED ON STANDARD MAST BOATS

REVISED FILE: H306 HUNTER LAZYJACK SAIL COVER

DRAWING NO.	3068044C	SCALE	NONE
ENGINEERING DEPT		DATE	5/25/99

This document describes information for which HUNTER MARINE CORP. has proprietary rights.



REEFING INSTRUCTIONS

1. SHACKLE TACK REEF BLOCKS TO FIRST AND SECOND REEF TACK CRINGLES.
2. RUN BOTH REEFING LINES AS ILLUSTRATED IN THE BOOM & REEF LAYOUT. BOTH PORTIONS OF THE REEFING LINE LEADING TO THE REEF TACK BLOCK MUST RUN THROUGH THE GOOSE NECK ON THE AFT OF THE SPAR. THE SHORTER REEF LINE WILL BE USED ON THE FIRST REEF (STARBOARD SIDE, GREEN) THE LONGER REEF LINE ON THE SECOND REEF (PORT SIDE, RED.)
3. RAISE THE MAIN SAIL.
4. EASE THE MAINSHEET AND VANG.
5. LOWER THE MAIN SAIL TO APPROXIMATELY THE FIRST REEF POSITION.
6. TAKE UP THE SLACK IN THE FIRST REEF LINE UNTIL THE TACK AND THE CLEW ARE DOWN TO ABOUT 2" ABOVE THE BOOM.
7. ADJUST THE MAIN HALYARD SO THAT THE TACK REEF BLOCK IS NOT CONTACTING THE GOOSE NECK ON THE FRONT OF THE SPAR AND IS APPLYING TENSION TO THE LUFF OF THE MAIN ABOVE THE REEF, NOT BELOW. THERE WILL BE AP-

PROXIMATELY 6" (150mm) OF STRECH IN THE MAIN LUFF AND MAIN HALYARD WHEN THE REEFING LINE IS TENSIONED, SO MAKE SURE THAT THIS IS ALLOWED FOR WHEN ADJUSTING THE MAIN HALYARD TO LOCATE THE TACK REEF BLOCK.

8. ALSO, TENSION THE REEF LINE WITH THE APPROPRIATE SELF-TAILING WINCH UNTIL THE CLEW REEF CRINGLE IS BROUGHT DOWN TO THE BOOM.
9. CONFIRM THAT THE TACK REEF BLOCK IS STILL CLEAR OF THE TACK SHACKLE AND THAT ONLY THE MAIN LUFF ABOVE THE REEF CRINGLE IS TENSIONED; NOT THE LUFF BETWEEN THE CRINGLE AND THE TOP STACKED SAIL SLIDE. EASE THE REEF LINE AND READJUST THE HALYARD IF NECESSARY.
10. MARK THE HALYARD AT THE STOPPER WITH A 1" (25mm) SINGLE BAND OF INDELIBLE MARKER INK. BY DROPPING THE HALYARD TO THIS MARK EVERY TIME A REEF IS REQUIRED THE HALYARD IS AUTOMATICALLY IN THE CORRECT POSITION FOR THE REEF.
11. REPEAT THE PROCEDURE FOR THE SECOND REEF, USING DOUBLE BANDS TO MARK THE HALYARD IN THE CORRECT POSITION.

REEFING PROCEDURE

1. HEAD UP INTO THE WIND.
2. EASE THE MAINSHEET AND VANG.
3. CHECK THE TOPPING LIFT FOR ADEQUATE BOOM SUP-PORT.

SHAKING OUT A REEF

1. HEAD UP INTO THE WIND.
2. EASE THE MAINSHEET AND VANG. TENSION TO TOPPING LIFT. (IF NEEDED)
3. RELEASE THE REEF STOPPER AND REMOVE REEF LINE FROM WINCH.

4. LOWER THE MAIN HALYARD TO THE APPROPRIATE MARK, AND SNUB THE LINE WITH THE STOPPER.
5. TENSION THE REEFING LINE WITH THE SELF-TAILING WINCH UNTIL THE REEF CLEW IS BROUGHT DOWN TO THE BOOM. APPLY STOPPER AND TENSION THE MAIN HALYARD BACK UP. EASE THE TOPPING LIFT. (IF NEEDED)

4. TENSION THE MAIN HALYARD TO RAISE SAIL, MAKING SURE REEF LINES RUN FREELY WHILE SAIL IS BEING RAISED. APPLY STOPPER TO MAIN HALYARD.
5. RE-TENSION VANG AND MAINSHEET. EASE THE TOPPING LIFT. (IF NEEDED)

h306 SELDEN STANDARD MAST RUNNING RIGGING SPECIFICATIONS

BOAT: H306 REVISION: ADD 4' TO MAIN HALY, SHORTEN REEFS 10' KJC 7/14/99
 BY: KJC DATE: 5/12/1999 ADD VANG LINE 8/700 KJC

OPT/STD	ITEM	QUANTITY	LINE SIZE	LINE TYPE	COLOR	END 1	LENGTH	END 2
1 STD	JIB HALYARD	1	3/8" (9.5mm)	XLS	RED	EYE	23.7 m 78 ft	BARE
2 OPT	MAIN TRAVELER LINE	2	5/16" (8mm)	LS	WHITE	SMALL EYE	7.9 m 26 ft	BARE
3 STD	MAINSHEET	1	3/8" (9.5mm)	LS	BLUE FLECK	SMALL EYE	14.8 m 49 ft	BARE
4 STD	JIB SHEET	2	7/16" (11mm)	LS	RED FLECK	BARE	10.1 m 33 ft	BARE
5 STD	REEF LINE 1	1	3/8" (9.5mm)	LS	GREEN FLECK	BARE	14.6 m 48 ft	BARE
6 STD	REEF LINE 2	1	3/8" (9.5mm)	LS	RED FLECK	BARE	21.9 m 72 ft	BARE
7 OPT	SPINN. SHEET	2	3/8" (9.5mm)	LS	BLACK FLECK	BARE	20.1 m 66 ft	BARE
8 STD	LAZY JACK WIRE	2	5/32" (4mm)	1x19 PLASTIC COATED	WHITE	NICO PRESSED EYE W/ 1/4" D-SHACKLE	2.1 m 7 ft	EYE AND LARGE OVAL THIMBLE
9 STD	LAZY JACK ROPE	2	5/16" (8mm)	LS	WHITE	BARE	6.4 m 21 ft	BARE
10 STD	VANG	1	5/16" (8mm)	LS	WHITE	BARE	13.7 m 45 ft	BARE
11 OPT	SPINNAKER HALYARD	1	3/8" (9.5mm)	XLS	BLACK	SNAP SHACKLE NF11000s	23.7 m 78 ft	BARE
12 STD	MAIN HALYARD	1	3/8" (9.5mm)	XLS	BLUE	HEADBOARD SHACKLE	24.5 m 80 ft	BARE
13 STD	BOOM TOPPING LIFT	1	5/16" (8mm)	LS	WHITE	1/4" D-SHACKLE	19.6 m 64 ft	BARE

h306 SELDEN FURLING MAST RUNNING RIGGING SPECIFICATIONS

BOAT: h306
 BY: KJC
 CHECKED BY:

REVISION: ADDED VANG LINE 8/7/00 KJC

DATE: 5/12/1999

OPT/STD	ITEM	QUANTITY	LINE SIZE	LINE TYPE	COLOR	END 1	LENGTH	END 2
1 STD	JIB HALYARD	1	3/8" (9.5mm)	XLS	RED	EYE	23.7 m 78 ft	BARE
2 OPT	MAIN TRAVELER LINE	2	5/16" (8mm)	LS	WHITE	SMALL EYE	7.9 m 26 ft	BARE
3 STD	MAINSHEET	1	3/8" (9.5mm)	LS	BLUE FLECK	SMALL EYE	14.8 m 49 ft	BARE
4 STD	JIB SHEET	2	7/16" (11mm)	LS	RED FLECK	BARE	10.1 m 33 ft	BARE
5 STD	VANG	1	5/16" (8mm)	LS	WHITE	BARE	13.7 m 45 ft	BARE
6 OPT	SPINN. SHEET	2	3/8" (9.5mm)	LS	BLACK FLECK	BARE	20.1 m 66 ft	BARE
7 OPT	SPINNAKER HALYARD	1	3/8" (9.5mm)	XLS	BLACK	SNAP SHACKLE NF11000s	23.7 m 78 ft	BARE
8 STD	MAIN FURLING LINE	1	3/8" (9.5mm)	LS	BLUE	BARE	9.1 m 30 ft	BARE
9 STD	BOOM TOPPING LIFT	1	1/4" (6.4mm)	LS	WHITE	1/4" D-SHACKLE	21.9 m 72 ft	BARE

H306 B&R RIG DESCRIPTION

The B&R rig, utilized on the Hunter H306, eliminates the need for a backstay to allow for a more efficient mainsail shape. Fixed backstays are commonly being designed out of today's performance-oriented boats to allow the mainsail to incorporate a full roach design - a more aerodynamic shape both for racing and cruising performance.

To accomplish this, the B&R rig has 30 degree swept spreaders, creating 120 degrees between each rigging point. This tri-pod arrangement has excellent strength for sailboat rigs, and has been used for years to support huge radio towers.


Additional support is given to the B&R rig (and is unique to it) with the addition of reverse diagonal rigging. For example, the diagonals that you see beginning near the gooseneck and ending at the tip of the spreader, supports and stabilizes the lower section of the mast as it creates a triangle with the lower shroud. The top RD2 runs from above the lower spreader base to the end of the top spreader, and stabilizes the top section of the mast.

The B&R rig is designed to be pre-bent to further add rigidity to the mast section and eliminate the need for adjustable rigging (like backstay adjusters). This design should prove more reliable than a rig with adjustable backstays or runners, as there is less chance for error.

The large main, small jib, sail plan on the H306 also eliminates the need for large overlapping headsails (genoas), as the driving power comes from the much improved shape and size of the mainsail. This allows for an easier tacking small jib, creating good performance and more comfortable sailing, as it is less work for the crew.


As the large main is creating additional mainsheet and leech loading, Hunter has included a cockpit arch whereby the mainsheet and leech loads are directed to the strong part of the boom (the outboard end) and is located at the heaviest loading point of the mainsail. The cockpit arch serves addition safety and comfort functions as handholds and cockpit canvas attachment points.


B&R rigs have been used on thousands of sailboats, and we are proud to incorporate this successful design on your new Hunter.



- ① FORESTAY 1/4" (6.4mm) 1 X 19
- ② D2 1/4" (6.4mm) 1 X 19
- ③ SPREADERS (SEE PAGES 49B & C)
- ④ D1 1/4" (6.4mm) 1 X 19
- ⑤ V1 1/4" (6.4mm) 1 X 19
- ⑥ RDI 3/16" (4.75mm) 1 X 19

NOTE: SEE PAGES 49A & B FOR SPREADER TIP DETAILS.
 SEE PAGE 50A & B FOR RIG LENGTHS.
 SEE PAGE 51 FOR FITTINGS DESC.






A	D2 stem T	G	jaw toggle
B	jaw toggle	H	V1
C	link plates	I	link plates
D	V2	J	jaw toggle
E	marine eye	K	RD1 stem T
F	spreader tip casting		

SELDEN LOWER SPREADER TIP

DRAWING TITLE	SELDEN LOWER SPREADER TIP
REVISION NO.	NONE
DATE	7/13/01
DRAWING NO.	30765049A
COMPILED BY	MG



DRAWING TITLE: SELDEN UPPER SPREADER TIP
 DRAWING NO.: 30766049B
 COMPANY: HUNTER




THIS DOCUMENT DISCLOSES INFORMATION FOR WHICH HUNTER MARINE CORP. HAS PROPRIETARY RIGHTS.
 NONE
 6/13/01
 DATE
 ENG

- | | |
|---|--|
| <p>A D3 marine eye</p> <p>B jaw toggle</p> <p>C 1/2" (1.27cm) pin</p> <p>D spreader tip casting</p> | <p>E 3/8" (.95cm) pin</p> <p>F link plates</p> <p>G marine eye stem</p> <p>H spreader tip casting fastener</p> |
|---|--|

H306 CHAINPLATE DETAIL

REVISED NO.	3068049C	REVISION NO.	NONE
DATE		DATE	6/10/99
ENGINEERING DEPT.			




- 1. *DIAGONAL SHROUD SWAGE END*
- 2. *VERTICAL SHROUD SWAGE END*
- 3. *SPLIT RING(S) ON ALL SHROUD ENDS*
- 4. *DIAGONAL SHROUD TURNBUCKLE BODY*
- 5. *VERTICAL SHROUD TURNBUCKLE BODY*
- 6. *THREADED TOGGLE JAW(S)*
- 7. *CLEVIS PIN(S)*
- 8. *STAINLESS STEEL CHAINPLATE*
- 9. *RUB RAIL*

h306 SELDEN STANDARD STANDING RIGGING SPECIFICATIONS							
BY: KJC		DATE: 25-Jun-03		REVISION: SHORTEN RD1 FROM 11' 11 3/4" TO 11' 3 1/2" 3/14/00			
OPT/STD	ITEM	QUANTITY	WIRE SIZE	UPPER END	LENGTH	LOWER END	
1	STD D2	2	1/4" (6 mm)	T TERMINAL 308-324	4.790 m	15 ft. 8-1/2in.	MARINE EYE 308-314
2	STD V1	2	1/4" (6 mm)	FORK 308-314	4.730 m	15 ft. 6-1/4in.	STANDARD TOGGLE TURNBUCKLE 3/8"
3	STD D1	2	1/4" (6 mm)	T TERMINAL 308-324	4.705 m	15 ft. 5-1/4in.	STANDARD TOGGLE TURNBUCKLE 3/8"
4	STD LOWER DIAMOND, RD1	2	5/32" (4 mm)	FORK 308-312	3.785 m	12 ft. 5in.	STANDARD T TURNBUCKLE 174-014
5	STD FORESTAY	1	1/4" (6 mm)	MARINE EYE 308-314	9.959 m	32 ft. 8in.	FURLEX DRUM106-12

HEADSTAY SUPPLIED BY JIB FURLING SYSTEM PROVIDER


h306 SELDEN FURLING STANDING RIGGING SPECIFICATIONS						
BY: KJC		DATE: 25-Jun-03		REVISION:		
OPT/STD	ITEM	QUANTITY	WIRE SIZE	UPPER END	LENGTH	LOWER END
1	STD D2	2	1/4" (6 mm)	T TERMINAL 308-324	4.09m 13 ft. 5in.	MARINE EYE 308-362
2	STD V1	2	1/4" (6 mm)	FORK 308-314	5.48m 18 ft.	STANDARD TOGGLE TURNBUCKLE 3/8"
3	STD D1	2	1/4" (6 mm)	T TERMINAL 308-324	5.36m 17 ft. 7in.	STANDARD TOGGLE TURNBUCKLE 3/8"
4	STD LOWER DIAMOND, RD1	2	5/32" (4 mm)	FORK 308-312	4.44m 14 ft. 7in.	STANDARD T TURNBUCKLE 174-014
5	STD FORESTAY	1	1/4" (6 mm)	MARINE EYE 308-314	9.94m 32 ft. 7-1/2in.	FURLEX DRUM106-12

FORESTAY SUPPLIED BY JIB FURLING SYSTEM PROVIDER



V = VERTICAL
 D = DIAGONAL
 RD = REVERSE DIAGONAL

NOTE: SEE PAGES 50A & 50B FOR ACTUAL RIG LENGTHS.



TUNING THE 306 B&R RIG

The easiest method for tuning the B&R rig is to perform step one as follows before the mast is stepped, with it lying aft side up on two sawhorses (one at each end). Begin with all rigging slack. If the mast is already stepped, loosen all the rigging, and then proceed to step one.


1. Start with all the rigging slack. Then induce the mast bend by tightening the reverse diagonals (diamonds). Measure the bend by tensioning a line or the main halyard between the masthead and the gooseneck. The maximum amount of bend should be no more than 6" (152 mm) for the standard rig and no more than 2" (50 mm) for the furling mast measured perpendicular from the aft face of the mast to the halyard at the deepest part of the bend. It can be less than that based on the sail shape and your own preference. The bend should also be evenly distributed along the mast to give a smooth shape. Keep in mind that bending a furling mast may make it more difficult to furl and will not do much to flatten the sail as in a standard rig. It is very important that the mast also be straight from side to side at this time. Tighten or loosen the diagonals or the reverse diagonals to achieve this.
2. Step the mast with all shrouds attached but with the turnbuckles completely loosened (if the mast was not already stepped).
3. Attach the jib halyard to a cleat on the bow to support the mast in a raked position (the masthead should be about 2-1/2' behind the step). Attach the verticals and tighten them until you can just see the hole for the cotter pin in the turnbuckle. Tighten the jib halyard until you can attach the forestay. At this point the masthead should be raked so that a weight hung on the main halyard hangs about 1' behind the mast step.
4. Use the main halyard to check that the mast is centered from side to side. Pull it tight and mark the halyard next to the verticals chainplate. Now do the same to the other side to see if the marks line up. If not, tighten and/or loosen the verticals until the marks line up. Once the masthead is centered, begin tightening the verticals until the turnbuckles are approximately half closed. While tightening the verticals you may notice the bend in the mast increasing. Now you can tighten the lowers which will tend to straighten the lower part of the mast. Be sure to tighten port and starboard sides evenly.
5. Now you should tighten the headstay until it is approximately half closed as well. This should induce the appropriate amount of headstay tension. Never use anything more than a pair of wrenches to tighten your rigging. If you use an extended piece of pipe on the handle of a wrench you can over tighten the rigging and do damage to the mast or rigging.
6. The final test is to go sailing in 10-15 knots of wind. First, adjust the tension in the shrouds. If when sailing upwind, the shrouds on the leeward side are slack then tighten them to remove about half the slack keeping note of the number of turns. Then tack and do the same to the other side. Do this

TUNING THE 306 B&R RIG


until you are happy with the tension and the leeward side does not get loose when the boat is heeled. Now sight up the mast to be sure it is still relatively straight from side to side. If it is not then adjust to appropriate rigging to correct it.

7. At this point you should have adequate headstay tension. The sails are built for about 10" of headstay sag, the bend in the standard mast should be about 6" and 2" in the furling mast and it should be nearly straight from side to side when sailing upwind. If any of these are not true then revisit the appropriate step above to correct it. If the sag in the headstay is too much then adding tension to the verticals will fix it.
8. Once the rig is tuned you should make sure to add the cotter pins to all the rigging bending back the ends and taping them to prevent snagged lines, sails, and fingers.

Remember that rigging, like everything else, can age. As it gets older it may need to be replaced. The frequency for which this becomes necessary depends on the climate and conditions in which the boat is sailed. For example: if you sail in the Caribbean it should be replaced every 2-3 years compared to every 10 for the great lakes. You should consult a professional rigger for advice.



SEE PAGES 38B-40 FOR
DETAILED OPTIONAL DECK
HARDWARE INFORMATION



This document describes information for which HUNTER MARINE CORP. has proprietary rights.

HUNTER


H306SPINNAKER HDWR LAYOUT

DRAWING NO.	3068054	REVISION NO.	NONE
DATE	3/20/99	ENGINEERING DEPT.	

ENGINE OPERATING INSTRUCTIONS:

- ① *FILL DIESEL TANK WITH DIESEL FUEL*
- ② *CHECK ENGINE OIL LEVEL (SEE YANMAR MANUAL)*
- ③ *OPEN ENGINE RAW WATER PICKUP SEACOCK (SEE PAGE 60A)*
- ④ *TURN ON "START BATTERY SELECTOR SWITCH" (LOCATED AT NAVIGATION STATION)*
- ⑤ *TURN KEY TO START POSITION, RELEASE WHEN ENGINE STARTS*
NOTE" IF ENGINE APPEARS TO HAVE TROUBLE STARTING, SEE YANMAR MANUAL
- ⑥ *TO SHUT ENGINE DOWN: PUSH RED BUTTON AT KEY SWITCH PANEL*
UNTIL ENGINE STOPS RUNNING THEN TURN KEY TO OFF POSITION.

WARNING: DO NOT LEAVE AFT HATCHES/ PORTS OPEN WHILE ENGINE IS RUNNING. THERE EXISTS A POSSIBILITY OF EXHAUST POISONING, OR EVEN DEATH.



FRESH WATER SYSTEM OPERATION:


- ① FILL TANK WITH FRESH WATER (SEE PAGE 60B FOR FILL LOCATIONS)
- ② OPEN MANIFOLD VALVE (SEE PAGE 57B-1 FOR MANIFOLD LOCATION)
- ③ TURN BATTERY "ON/OFF" SWITCH TO THE ON POSITION
"FLIP" MAIN PANEL BREAKERS @ BATTERY SWITCH TO THE "ON" POSITION
(LOCATED BELOW NAV STATION)
- ④ TURN ON "D.C. MAIN" BREAKER ON MAIN BREAKER PANEL
- ⑤ TURN ON "WATER PRESSURE" BREAKER ON MAIN BREAKER PANEL
- ⑥ "HOT WATER" IS ATTAINABLE BASICALLY IN TWO WAYS...
 - Ⓐ BY HEATING THE WATER THRU THE ENGINE HEAT EXCHANGER UNIT
 - Ⓑ BY SUPPLYING 110V.A.C. BY "DOCKSIDE SHORE POWER".
- ⑦ TO HEAT BY "ENGINE" SEE PAGE 55 FOR ENGINE OPERATING INSTRUCTIONS.

NOTE: WHEN COOLANT IS INSTALLED, BLEED AIR FROM HEAT EXCHANGER LINES TO WATER HEATER. CRANK ENGINE, OPEN BLEEDER VALVE (SEE PAGE 55A) UNTIL AIR IS GONE FROM LINES

- ⑧ TO HEAT BY "SHORE POWER"
 - Ⓐ HOOK UP SHORE POWER CABLE/S
 - Ⓑ TURN ON A.C. MAIN BREAKER ON MAIN BREAKER PANEL
 - Ⓒ TURN ON "WATER HEATER" BREAKER ON MAIN BREAKER PANEL

NOTE: AS WITH ALL WATER HEATERS, BE SURE WATER TANK IS FULL BEFORE APPLYING POWER TO UNIT, TO AVOID DAMAGE TO HEATING ELEMENT

HOT WATER LINES
 - - - - -
 COLD WATER LINES
 = = = = =
 FRESH WATER FEED LINES TO MANIFOLD
 = = = = =



NOTATIONS ON FOLLOWING PAGE

DRAWING TITLE: **H306FRESH WATER SYSTEM LAYOUT**
 DRAWING NO.: 3068057B-1
 ENGINEERING DEPT.: ENGINEERING DEPT.
 DESIGNER NO.: NONE
 DATE: 4/14/99

This document contains information for which HUNTER MARINE CORP. has proprietary rights.

HUNTER

FRESH WATER SYSTEM LAYOUT LIST

A1
A2
A3
A4
A5
A6
A7
A8
A9

FWD WATER TANK COMPONENTS

FWD WATER TANK (40 GALLONS/151 LITERS)
TANK FILL VENT LOCATION (3/4" / 19.1mm HULL FITTING)
TANK FILL LOCATION (1 1/2" / 38.1mm DECK FITTING)
FILL HOSE RUN (1 1/2" / 38.1mm)
VENT HOSE RUN (3/4" / 19.1mm)
TANK ON/OFF VALVE (MANIFOLD) LOCATION (JUST AFT OF FWD BERTH)
FWD WATER TANK FEED LINE TO WATER PUMP (1 1/2" / 38.1mm)
TANK SENDING UNIT/ POWER LEADS
TANK SENDING UNIT LOCATION

B1
B2
B3
B4

WATER PUMP/HEATER COMPONENTS

WATER HEATER (6 GALLONS/23 LITERS)
WATER HEATER HEAT EXCHANGER LINES TO ENGINE
IN LINE WATER FILTER (LOCATED UNDER FWD STBD SETTEE)
12 VOLT D.C. WATER PUMP

C1
C2
C3

GALLEY WATER SYSTEM COMPONENTS

GALLEY FAUCET
GALLEY SINK DRAIN HOSE RUN (1 1/2" / 38.1mm)
GALLEY SINK DRAIN SEACOCK (1 1/2" / 38.1mm)

D1
D2
D3

HEAD WATER SYSTEM COMPONENTS

HEAD VANITY/ SHOWER FAUCET (SEE PG 59B FOR MORE DETAILS)
HEAD VANITY SINK DRAIN HOSE RUN (1" / 25.4mm)
HEAD VANITY SINK DRAIN SEACCK (1" / 25.4mm)

E1

TRANSOM SHOWER WATER SYSTEM COMPONENTS

TRANSOM SHOWER FAUCET


PROPOSED FILE
H3067FRESH WATER SYSTEM LAYOUT LIST (TRI CAB.)
ISSUANCE NO. 3068057B-2 ISSUANCE NO. NONE DATE 4/15/99
PROJECT ENGINEERING DEPT

HUNTERA

This document discloses information for which HUNTER MARINE CORP. has proprietary rights.

- A1 FWD WATER TANK (LOCATED UNDER FWD BERTH)
40 GALLONS / 151 LITERS
- A2 TANK FILL VENT THRU HULL (3/4" / 19.1mm)
- A3 TANK FILL DECK PLATE (1 1/2" / 38.1mm)
- A4 TANK FILL HOSE RUN (1 1/2" / 38.1mm)
- A5 TANK VENT HOSE RUN (3/4" / 19.1 mm)
- A6 TANK (ON/OFF) VALVE LOCATED @ AFT END OF
FWD BERTH. ACCESSED THRU PANEL UNDER BERTH
- A7 TANK FEED LINE TO WATER FILTER AND PUMP
(1/2" / 12.7mm)
- A8 TANK SENDING UNIT POWER/ GAUGE LEADS
- A9 TANK SENDING UNIT (LOCATED ON FWD WATER
TANK AFT END)


FILL PLATE LOCATED
INSIDE ANCHORWELL.



HOT WATER LINES (1/2" / 12.7mm)
=====

COLD WATER LINES (1/2" / 12.7mm)
=====


FRESH WATER FEED LINES TO MANIFOLD
=====



=====
 HOT WATER LINES (1/2" / 12.7mm)
 =====

 COLD WATER LINES (1/2" / 12.7mm)


- B1 6 GALLONS (23 LITERS) WATER HEATER
- B2 HEAT EXCHANGER LINES AFT TO ENGINE
- B3 IN LINE WATER FILTER (ACCESS UNDER FWD STBD SETTEE ACCESS PANEL)
- B4 12 VOLT D.C. WATER PUMP (PRESSURIZES WATER SYSTEM)
- C1 GALLEY FAUCET
- C2 GALLEY FAUCET SINK DRAIN HOSE RUN TO SEACOCK (1 1/2" / 38.1mm SHEILDVAC)
- C3 GALLEY DRAIN DISCHARGE SEACOCK (1 1/2" /38.1mm)



FOR MORE TILES
 H306 HEAD/ TRANSOM SHOWER COMPONENT LAYOUT
 3068057C-3
 NONE
 4/14/99
 ENGINEERING DEPT.

This document contains information for which HUNTER WATER CORP. HAS PROPRIETARY RIGHTS

HUNTER



ALL HOSES ARE
SANITATION GRADE


1. HEAD
2. RAW WATER PICKUP SEACOCK (3/4" / 19.1mm)
3. RAW WATER LINE TO HEAD (3/4" / 19.1mm)
4. RAW WATER LINE TO VENTED LOOP (3/4" / 19.1mm)
5. VENTED LOOP (3/4" / 19.1mm)
6. WASTE HOSE INTO TANK FROM HEAD (1 1/2" / 38.1mm)
7. WASTE HOLDING TANK (20 GAL. / 76 L.)
8. WASTE HOSE FROM TANK TO MACERATOR (1 1/2" / 38.1mm)
9. 12 VOLT D.C. MACERATOR PUMP
10. WASTE HOSE FROM MACERATOR TO DISCHARGE (1" / 25.4mm)
11. MACERATOR DISCHARGE SEACOCK (1" / 25.4mm HULL FITTING)
12. HOLDING TANK SEDNING UNIT
13. WASTE HOSE FROM TANK TO PUMP/OUT (1 1/2" / 38.1mm)
14. WASTE TANK VENT HOSE (3/4" / 19.1mm)
15. WASTE TANK VENT FITTING (3/4" / 19.1mm HULL FITTING)
16. WASTE TANK PUMP/OUT DECK PLATE (1 1/2" / 38.1mm)
17. SEDNING UNIT POWER LEADS TO PANEL / GAUGE
18. MACERATOR POWER LEADS TO MOMENTARY SWITCH/PANEL
19. (1 1/2" / 38.1mm) PVC WASTE PIPE RUN (THRU PAN)

H306 WASTE SYSTEM LAYOUT

This document discloses information for which HUNTER MARINE CORP. has proprietary rights.

HUNTER

PROJECT NO. 3068058A-1
ENGINEERING DEPT. NONE
DATE 4/15/99



ALL HOSES ARE
SANITATION GRADE

1. HEAD
2. WASTE HOSE FROM TANK TO "Y-VALVE" (1 1/2" / 38.1mm.)
3. "Y-VALVE" HANDLE (LOCATED ON VALVE)
4. "Y-VALVE" PRESENT ON SELECT OVERSEAS BOATS ONLY
5. WASTE HOSE FROM "Y-VALVE" TO DISCHARGE (1" / 25.4mm.)
6. DIRECT OVERBOARD DISCHARGE SEACOCK (1" / 25.4mm HULL FITTING)
7. WASTE HOSE FROM "Y-VALVE" TO HOLDING TANK (1 1/2" / 38.1mm.)
8. (1 1/2" / 38.1mm.) PVC WASTE PIPE RUN (THRU PAN)

NOTE:

ALL OTHER COMPONENTS ARE THE SAME AS THE PREVIOUS PAGE. SEE PAGE 58A-1 FOR FURTHER INFORMATION.


H306INTERNATIONAL WASTE SYSTEM LAYOUT

PROJECT NO.	3068058A-2	DESIGN NO.	NONE
ENGINEERING DEPT.		DATE	4/15/99


This document contains information for which HUNTER MARINE CORP. has proprietary rights.



THE MACERATOR MOMENTARY SWITCH IS PROVIDED TO PROHIBIT THE "DRY RUNNING" OF THE MACERATOR. TO OPERATE THE MACERATOR, TURN THE MACERATOR BREAKER TO THE "ON" POSITION. WHILE EITHER WATCHING THE WASTE TANK LEVEL INDICATOR, OR LISTENING TO THE PITCH OF THE PUMP, PUSH THE MOMENTARY SWITCH IN. THIS WILL ACTIVATE THE MACERATOR. ONCE THE TANK LEVEL INDICATOR REACHES "EMPTY", OR THE PITCH CHANGES NOTICEABLY, RELEASE THE MOMENTARY SWITCH AND TURN THE BREAKER TO THE "OFF" POSITION. NOTE: OCCASIONALLY THE TANK SENDING UNIT BECOMES STUCK, THEREFORE IT IS MORE EFFECTIVE AND SAFER FOR THE PUMP IF THE OPERATOR USES THE "LISTENING" METHOD TO DETERMINE IF THE TANK HAS BEEN EMPTIED.




MACERATOR SCHEMATIC TYPICAL



MOMENTARY SWITCH LOCATION


[Return to Table of Contents](#)
[This document contains information for which HUNTER MARINE CORP. has proprietary rights.](#)
HUNTER
H306 MACERATOR SCHEMATIC
 DRAWING NO. 3068058B
 REVISION NO. NONE
 DATE 6/22/01
 DRAWN BY: ENG




NOTE:
 ALWAYS KEEP WASTE DISCHARGE THRU HULL BALL
 VALVE CLOSED WHEN SYSTEM IS NOT IN USE.



1. BILGE PUMP RECESS
 2. BILGE PUMP FLOAT SWITCH
 3. 12 V.D.C. BILGE PUMP
- NOTE: THE FLOAT SWITCH AND THE PUMP ARE INTEGRATED INTO THE SAME CASING.
4. BILGE DISCHARGE HOSE (3/4" / 19.1mm SHIELDVAC HOSE)
 5. BILGE DISCHARGE (3/4" / 19.1mm THRU HULL)
 6. BILGE PUMP POWER LEADS TO MAIN DIST. PANEL (SEE PG 59D FOR DETAILS)
 7. OPTIONAL HIGH WATER BILGE PUMP WITH FLOAT SWITCH




1 1/8" HOSE



1. HEAD SHOWER DRAIN
2. SHOWER DRAIN HOSE RUN TO BILGE RECESS (3/4" / 19.1mm)
3. BILGE PUMP FLOAT SWITCH AND NOTE: THE FLOAT SWITCH AND THE BILGE PUMP ARE INTEGRATED INTO ONE CASING.
4. 12 V.D.C. BILGE PUMP
5. BILGE DISCHARGE HOSE (3/4" / 19.1mm SHEILDVAC HOSE)
6. BILGE DISCHARGE (3/4" / 19.1mm THRU HULL)
7. BILGE PUMP POWER LEADS TO MAIN DIST. PANEL (SEE PG 59D FOR DETAILS)


NOTE: THE SHOWER DRAINS DIRECTLY INTO THE BILGE RECESS, THEN UTILIZES THE BILGE PUMP SYSTEM TO DISCHARGE THIS "GRAY" WATER OVERBOARD.



1. STD. REFRIGERATION / ICE BOX DRAIN
 2. STD. REFRIGERATION DRAIN HOSE RUN TO BILGE RECESS (3/4" / 19.1mm)
- SEE PAGE 59A FOR DETAILS ON REFRIGERATION DRAIN WATER DISCHARGE
- NOTE: THE FREEZER DRAINS DIRECTLY INTO THE BILGE RECESS, THEN UTILIZES THE BILGE PUMP SYSTEM TO DISCHARGE THIS DRAINAGE OVERBOARD.**

NOTE: IT IS NECESSARY TO PLUG THE FREEZER DRAIN TO PREVENT COLD AIR FROM BEING PUMPED INTO THE BILGE. UNPLUG AND DRAIN THE LINE WHEN NEEDED.







This document discloses information for which HUNTER MARINE CORP. has proprietary rights.






H306 MANUAL BILGE PUMP LAYOUT			
REVISED NO.	3068059E	DESIGNER NO.	NONE
DATE	1/22/99	ENGINEERING DEPT	




1. WATER TANK VENT (THRU HULL)
2. BILGE PUMP DISCHARGE (THRU HULL)
3. GALLEY SINK DISCHARGE (BALL VALVE)
4. ENGINE RAW WATER PICKUP (BALL VALVE)
5. SELECT OVERSEAS MODEL DIRECT OVERBOARD WASTE DISCHARGE (BALL VALVE)
6. MACERATOR DISCHARGE (BALL VALVE)
7. HEAD VANITY SINK DISCHARGE (BALL VALVE)
8. LPG LOCKER DRAIN (THRU SHELL)
9. ENGINE EXHAUST




1. FWD WATER TANK FILL VENT (3/4" / 19.1mm)
2. FWD WATER TANK FILL LOCATION (1 1/2" / 38.1mm)
3. FUEL TANK VENT (3/4" / 19.1mm)
4. FUEL TANK FILL LOCATION (1 1/2" / 38.1mm)
5. TRANSOM SHOWER LOCATION
6. EMERGENCY TILLER COVER PLATE
7. MAJNAL BILGE PUMP PUMP ASSEMBLY
8. SHORE POWER INLET LOCATION
9. WASTE TANK VENT (3/4" / 19.1mm)
10. WASTE TANK DECK PUMP OUT LOCATION (1 1/2" / 38.1mm)





1. PRIMARY ENGINE FUEL FILTER
2. ENGINE FUEL HOSE
3. DIESEL FILL (DECK FITTING)
4. DIESEL TANK VENT (HULL FITTING)
5. DIESEL FILL HOSE
6. DIESEL VENT HOSE
7. TANK SENDING UNIT
8. SECONDARY FUEL FILTER

- - - = FUEL FEED LINE 1/4" (6.3 mm)
 ——— = FUEL RETURN 1/4" (6.3 mm)
 -x-x-x-x- = FUEL VENT HOSE 5/8" (15.9 mm)
 = FUEL FILL HOSE 1/2" (38.1 mm)
 - - - = OVERSEAS/CHTR SPEC ALUM. TANK STATIC GND.



1. DIESEL FUEL TANK (20 GALLONS / 76 LITERS)
2. FUEL FILL HOSE TO DECK FITTING (1 1/2" / 38.1mm)
3. FUEL VENT HOSE TO DECK FITTING (5/8" / 15.9mm)
4. DIESEL FUEL RETURN LINE (1/4" / 6.4mm)
5. DIESEL FUEL FEED LINE (1/4" / 6.4mm)
6. OVERSEAS/CHTR. SPEC ALUMINIUM TANK STATIC GUARD
7. PRIMARY FUEL FILTER @ ENGINE
8. SECONDARY FUEL FILTER @ ENGINE
9. (18 HP / 13.4 KW). DIESEL ENGINE


FILTER LOCATED ON
AFT ENGINE ROOM
BULKHEAD.

FILTER LOCATED ON
STBD. SIDE OF
ENGINE

This document describes information for which HUNTER MARINE CORP. has proprietary rights.


H306 ENGINE FUEL LINE RUNS AND COMPONENTS	
DRAWING NO.	3068061B
REVISION NO.	NONE
DATE	4/15/99
ENGINEERING DEPT.	

HUNTER




- 1 LPG TANK STORAGE BOX UNIT (LOCATED IN PORT AFT COCKPIT LOCKER)
- 2 LPG TANK (4 lbs. / 1.81 kgs.)
- 3 LPG TANK DRAIN TO THRU HULL (3/4" / 19.1mm)
- 4 LPG SUPPLY LINE TO STOVE (1/2" / 12.7mm)
- 5 LPG SOLENOID POWER LEAD TO SOLENOID
- 6 LIQUID TWO BURNER STOVE UNIT
- 7 LPG SOLENOID (REMOTE ON / OFF SWITCH)
- 8 LPG SOLENOID POWER LEAD TO MAIN PANEL





- 1 LPG TANK STORAGE BOX UNIT (LOCATED IN PORT AFT COCKPIT LOCKER)
- 2 LPG TANK (4 lbs. / 1.81 kgs.)
- 3 LPG TANK BOX DRAIN TO THRU HULL (3/4" / 19.1mm)
- 4 LPG SUPPLY LINE TO STOVE (1/2" / 12.7mm)
- 5 LPG SOLENOID POWER LEAD TO SOLENOID
- 6 LIQUID TWO BURNER STOVE UNIT
- 7 OPTIONAL LPG OVEN UNIT
- 8 LPG SOLENOID (REMOTE ON / OFF SWITCH)
- 9 LPG SOLENOID POWER LEAD TO MAIN PANEL



WARNING:

LPG BOTTLE MUST ALWAYS BE FIRMLY SECURED WITHIN THEIR ENCLOSURE/LOCKER.

NOTE: THIS DRAIN LINE MUST NOT HAVE ANY LOW SPOTS OR DIPS. IT SHOULD BE A CONTINUOUS DOWNHILL RUN.

WARNING:

FLEX-HOSE @ STOVE MUST ALWAYS RUN FAIR AND BE FREE OF KINKS AND CHAFING.


NOTE:

AFT SWIM LOCKER MODEL SHOWN LOCATIONS VARY IN SOME MODELS BASIC LAYOUT STILL APPLIES

WARNING:

VAPOR DRAIN MUST ALWAYS BE CLEAR AND CLEAN OF OBSTRUCTIONS CONTINUOUSLY WITHIN AND @ EACH END.

REMOTE CONTROL SHUT-OFF SOLENOID @ OR NEAR STOVE



GIMBALED STOVE

HUNTERA
 H306 OPTIONAL L.P.G. SYSTEM LAYOUT
 DRAWING NO. 3068062C
 ENGINEERING DEPT.
 REVISION NO. NONE
 DATE 4/15/99
This document contains information for which HUNTERA MARINE CORP. has proprietary rights.

H306 ELECTRICAL SYSTEMS

H306 ELECTRICAL SYSTEM CONTENTS

PAGES 63A-10 THRU 63C-3 CONTAINS A.C. POWER SYSTEMS
(110 V.A.C.) (220 V.A.C. ON OVERSEAS MODELS)

NOTE TO CONSUMER: THE FOLLOWING PAGES PROVIDE DETAILED INFORMATION, SCHEMATICS ETC. PERTAINING TO THE H306 **STANDARD** ELECTRICAL SYSTEMS AS WELL AS THE **OPTIONAL** ELECTRICAL SYSTEM.

BE SURE TO READ THE DRAWING TITLE IN THE TITLE BLOCK TO ENSURE YOU ARE REFERRING TO THE CORRECT SYSTEM FOR YOUR MODEL.

BASIC POWER SYSTEMS / MAIN DIST. PANEL DESCRIPTION.....	PAGES 63A-2 THRU 63A-5
SELECTOR SWITCH PANELS.....	PAGE 63A-6
POWER SYSTEMS TROUBLESHOOTING GUIDE	PAGES 63A-7 THRU 63A-8
A.C. DISTRIBUTION PANEL SCHEMATIC:	PAGES 63A-9
WATTAGE DEMANDS.....	PAGE 63-10
A.C. POWER WIRING.....	PAGE 63B
OPTIONAL BATTERY CHARGING SYSTEM.	PAGES 63C-1 THRU 63C-3

<u>PAGES 64A-1 THRU 64J CONTAINS D.C. POWER SYSTEMS</u> <u>(12-VOLT D.C.)</u>	
D.C. DISTRIBUTION. PANEL SCHEMATIC AND GROUNDING SYSTEM.....	PAGES 64A-1 & 64A-2
12 VOLT LIGHTING / SPEAKERS / STEREO.....	PAGES 64B-1 & 64B-3
OPTIONAL TV/DVD.....	PAGE 64B-4 THRU 64D-5
12 VOLT DECK WIRING.	PAGE 64C
OPTIONAL WINDLASS DETAILS.....	PAGE 64D-1 AND 63D-2
HEADLINER WIRE CHASE LOCATION.....	PAGE 64E
PAN WIRE CHASE LOCATIONS.....	PAGE 64F
OPTIONAL REFRIGERATION SYSTEM.....	PAGE 64G-1 THRU 64G-3
OPTIONAL AIR CONDITIONER.....	PAGES 64H
AUTOMATIC FIRE EXTINGUISHER SYSTEM.....	PAGE 64I-1 THRU 64I-2

SHORE POWER WIRING.....	PAGE 65A
ELECTRIC WIRING COLOR / GAUGE CHART.....	PAGE 65B

H306 POWER SYSTEMS OPERATION PROCEDURES



POWER SOURCE:	TO OPERATE:
(12V.)D.C. MAIN	<ol style="list-style-type: none"> TURN BATTERY SWITCH (LOCATED UNDER NAV STATION, AFT FACE OF SETTEE) TO THE #1, #2 OR "BOTH" POSITION. ** (SEE BATTERY SEL. SW. NOTE BELOW) TURN ON "D.C. MAIN" BREAKER ON D.C. SIDE OF MAIN DISTRIBUTION PANEL. D.C. SIDE OF DISTRIBUTION PANEL SHOULD NOW BE OPERABLE. IF NO POWER: CHECK 50a. RESET ON BATTERY SWITCH PANEL AND/OR BATTERY CONNECTIONS.
(110V.) A.C. MAIN (220V.A.C. ON SOME OVERSEAS MODELS)	<ol style="list-style-type: none"> CONNECT SHORE POWER CABLE TO DOCKSIDE POWER SUPPLY AND SHORE POWER INLET ON STERN OF BOAT. TURN ON "A.C. MAIN" BREAKER ON A.C. SIDE OF MAIN DISTRIBUTION PANEL. A.C. SIDE OF DISTRIBUTION PANEL SHOULD NOW BE OPERABLE. IF NO POWER: CHECK BREAKER AT DOCKSIDE POWER SUPPLY BOX. CHECK A.C. BREAKER LOCATED ON PORT SIDE OF Q-BERTH HEADLINER .

H306OPTIONAL BATTERY CHARGING SYSTEM OPERATION PROCEDURES

CHARGE SOURCE:	TO OPERATE:
OPT. BATTERY CHARGER	<ol style="list-style-type: none"> CONNECT SHORE POWER CABLE TO POWER A.C. SIDE OF MAIN DISTRIBUTION PANEL AND TURN ON THE "A.C. MAIN" BREAKER. TURN OPT. "BATTERY CHARGER" BREAKER (LOCATED ON "A" SIDE OF A.C. PANEL) TO THE "ON" POSITION NOTE: IT IS NOT NECESSARY TO TURN ON THE BATTERY SWITCH TO PROVIDE CHARGING POWER TO THE BATTERY/S.**
ENGINE ALTERNATOR	<ol style="list-style-type: none"> CHECK SEA STRAINER & OPEN ENGINE RAW WATER SEACOCK. SEE PAGE 60A FOR LOCATION. TURN BATTERY SELECTOR SWITCH TO THE #1, POSITION.** START SHIP'S ENGINE (FOLLOW STARTING INSTRUCTIONS IN THE "ENGINE MANUAL")
**BATTERY SEL. SWITCH	NOTE: THE H306IS CAPABLE OF HAVING TWO BATTERIES IF DESIRED (2ND BATT. NOT PROVIDED) SEE PAGE 63C-3 FOR BATTERY CONNECTION / OPTIONAL CHARGER DETAILS. WHEN CONNECTED AS SHOWN, YOU NOW F ISOLATION CAPABILITIES BY TURNING THE SEL. SW. TO THE #1 OR #2 POSITION, OR DRAW POWER FROM BOTH BATTERIES WHEN SWITCH IS IN THE "BOTH" POSITION.

NOTE: THIS LAYOUT IS INTENDED TO PROVIDE A BASIC UNDERSTANDING OF THE VARIOUS POWER SYSTEMS ONLY. IT IS NOT A SCHEMATIC! SEE FOLLOWING PAGES FOR MORE DETAILED INFO. SCHEMATICS, ETC.



ENGINE



POWER SYSTEM OPERATION:

1. SHORE POWER "A" INLET (STBD AFT TRANSOM)
2. SHORE POWER RESET BREAKER 30 amp (LOCATED IN THE STBD AFT EUROLOCKER)
3. ISOLATION TRANSFORMER (LOCATED IN THE STBD AFT TRANSOM)
4. 120 V.A.C. SUPPLY LINE TO A.C. SIDE OF MAIN DISTRIBUTION PANEL
5. ENGINE
6. ENGINE GROUND TO BUSS BAR
7. ENGINE STARTER LEAD TO BATTERY ON / OFF SWITCH
8. GROUNDING STUD
9. START BATTERY GROUND TO GROUNDING STUD
10. BATTERY ON / OFF SWITCH (LOCATED BELOW CHART TABLE)
11. START BATTERY LEAD TO BATTERY ON / OFF SWITCH
12. START BATTERY
13. MAIN DISTRIBUTION PANEL (LOCATED @ CHART TABLE)
14. OPTIONAL BATTERY CHARGER.




- = BATTERY SELECTOR SWITCHES
- = POWER FLOW DIRECTION
- = 12 V.D.C.
- = 120 V.A.C. (230 V.A.C. OVERSEAS MODELS)



H306 DISTRIBUTION PANEL

BREAKER	(D.C. SIDE OF PANEL)	DESCRIPTION
D.C. MAIN		SUPPLIES 12 V.D.C. POWER FROM BATTERY TO ALL BREAKERS ON D.C. SIDE OF PANEL.
PANEL LIGHTS		SUPPLIES POWER TO THE BACK LIGHTING ON THE MAIN DISTRIBUTION PANEL
CABIN LIGHTS		SUPPLIES POWER TO ALL THE INTERIOR LIGHTING AND COCKPIT LIGHT
AUTO PILOT (OPTIONAL)		SUPPLIES POWER TO THE OPTIONAL AUTOPILOT MOTOR/COMPONENTS. NOTE: THIS BREAKER MAY BE A "FANS" BREAKER IF OPTIONAL AUTOPILOT WASN'T CHOSEN. MAY BE USED FOR "FANS" OR AS A "SPARE" IF DESIRED, SINCE FANS ARE NOT PROVIDED.
WATER PRESSURE		SUPPLIES POWER TO FRESH WATER PUMP TO PRESSURIZE H2O SYSTEM.
L. P. GAS		SUPPLIES POWER TO L.P. GAS SWITCH AT GALLEY. SEE "SEAWARD MANUAL" FOR OPER. & SAFETY INST.
REFRIGERATION		SUPPLIES POWER TO THE OPTIONAL REFRIGERATION COMPRESSOR LOCATED IN THE PORT MAIN BUNK COMP.
BILGE PUMP		TOGGLE SWITCH STAYS IN THE "AUTO" POSITION, THIS ALWAYS FEEDS POWER TO THE FLOAT SWITCH (AS LONG AS BATTERY IS CONNECTED AND HAS AMPLE CHARGE) FOR MANUAL USE, PUSH SWITCH TO "MANUAL" PRIOR TO LEAVING VESSEL, "MANUALLY" TEST PUMP AND CHECK FLUID LEVELS (IF APPLIES) IN BATTERIES.
STEREO		BREAKER PROVIDED, STEREO IS NOT
ANCHOR LIGHT		SUPPLIES POWER TO 360 DEGREE LIGHT AT TOP OF MAST, USE WHEN ANCHORED AT NIGHT.
STEAMING LIGHT		SUPPLIES POWER TO STEAMING LIGHT (LOCATED W/ANCHOR LIGHT) USE AT NIGHT WHEN VESSEL UNDERWAY BY ENGINE POWER. (ALONG W/RUNNING LTS.)
RUNNING LIGHTS		SUPPLIES POWER TO THE BOW, STERN, & COMPASS LIGHT. USE AT NIGHT UNDER SAIL AND/OR ENGINE POWER.
INSTRUMENTS		SUPPLIES POWER TO KNOT & DEPTH, REPEATERS LOCATED ON SEAHOOD.
VHF		SUPPLIES POWER TO THE VHF RADIO LOCATED IN THE COMPANIONWAY(P.T. SIDE). (ON SOME EXPORT MODELS THE V.H.F. RADIO IS LOCATED BY THE MAIN DISTRIBUTION PANEL)
TANK INDICATOR		SUPPLIES POWER TO TANK/S SENDING UNITS TO DISPLAY TANK LEVELS ON TANK GAUGES.
MACERATOR		SUPPLIES POWER TO MACERATOR (LOCATED BEHIND THE AFT STATEROOM BUNK) NOTE: THIS DEVICE IS USED FOR DIRECT OVERBOARD DISCHARGE OF RAW SEWAGE, BE AWARE OF YOUR LOCAL BOATING REGULATIONS BEFORE USING.
WINDLASS (OPTIONAL)		SUPPLIES POWER TO UP/DOWN CONTROLS AT ANCHOR WELL. NOTE: IT IS GOOD PRACTICE TO START THE SHIPS ENGINE PRIOR TO OPERATING WINDLASS TO PREVENT BATTERY DRAIN. (IF NO POWER, CHECK RESET ON WINDLASS REMOTE PANEL)
BLOWER		SUPPLIES POWER TO ENGINE BOX BLOWER (LOCATED INSIDE ENGINE COMPARTMENT) AIDS IN COMP'T VENTILATION
YELLOW L.E.D.'S		LIGHT EMITTING DIODES ILLUMINATE WHEN 12 V.D.C. POWER PRESENT.
NOTE:		SEE PAGE 64A-1 FOR BREAKER AMPERAGES

BREAKERS	(A.C. SIDE OF PANEL)	DESCRIPTION
A.C. MAIN (SHORE POWER)		PROVIDES A.C. VOLTAGE TO MAIN DISTRIBUTION PANEL WHEN SHORE POWER CORD IS CONNECTED TO OUTLET AT DOCKING FACILITY.
OUTLETS		PROVIDES A.C. POWER TO THE OUTLETS IN THE AFT STATEROOM ,GALLEY , HEAD AND NAV. STATION NOTE: NO OUTLET PROVIDED IN HEAD ON SELECT 220 V. MODELS.
OUTLETS NOTE:		G.F.C.I. (GROUND FAULT CIRCUIT INTERRUPTER) OUTLETS ARE PROVIDED IN THE HEAD. THE G.F.C.I. OUTLET PROTECTS ALL THE OUTLETS ON THE PORT AND STBD SIDES OF THE BOAT THE RED (RESET) BUTTON RESTORES POWER TO THE OUTLETS ON THAT CIRCUIT. THE BLACK BUTTON (TEST) DISCONNECTS POWER TO THAT CIRCUIT.
WATER HEATER		SUPPLIES POWER TO WATER HEATER. BE SURE TANK IS FULL AND SYSTEM IS FREE FROM AIR BEFORE APPLYING POWER TO HEATER TO PREVENT ELEMENT BURNOUT.
BATTERY CHARGER		SUPPLIES POWER TO CHARGER FOR CHARGING BATTERY(S) (IF 2ND BATT. DESIRED SEE PAGE 63A-10 FOR DETAILS)
MICROWAVE		SUPPLIES POWER TO OUTLET BEHIND MICRO. IN WHICH MICROWAVE IS PLUGGED INTO.
SPARE		THIS SPACE PROVIDED FOR AN ADDITIONAL BREAKER IF DESIRED
MISC. INFO		
RED L.E.D.'S		ILLUMINATE WHEN A.C. POWER PRESENT.
REV. POLARITY		IF REVERSED POLARITY L.E.D. ILLUMINATES AFTER CONNECTING SHORE POWER CORD, DISCONNECT CORD AND HAVE DOCKSIDE POWER CHECKED BY QUALIFIED PERSONELL.
NOTE:		SEE PAGE 63A-10 FOR BREAKER AMPERAGES



H306 12V.D.C. SYSTEM TROUBLESHOOTING GUIDE


TO POWER PANEL: 1. TURN BATTERY SWITCH TO THE #1 OR #2 OR "BOTH" POS. (LOCATED IN STBD. AFT COCKPIT LOCKER)
 2. TURN ON "D.C. MAIN" BREAKER ON PANEL,
IF NO POWER TO PANEL , PUSH "RESET" ON BATTERY SWITCH PANEL
 AND/OR CHECK BATTERY CONNECTIONS.

COMPONENT	SYMPTOM	POSSIBLE SOLUTIONS
D.C. MAIN	NO POWER TO PANEL	SEE "TO POWER PANEL" ABOVE BATTERY/S CHARGED?
PANEL LIGHTS	WON'T ILLUMINATE	SEE "TO POWER PANEL" ABOVE (BULB/S / L.E.D.S) NEED REPLACING?
CABIN LIGHTS	WON'T ILLUMINATE	SEE "TO POWER PANEL" ABOVE BULB/S NEED REPLACING?
OPT. AUTO PILOT	WON'T OPERATE WON,T HOLD STEADY COURSE CONSTANTLY ADJUSTING HELM	SEE "TO POWER PANEL" ABOVE IS THERE ANY METAL OBJECTS NEAR THE FLUX GATE COMPASS LOCATED BEHIND THE KICKBOARD BULKHEAD IN THE Q-BERTH ? SENSITIVITY SETTING SET TO HIGH, SEE "AUTO PILOT MANUAL" FOR SENS. ADJ.
WATER PUMP	NO POWER CYCLES ON/OFF EXCESSIVELY	SEE "TO POWER PANEL" ABOVE FAUCETS OFF? LEAK IN SYSTEM SEE PAGEC 57A FOR CONNECTION LOC.
L.P. GAS	NO POWER TO SWITCH AT GALLEY SYSTEM TURNS ON, NO GAS PRESENT	SEE "TO POWER PANEL" PREV. PAGE IS TANK VALVE OPEN? IS TANK EMPTY? SEE "STOVE/OVEN" MANUAL
REFRIGERATION	WON'T GET COLD	SEE "TO POWER PANEL" ABOVE THERMOSTAT TURNED ON? SEE "REFRIGERATION" MANUAL SEEK QUALIFIED PERSONELL
BILGE PUMP	WON'T OPERATE AUTO OR MANUAL PUMP MAKES NOISE, DOESN'T PUMP PUMP RUNS BUT DOESN'T DISCHARGE	BATTERY LEVEL O.K.? CHECK BILGE RESET ON BATT. SW. PANEL BATTERY CONNECTIONS GOOD? DEBRIS IN PUMP IMPELLER? DISCHARGE HOSE CLOGGED?
ANCHOR, STEAM., & RUNNING LIGHTS	WON'T ILLUMINATE	SEE "TO POWER PANEL" ABOVE CHECK CONNECTION/S @ TERMINAL STRIP ABOVE PANEL AT TOP OF COMPRESSION POST BULB/S NEED REPLACING?
INSTRUMENTS	REPEATERS DON'T OPERATE	SEE "TO POWER PANEL" ABOVE DO TRANSDUCERS NEED CLEANING? SEE "INSTRUMENTS" MANUAL
V.H.F. RADIO	WON'T OPERATE TURNS ON WON'T TRANSMIT/RECEIVE	SEE "TO POWER PANEL" ABOVE RADIO TURNED ON? ANTENNA CONNECTED PROPERLY?
TANK INDICATOR	TANK LEVEL GAUGES DON'T ILLUMINATE TANK LEVEL DISPLAYED IS INCORRECT	SEE "TO POWER PANEL" ABOVE TANK SENDING UNIT NEEDS CLEANING
MACERATOR	WON'T TURN ON RUNS BUT DOESN'T DISCHARGE PUMP MAKES NOISE, DOESN'T PUMP	SEE "TO POWER PANEL" IS DISCHARGE SEACOCK OPEN? IS WASTE DECK FITTING SECURE, IS IT PULLING AIR THRU? IF SO, TIGHTEN CAP OR REPLACE O- RING ON CAP. IS TANK VENT (HULL FITTING) CLOGGED? (SEE PAGE 60 FOR LOCATIONS) LODGED DEBRIS, TURN OFF POWER TO PUMP, INSERT SCREWDRIVER INTO PUMP ARMATURE AT END OF PUMP AND TURN TO DISLODGE DEBRIS
WINDLASS (OPT.)	UP/DOWN CONTROLS DON'T OPERATE WINDLASS	SEE "TO POWER PANEL" ABOVE IS RESET "TRIPPED" ON WINDLASS RESET PANEL?
BLOWER	WON'T OPERATE PUMP MAKES NOISE, DOESN'T PUMP PUMP RUNS BUT DOESN'T DISCHARGE	BATTERY LEVEL O.K.? CHECK BREAKER @ MAIN DISTRIBUTION PANEL BATTERY CONNECTIONS GOOD? DEBRIS IN PUMP IMPELLER? DISCHARGE HOSE CLOGGED?

NOTE: COMPONENT/S FAILURE COULD ALSO BE THE RESULT OF A POOR "GROUND" CONNECTION. GROUND BUSS BARS ARE LOCATED IN THE BUNK COMPARTMENT BEHIND THE SELECTOR SWITCH PANEL. DUE TO VIBRATION, WEATHER CONDITIONS, ETC. OCCASIONAL INSPECTION, CLEANING AND TIGHTENING OF THESE TERMINALS (BY QUALIFIED PERSONELL) MAY BE NECESSARY.

H306 110V.A.C.(220 OVERSEAS MODELS) SYSTEM TROUBLESHOOTING GUIDE

COMPONENT	SYMPTOM	POSSIBLE SOLUTION/S
A.C. MAIN	NO POWER TO PANEL	SEE "TO POWER PANEL" ABOVE BATTERY/S CHARGED?
OUTLETS	WON'T ILLUMINATE	SEE "TO POWER PANEL" ABOVE IS OUTLET BREAKER/S ON CHECK RESET (RED BUTTON) ON G.F.C.I. OUTLETS AT GALLEY AND Q-BERTH
WATER HEATER	NO POWER WON'T HEAT WATER WATER TOO COLD/HOT	SEE "TO POWER PANEL" ABOVE IS BREAKER ON? CHECK "RESET" ON HEATER SEE "WATER HEATER MANUAL FOR LOCATION SEE WATER HEATER MANUAL FOR THERMOSTAT ADJUSTMENT AND/OR ELEMENT REPLACEMENT
OPT. BATTERY CHARGER	NOT CHARGING BATTERY/S NOTE:SECOND BATTERY NOT PROVIDED AS STANDARD	SEE "TO POWER PANEL" ABOVE IS BATTERY CHARGER BREAKER ON? ARE BATTERY CONNECTIONS GOOD? CHECK GROUND CONNECTIONS AT GROUND BUSS BAR SEE CHARGER MANUAL
ALTERNATOR	NOT CHARGING BATTERIES	CHECK CONNECTIONS AND/OR SEE ENGINE MANUAL
MICROWAVE		SEE TO POWER PANEL ABOVE IS BREAKER ON IS MICROWAVE ON? SEE MICROWAVE MANUAL



This document describes information for which HUNTER MARINE CORP. has proprietary rights.

HUNTER

H306 AC PANEL SCHEMATIC AND CHARGE CIRCUIT

REVISED BY: 3068063A-9 NONE

DATE: 5/20/99

ENGINEERING DEPT.

H306 WATTAGE DEMAND FOR ELECTRICAL EQUIPMENT AND APPLIANCES

NOTE: A PRUDENT MARINER REALIZES THAT THE RESOURCES TO POWER A VESSEL ARE LIMITED. WHEN USING THE ALTERNATE POWER SOURCES ONE SHOULD BE CONSERVATIVE AND AWARE OF THE AMOUNT OF POWER BEING SUPPLIED VERSES POWER BEING DRAWN THIS IS ESPECIALLY IMPORTANT WHEN USING THE INVERTER POWER. CONSULT THE "INVERTER MANUAL" FOR POWER OUTPUT CAPABILITIES.

FIXED APPLIANCES:

SEE MANUALS AND/OR SPECIFICATION SHEETS IN YOUR OWNER'S PACK

PORTABLE APPLIANCES:

BELOW ARE APPROXIMATE EXAMPLES OF THE AMPERAGE DRAW ASSOCIATED WITH CERTAIN ITEMS.


APPLIANCES: / WATTS:

COFFEE MAKER.....	800 - 1,000 WATTS
FRYING PAN.....	1,000 - 2,500 WATTS
TOASTER.....	800 - 1,000 WATTS
FAN.....	75 - 300 WATTS
RADIO.....	60 - 150 WATTS
TV.....	250 - 600 WATTS
HOT PLATE.....	800 - 1,200 WATTS
HAIR DRYER.....	700 - 1,100 WATTS
SHAVER.....	50 - 100 WATTS
CLOCK.....	25 - 50 WATTS
BLENDER.....	250 - 350 WATTS
TOASTER OVEN.....	1,250 - 1,700 WATTS

ALTERNATE POWER SOURCES: / PROVIDED WATTS:

SMALLER MODEL INVERTER.....	1,000 WATTS (YOUR MODEL)
LARGER MODEL INVERTER.....	2,000 WATTS
SMALLER MODEL GENERATOR.....	5,500 WATTS
LARGER MODEL GENERATOR.....	8,000 WATTS
SHORE POWER (PER INLET).....	3,500 WATTS

EXAMPLE: TV (250-600)+ TOASTER (800-1,000)+ HAIR DRYER (700-1,100) = TOTAL (1,750-2,700)
THUS, IF THE WATTS BEING USED EXCEEDS THE WATTS BEING PRODUCED, THEN SOME OF THE ITEMS IN USE WILL NOT BE FUNCTIONAL. AGAIN, IT IS IMPORTANT TO BE AWARE OF THE AMPERAGE DRAW VERSUS THE AMPERAGE OUTPUT AT ALL TIMES.



1. POWER OUTLETS
2. G.F.I. OUTLETS
3. DC REFRIGERATION COMP. UNIT
4. OPTIONAL BATTERY CHARGER
5. WATER HEATER

POWER PANE
This document describes information for which HUNTER HAWKE CORP. has proprietary rights.

H306AC POWER PAN WIRING SCHEMATIC	
REVISED NO.	3068063B
DESIGNER NO.	NONE
DATE	5/20/99
ENGINEERING DEPT.	



SECTION 63C...OPTIONAL BATTERY CHARGING SYSTEM

BASIC OPERATING INSTRUCTIONS:


- ① CONNECT SHORE POWER TO DOCKSIDE SUPPLY AND SHORE POWER INLET ON STERN OF BOAT
- ② TURN ON "A.C. MAIN" BREAKER
- ③ TURN ON "BATTERY CHARGER" BREAKER

NOTE:

CHECK FOR CORRECT FLUID LEVEL IN BATTERIES (IF APPLICABLE) PRIOR TO USING CHARGER.
USE OF CHARGER (OR ENGINE ALT.) IS IMPORTANT WHEN USING 12V.D.C. SYSTEMS
TO REDUCE BATTERY DRAIN.

NOTE: THIS LAYOUT IS INTENDED TO PROVIDE A BASIC UNDERSTANDING OF THE VARIOUS POWER SYSTEMS ONLY. IT IS NOT A SCHEMATIC! SEE FOLLOWING PAGES FOR MORE DETAILED INFO, SCHEMATICS, ETC.

ENGINE



POWER SYSTEM OPERATION:


1. SHORE POWER "A" INLET (STBD AFT TRANSOM)
2. SHORE POWER RESET BREAKER 30 amp (LOCATED IN THE STBD AFT EUROLOCKER)
3. 110 V.A.C. SUPPLY LINE TO A.C. SIDE OF MAIN DISTRIBUTION PANEL
4. ENGINE
5. ENGINE TO GROUNDING STUD
6. ENGINE CHARGE CIRCUIT TO BATTERY ON / OFF SWITCH
7. GROUNDING STUD
8. START BATTERY GROUND TO GROUNDING STUD
9. BATTERY ON / OFF SWITCH (LOCATED BELOW CHART TABLE)
10. START BATTERY LEAD TO BATTERY ON / OFF SWITCH
11. START BATTERY
12. MAIN DISTRIBUTION PANEL (LOCATED @ CHART TABLE)
13. OPTIONAL BATTERY CHARGER
14. OPTIONAL BATTERY CHARGER LEAD TO MAIN DISTRIBUTION PANEL
15. OPTIONAL BATTERY CHARGER LEAD TO BATTERY ON / OFF SWITCH
16. OPTIONAL BATTERY CHARGER LEAD TO GROUNDING STUD

- = BATTERY SELECTOR SWITCHES
- = POWER FLOW DIRECTION
- = 12 V.D.C.
- = 110 V.A.C. (220 V.A.C. OVERSEAS MODELS)

This document describes information for which HUNTER MARINE CORP. has proprietary rights.


H306 OPTIONAL BATTERY CHARGER SYSTEM LAYOUT	
REV. NO.	3068063C-2
DESIGNER	NONE
DATE	6/23/99
ENGINEERING DEPT.	

HUNTER




This document describes information for which HUNTER MARINE CORP. has proprietary rights.

PANEL COMPONENTS SHOWN AS VIEWED WHEN PANEL IS OPEN




1. OPTIONAL WINDLASS
2. OPTIONAL BATTERY CHARGER
3. PANEL GROUND TO GRND. STUD
4. START BATTERY
5. ENGINE GROUND TO GRND. STUD
6. CABIN LIGHTS
7. MACERATOR
8. BILGE PUMP
9. OPTIONAL AUTO PILOT

10. TANK SENDING UNITS
11. STEREO
12. OPTIONAL LPG SOLENOID
13. INSTRUMENTS
14. VHF RADIO
15. ANCHOR/STEAMING/DECK/RUNNING LIGHTS
(TERMINAL STRIP LOCATED ATOP COMPRESSION POST)
16. STERN LIGHT
17. ENGINE COMPARTMENT BLOWER




GROUNDING STUD LOCATED IN
BUNK COMPARTMENT BEHIND
SELECTOR SWITCH PANEL

EXAMPLE SWITCH PANEL WIRING (PARALLEL CIRCUITS)



EACH CIRCUIT IN PARALLEL. 16ga. BLU (LOAD TO BREAKER) AND 16ga. YEL. GROUND TO GROUND BUSS BAR (SEE EX.)

- SWIVEL LIGHTS
- DOME LIGHTS
- RECESSED LIGHTS
- NAV STATION MAP LIGHT




ALL SIX CIRCUITS TO MAIN DISTRIBUTION PANEL

COURTESY LIGHT LOCATED FWD EDGE OF COCKPIT CONSOLE

This document describes information for which HUNTER WAVE CORP. has proprietary rights.


HUNTER


PROJECT TITLE: H306 12 VOLT HEADLINE LIGHT WIRING LAYOUT
 DRAWING NO.: 3068064B-1
 REVISION NO.: NONE
 DATE: 5/20/98
 ENGINEERING DEPT.



1. PORT SIDE STEREO SPEAKER
2. STEREO SPEAKER WIRE (RUNS THRU CHASE TUBE IN HEADLINER)
3. STBD. SIDE STEREO SPEAKER
4. SPEAKER WIRE RUN TO STEREO RECEIVER UNIT
5. AM/FM/CD STEREO RECEIVER (LOCATED @ NAV STATION)

NOTE: SEE FOLLOWING PAGE FOR SPEAKER WIRING SCHEMATIC.






--- WIRE RUNS IN PAN
 — WIRE RUNS IN HEAD LINER

- ① CABLE/PHONE INLET
- ② CABLE/PHONE WIRES IN HEAD LINER
- ③ AC/DC MAIN PANEL
- ④ PHONE OUTLET
- ⑤ CABLE/POWER LEADS TO TV/DVD
- ⑥ DVD PLAYER
- ⑦ 10" FLAT SCREEN TV






10" FLAT SCREEN MONITOR

DRAWING TITLE: **OPTIONAL TV/DVD SCHEMATIC**
 DRAWING NO.: 3068064B-5
 DESIGNER: None
 DATE: 09/04/02
 DRAWN BY: ENG



This document contains information for which HUNTER WARE CORP. has proprietary rights.



- ① BOW LIGHT
 - ② OPTIONAL ANCHOR WINDLASS (SEE PAGE 64D-1 & 64D-2)
 - ③ OPTIONAL WINDLASS CONTROLS
 - ④ POWER LEADS TO ANCHOR, DECK, STEAMING LIGHTS
 - ⑤ COURTESY LIGHT (IN COCKPIT CONSOLE BASE)
 - ⑥ STERNLIGHT
 - ⑦ COMPASS WIRE RUN
- = VHF COAX CABLE (CONNECTOR ABOVE MAST POST)

NOTE: SOME WIRE RUNS SHOWN IN APPROXIMATE LOCATIONS FOR CLARITY, SEE PAGE 64F FOR WIRE CHASE LOCATIONS

PROJECT TITLE: **H306 12V. WIRING DECK**

DESIGN NO.: 3068064C

ENGINEERING DEPT: NONE

DATE: 5/21/99

This document describes information for which HUNTER MARINE CORP. has proprietary rights.

HUNTER

SECTION 64D...OPTIONAL WINDLASS SYSTEM

BASIC OPERATING INSTRUCTIONS:

LOWERING ANCHOR...

- ① TURN ON START BATTERY SWITCH UNDER NAV. STATION.
- ② TURN ON WINDLASS BRKR. ON MAIN D.C. BRKR. PANEL.
- ③ ENSURE THE RESET BREAKER @ NAVIGATION STATION IS "RESET".
- ④ PUSH WINDLASS "DOWN" BUTTON INSIDE ANCHOR WELL LOCKER.


NOTE: "BUMP" SWITCH UNTIL ANCHOR CLEARS ANCHOR ROLLER AND HULL BEFORE LETTING ANCHOR DOWN FREELY.

RAISING ANCHOR...

- ① START BOAT ENGINE, THIS WILL ALLOW CONTROL OF BOAT WHEN ANCHOR BECOMES FREE, AS WELL AS REDUCING LOAD ON THE START BATTERY
- ② SAME AS STEP #1 OF LOWERING ANCHOR
- ③ SAME AS STEP #2 OF LOWERING ANCHOR
- ④ PUSH WINDLASS "UP" BUTTON (LOCATED-NEXT TO "DOWN BUTTON" BEING CAREFUL-AS THE ANCHOR APPROACHES THE HULL AND ANCHOR ROLLER) UNTIL THE ANCHOR RESTS IN THE STEMHEAD PROPERLY.

NOTE: IF IT APPEARS THERE IS NO POWER TO THE WINDLASS, CHECK RESET BRKR. AT THE NAV. STATION.
IF WINDLASS BECOMES INOPERABLE ELECTRICALLY, A MANUAL WINCH HANDLE IS SUPPLIED, SEE THE "WINDLASS MANUAL" SUPPLIED IN YOUR OWNERS MANUAL PACKAGE FOR INSTRUCTIONS.

16ga TAN




For document access information for which HUNTER MARINE CORP. has proprietary rights.

HUNTER

H3060OPTIONAL WINDLASS WIRING	
REVISED NO. 3068064D-2	REVISION NO. NONE
ENGINEERING DEPT.	DATE 6/23/99

NOTE: SEE PAGE 64C FOR POWER FEED/WIRE RUN LOCATIONS



ACCESS PANEL
LOCATION

1 1/2" (38.1mm) FLEX
PVC CHASE TUBE


ACCESS PANEL
LOCATION

This document describes information for which HUNTER MARINE CORP. has proprietary rights.

H306HEADLINER CHASE TUBE LOCATION

DRAWING NO.	3068064E	REVISION NO.	NONE
DATE	5/20/98	ENGINEERING DEPT.	





DRAWING TITLE: **H306THRU PAN HOLE/CHASE TUBE LOCATIONS**
 DRAWING NO.: 3068064F
 ENGINEERING DEPT.: ENGINEERING DEPT.
 DESIGN NO.: NONE
 DATE: 4/30/99

This document contains information for which HUNTER MARINE CORP. has proprietary rights.

HUNTER


SECTION 64G...OPTIONAL REFRIGERATION SYSTEM

BASIC OPERATING INSTRUCTIONS:


- ① TURN ON HOUSE/START BATTERY SWITCH (LOCATED UNDER NAV. STATION)
- ② TURN ON MAIN D.C. BREAKER AT MAIN BREAKER PANEL
- ③ TURN ON REFRIGERATION BREAKER
- ④ SET THERMOSTATS TO DESIRED TEMP.

NOTE:

IF LEAVING UNIT ON WHEN AWAY FROM BOAT
BE SURE SHORE POWER CABLES ARE CONNECTED AND
BATTERY CHARGER IS ON TO PREVENT BATTERY DRAIN.



1. MAIN DISTRIBUTION PANEL (LOCATED @ NAV. STATION)
2. POWER LEADS FROM PANEL TO REFRIGERATION UNIT
3. REFRIGERATION UNIT EXHAUST VENT
4. REFRIGERATION UNIT INTAKE VENT
5. REFRIGERATION INTAKE DUCT
6. THERMOSTAT CONTROL LINE FROM COMPRESSOR TO CONTROL UNIT
7. THERMOSTAT CONTROL UNIT (LOCATED INSIDE REFRIGERATOR)
8. OPTIONAL REFRIGERATOR
9. REFRIGERATION LINES TO REFRIGERATOR
10. REFRIGERATION LINES FROM REFRIGERATOR
11. REFRIGERATOR COMPRESSOR (LOCATED UNDER PORT SETTEE)




- ① REFRIGERATION COMPRESSOR
- ② REFRIGERATION UNIT CONTROL BOX
- ③ THERMOSTAT
- ④ UNIT COOLING (AIR INTAKE) FANS
- ⑤ 12V. POSITIVE FROM LOAD SIDE (8GA. RED) OF BREAKER TO REFRIGERATION UNIT
- ⑥ GROUND FROM REFRIGERATION UNIT (8GA. BLACK) TO GROUND BUSS BAR BEHIND BREAKER PANEL
- ⑦ THERMOSTAT CONNECTOR PLUG


NOTE: SEE REFRIGERATION MANUAL FOR CONTROL BOX HOOKUP DETAILS




This document describes information for which HUNTER WAPAC CORP. has proprietary rights.



A	3/4" (1.9cm) BALL VALVE WITH THRU-HULL	G	5/8" (1.6cm) HOSE	M	6" (15.2cm) X 10" (25.4cm) VENT
B	3/4" (1.9cm) STRAINER	H	1/2" (1.27cm) HULL VALVE	N	TRANSITION BOX WITH 3" (7.6cm) OUT
C	3/4" (1.9cm) HOSE	I	1/2" (1.27cm) DISCHARGE THRU-HULL FITTING	O	3" (7.6cm) DUCT
D	5/8" (1.6cm) HOSE	J	4" (10.2cm) ROUND VENT	P	4" (10.2cm) ROUND VENT
E	A/C SEA WATER PUMP	K	4" (10.2cm) DUCT	Q	6" (15.2cm) DUCT
F	10K BTU AIR CONDITIONER	L	12" (30.5cm) X 12" (30.5cm) RETURN AIR VENT	R	DISTRIBUTION BOX




ENLARGEMENT OF BOXED AREA



- ① AUTOMATIC FIRE EXTINGUISHER
- ② ENGINE PANAL (STRBD COCKPIT)
- ③ DISPLAY (STRBD COCKPIT)
- ④ ENGINE INTERRUPT CONTROL BOX

TO ISOLATION TRANSFORMER

30 AMP SHORE POWER BREAKER
(LOCATED IN STBD AFT EUROSEAT LOCKER)



LINE 1

NOTES: RESET BREAKER ARE
IN THE STBD AFT EURO LOCKER
SEE PAGE 60B FOR LOCATION
OF SHORE POWER INLET.
SEE PAGE 63C FOR WIRE
RUN LOCATION
SEE PAGE 64A-1 FOR "BATTERY
SWITCH" WIRING

MASTER ELECTRICAL AMPERAGE DATA

12V.D.C. SYSTEM	
CIRCUIT/BREAKER	AMPERAGE
D.C. MAIN	50amp
PANEL LIGHTS	5amp
CABIN LIGHTS 1	20amp
CABIN LIGHTS 2	20amp
COURTESY 1	10amp
COURTESY 2	10amp
TANK INDICATOR	5amp
WATER PRESSURE	10amp
FWD.SHOWER SUMP	10amp
AFTSHOWER SUMP	10amp
MACERATOR 1	20amp
MACERATOR 2	20amp
STEREO	15amp
STEREO W/AMPLIFIER	20amp
REFRIGERATION	15amp
L.P. GAS	5amp
WINDLASS (SWITCH)	5amp
INSTRUMENTS	5amp
G.P.S.	5amp
V.H.F.	10amp
AUTO-PILOT	VARIES PER MODEL
ANCHOR LIGHT	5amp
STEAMING LIGHT	5amp
DECK LIGHT	15amp
RUNNING LIGHTS	10amp (LGR. MOD.)
RUNNING LIGHTS	5amp (SM. MOD.)
COMPASS (TIES TO RUN. LIGHTS)	300amp
BATTERY CABLES	
ENGINE STARTER CABLE	
HALYARD WINCH	
WINDLASS (MOTOR) CABLE	


110V.A.C. SYSTEM	
SHORE POWER A.C. MAIN/S	30 amp
OUTLETS	15amp
MICROWAVE OVEN	15amp
WATER HEATER	20amp
BATTERY CHARGER	15amp
INVERTER	INTERNAL
AIR CONDITIONING	25amp

220V.A.C. SYSTEM (ON SELECT OVERSEAS MODELS ONLY)	
SHORE POWER A.C. MAIN/S	15 amp
OUTLETS	10amp
MICROWAVE OVEN	10amp
WATER HEATER	10amp
BATTERY CHARGER	10amp
INVERTER	N/A
AIR CONDITIONING	15amp

MASTER ELECTRICAL WIRING/CABLE DATA

DESCRIPTION	PRT. NUMBER	WIRE SIZE	WIRE COLOR
LPG SWITCH/POWER	659802	16 gauge	ORANGE/RED
SENDER GUAGES	658600	16 gauge	RED/BLUE
FUEL SENDER	658100	16 gauge	PINK,ORANGE/WHITE
GROUND	659800	16 gauge	YELLOW
FWD WATER SENDER	659806	16 gauge	ORANGE/BLUE, PINK/BLACK
GROUND	659800	16 gauge	YELLOW
WATER PUMP	655200	12 gauge	BROWN
GROUND	659700	12 gauge	YELLOW
VACCU FLUSH	652202	10 gauge	BROWN/RED
GROUND	659800	16 gauge	YELLOW
AFT WASTE SENDER	659805	16 gauge	ORANGE/GREEN, PINK/GRAY
GROUND	659800	16 gauge	YELLOW
AFT SUMP PUMP	655400	12 gauge	BROWN/BLACK
GROUND	659700	12 gauge	YELLOW
FWD MACERATOR	655800	10 gauge	BROWN/WHITE
GROUND	659800	16 gauge	YELLOW
SOLAR PANEL	653640	16/2 DUPLEX	RED/YELLOW
VHF	653300	16 gauge	RED/WHITE
GROUND	659800	16 gauge	YELLOW
COURTESY LIGHTS	655100	16 gauge	BLUE/WHITE
GROUND	659800	16 gauge	YELLOW
CABIN LIGHTS	655000	16 gauge	BLUE
GROUND	659800	16 gauge	YELLOW
PORT FWD SPEAKERS	653620	16 gauge	WHITE/RED
STBD FWD SPEAKERS	653622	16 gauge	WHITE/BROWN
PORT MAIN SPEAKERS	653623	16 gauge	WHITE/ORANGE
STBD MAIN SPEAKERS	653624	16 gauge	WHITE/BLUE
PORT AFT SPEAKER	653625	16 gauge	WHITE/GREEN
STBD AFT SPEAKER	653626	16 gauge	WHITE/VIOLET
PORT ARCH SPEAKER	653627	16 gauge	WHITE/PINK
PORT GROUND	653629	16 gauge	WHITE/YELLOW
STBD ARCH SPEAKER	653630	16 gauge	WHITE/GRAY
STBD GROUND	659800	16 gauge	WHITE/BLACK
COMPASS BOW LIGHT	659804	16 gauge	GRAY/WHITE
STERN LIGHT		16 gauge	GRAY/YELLOW
GROUND	659800	16 gauge	YELLOW
MAST LIGHT	657300	16 gauge	GRAY
STEAMING LIGHT	656800	16 gauge	GRAY/GREEN
ANCHOR LIGHT	656900	16 gauge	GRAY/RED
HOUSE BATTERY	653610	2/O, 2 gauge	RED
GROUND	653900	2/O, 2 gauge	YELLOW
AC/DC PANEL	657900	6 gauge	ORANGE/RED,ORANGE/GREEN
GROUND	653618	6 gauge	YELLOW
ENGINE	654100	1/O, 2 gauge	RED
HALYARD	654010	1/O, 2 gauge	YELLOW
T.V. / V.C.R.	658400	10 gauge	RED
GROUND	653631	10 gauge	YELLOW
REFRIGERATION	658800	8 gauge	RED/BLACK
FREEZER	658900	8 gauge	RED/WHITE
GROUND	653615	8 gauge	YELLOW
STEREO OUT	657600	12 gauge	ORANGE/GREEN
STEREO POWER	658500	12 gauge	RED
GROUND	659700	12 gauge	YELLOW
INVERTER GROUND	653642	4 gauge	GREEN/YELLOW
WINDLASS SWITCH	659200	16 gauge	TAN
MANUAL BILGE	655700	12 gauge	BROWN/RED
AUTO BILGE	655600	12 gauge	BROWN/ORANGE
GROUND	659700	12 gauge	YELLOW
AFT MACERATOR	652400	10 gauge	BROWN
AFT SUMP PUMP	655400	12 gauge	BROWN/BLACK
FWD SUMP PUMP	654600	12 gauge	BROWN/YELLOW
AUTO PILOT	658700	10 gauge	RED
GROUND	653615	10 gauge	YELLOW
CHAINPLATE	653642	4 gauge	GREEN/YELLOW
BATTERY CHARGER # 1	658000	8 gauge	ORANGE/RED
BATTERY CHARGER # 2	657800	8 gauge	ORANGE/GREEN

HEAVY DUTY FLEXIBLE EXHAUST HOSE
2" (50.8mm)



ENGINE


TOP VIEW

ALL HOSES ARE
DOUBLE CLAMPED.

LOOP

ELBOW @ ENGINE

CLAMP



ENGINE

SIDE VIEW

WATERLINE

MUFFLER

OUTLET

HULL BOTTOM


THIS DOCUMENT CONTAINS INFORMATION FOR WHICH HUNTER MARINE CORP. HAS PROPRIETARY RIGHTS.

H3306 EXHAUST SYSTEM LAYOUT	
DRAWING NO. 3068066	REVISION NO. NONE
ENGINEERING DEPT.	DATE 11/16/99


HUNTER




STEERING CONSOLE HOLDS INSTRUMENTS SUCH AS KNOTMETER, DEPTH GAUGE, WIND INDICATOR, ETC



SEE WHITLOCK PROVIDED MATERIAL FOR DETAILED INFORMATION ON COMPONENTS, MAINTENANCE, ETC






This document contains information for which HUNTER MARINE CORP. has proprietary rights.

HUNTER

H306 RUDDER & SHAFT DETAILS	
DESIGN NO.	3068068
REVISION NO.	NONE
DATE	2/4/99
ENGINEERING DEPT.	



DWL

CONTROL LINE EYE

SLOT IN BOTTOM OF EMERGENCY TILLER
 FITS OVER BOLT IN TOP OF CONTROL
 ARM AFTER OPENING
 DECK PLATE ACCESS

DECK PLATE ACCESS

CONTROL ARM

FORWARD


This document contains information for which HUNTER MARINE CORP. has proprietary rights.




H306 EMERGENCY TILLER	
REVISED NO.	3068069A
DESIGNER NO.	NONE
DATE	4/16/99
ENGINEERING DEPT.	

**NOTE: IF SECURING TILLER BECOMES NECESSARY-
OR IF YOU DESIRE TO STEER FROM COCKPIT**

**SECURE LINE TO EYE ON TILLER HANDLE
LEAD AROUND MOORING CLEATS AS SHOWN
THEN FORWARD TO WINCHES.**




INSTALL TILLER BASE
THRU ACCESS PLATE
ON STERN STEP




1. REMOVE ACCESS PLATE COVER ON STERN STEP
2. INSERT SLOT IN TILLER BASE OVER PIN IN TOP OF RUDDER POST.
3. INSTALL TILLER HANDLE OVER TILLER BASE ALIGNING PIN HOLES, INSERT LOCKING PIN.

EMERGENCY STEERING

NOTE: THE FORWARD SIDE CLEATS ON THE DECK ARE CONSIDERED THE STRONG POINT. THAT SHOULD BE THE ANCHOR POINT IF THE BOAT IS TO BE LEFT UNATTENDED.



DANFORTH ANCHOR



FLOW ANCHOR



ANCHOR RODE
(CHAIN OR ROPE OR COMBO)



TYPICAL CLEAT
LOCATIONS VARY
W/MODEL.

STAINLESS BOW ROLLER
(SIZE & SHAPE VARIES
BETWEEN MODELS)

- GROUND TACKLE:**
- 1.) BOW SHACKLE(W/PIN WIRED)
@ ANCHOR...FOLD. BY...
 - 2.) SWIVEL...FOLD. BY...
 - 3.) CHAIN(OPTION)...FOLD. BY...
 - 4.) D-SHAPED SHACKLE(W/PIN
WIRED) @ EA. 27M OF CHAIN
OR @ CHAIN TO ROPE RODE.

PLAN

ELECTRIC ANCHOR WINDLASS
(STANDARD OR OPTIONAL ON LARGER MODELS)

WELL: SMALLER MODELS

WELL: LARGER MODELS

ELEVATION

WATERLINE

3D=CHAIN
5D=ROPE

D

DRAWING TITLE: **BASIC ANCHORING DIAGRAM**
This document contains information for which HUNTER MARINE CORP. has proprietary rights.

DESIGNER NO.	DATE
30688070A	07/15/03
COMPANY BY:	ENG
REVISION NO.	NONE

HUNTER

NOTE: THE FORWARD SIDE CLEATS ON THE DECK ARE CONSIDERED THE STRONG POINT. THESE ARE THE CLEATS TO BE USED FOR ANCHORING, MOORING, AND TOWING.

THE AFT CLEATS ARE THE STRONG POINT FOR MOORING OR TOWING ANOTHER VESSEL.

STRONG POINT BREAKING STRENGTH: 8947.4 Pf (39.8 Kn)



CAUTION:

- 1. THE BREAKING STRENGTH OF LINES/CHAINS SHALL IN GENERAL NOT EXCEED 80 % OF THE BREAKING STRENGTH OF THE RESPECTIVE STRONG POINT.**
- 2. ALWAYS TOW OR BE TOWED AT A SLOW SPEED. NEVER EXCEED THE HULL SPEED OF A DISPLACEMENT CRAFT WHEN BEING TOWED.**
- 3. A TOW LINE SHALL ALWAYS BE MADE FAST IN SUCH A WAY THAT IT CAN BE RELEASED WHEN UNDER LOAD.**

NOTE:

IT IS THE OWNER'S/OPERATORS RESPONSIBILITY TO ENSURE THAT MOORING LINE, TOWING LINES, ANCHOR CHAIN(S), ANCHOR LINES AND ANCHOR(S) ARE ADEQUATE FOR THE VESSEL'S INTENDED USE, I.E. THE LINES OR CHAINS DO NOT EXCEED 80 % OF THE BREAKING STRENGTH OF THE RESPECTIVE STRONG POINT.

OWNER'S SHOULD ALSO CONSIDER WHAT ACTION WILL BE NECESSARY WHEN SECURING A TOW LINE ON BOARD.



DRAWING TITLE: **STRONG POINTS**
This document contains information for which HUNTER MARINE CORP. has proprietary rights.

<small>DRAWING NO.</small> 30668070B	<small>VERSION NO.</small> NONE
<small>DESIGNED BY</small> ENG	<small>DATE</small> 07/15/03