


# Hunter 31

## Deck Hardware

H31 DECK HARDWARE LIST

ITEM	QTY.	DESCRIPTION
1	1	COMPWAY U CHANNEL
2A	1	DECK RAIL SLIDER STBD
2B	1	DECK RAIL SLIDER PORT
3	2	HELMSEAT MOUNT BRACKET
4	1	HELMSMAN SEAT
5	1	SEAHOOD SLIDER
6	1	ARCH
7	1	FIXED PORTLIGHT PORT
8	1	FIXED PORTLIGHT STBD
9	1	STERNRAIL PORT
10	1	STERNRAIL STBD
11	1	OPTIONAL WINDLASS
12	1	ANCHOR ROLLER
13	1	BOWRAIL
14	1	BOWRAIL LIGHTPLATE
15	7	CLEAT 8" STAINLESS
16	2	SHEET-ORGANIZER
17	4	30CST WINCH
18	1	LOW-PROFILE SIZE 40
18	1	LOW-PROFILE SIZE 40 RING
18	1	LOW-PROFILE SIZE 40 TOP
19	1	LOW-PROFILE ROUND SIZE 22
19	1	LOW-PROFILE ROUND SIZE 22 RING
19	1	LOW-PROFILE ROUND SIZE 22 TOP
20	2	LPG TANK(S)
21	10	STANCHION BASE
22A	4	STANCHION
22B	2	GATE STANCHION
23	1	STEERING PEDESTAL PLATE
24	2	STERNRAIL SEAT
25	2	SHEET STOPPER
26	1	SWIM LADDER
27	1	STEERING SYSTEM
28	2	JIB TRCK SYSTEM
29	2	OPTIONAL JIB TRCK SYSTEM
30	2	PORT LIGHT (SMOKED)
31	2	PORT LIGHT (FROSTED)
32	1	MAST STEP and BASE PLATE
33	2	JIB TURNING BLOCK
34	1	STEM PLATE
35	1	EMERGENCY TILLER ACCESS
36	2	CHAINPLATE
37	2	DECK HANDRAIL



⚠ CAUTION ⚠


Always be aware of your surroundings when on the deck!

Area's of the deck may be very slippery when wet. This could result in a fall, or a "Man Overboard"! Be sure and review the procedures for rescue of a man overboard, and have a plan in place!

# Hunter 31

## Fuel System

- A FUEL FILL HOSE 1 1/2" (3.8cm)
- B FUEL FILL (ON DECK)
- C FUEL VENT (ON HULL)
- D FUEL VENT HOSE 5/8" (1.6cm)
- E FUEL FILTER/WATER SEPARATOR
- F ENGINE FUEL RETURN LINE 1/4" (.64cm)
- G ENGINE FUEL SUPPLY LINE 1/4" (.64cm)
- H ENGINE FUEL RETURN PORT
- I FUEL CUTOFF VALVE
- J FUEL LEVEL SENSOR



### ⚠ DANGER ⚠

California Proposition 65  
Diesel Engine Exhaust and some of its components are known by the state of California to cause cancer, birth defects, and other reproductive harm.

Leaking fuel is a fire and explosion hazard. Avoid serious injury or death from fire or explosion.

#### NO SMOKING

Keep both sight gauge valves closed except when checking fuel level.

Do not mistake the water fill, waste pumpout, or even a rod holder for the Fuel Fill, ensure you are placing fuel in the correct deck fitting.

Before starting the engines, open the engine compartment and check for fuel smell.

\*If you smell fuel, do not start the engine; get everyone off the boat and get trained help to find and fix the problem.

### ⚠ CAUTION ⚠


The "Fuel System" chapter 5, and "Boating Safety" chapter 4 both contain important fuel related information. Take the time to read all the fuel related information in your Operator's Manual, Owner's Manual, as well as the O.E.M. manuals.



# Hunter 31

## LPG (Liquified Petroleum Gas) Lines Layout

- A LPG TANK(S) LOCATED IN STBD SWIM LOCKER
- B LPG SOLENOID
- C RUBBER GAS LINE HOSE (COPPER IN CERTAIN REGIONS)
- D POWER LINE FROM LPG CONTROL SWITCH
- E GIMBALLED STOVE
- F REMOTE CONTROL SHUT-OFF LOCATED IN GALLEY FACE
- G POWER FROM MAIN ELECTRIC PANEL TO REMOTE SWITCH






# Hunter 31

## Bottom Thru Hulls

1. VANITY SINK DISCHARGE	4. ENGINE PICKUP
2. HEAD PICK UP	5. KNOT TRANSDUCER
3. GALLEY DRAIN	6. DEPTH TRANSDUCER
7. MACERATOR DISCHARGE	






# Hunter 31

## DC Wiring Diagram

1. SHORE POWER POWERS AC PANEL
2. SHORE POWER RESET
3. HOUSE BATTERIES PROVIDE 12VDC VOLTAGE TO DC SIDE OF DISTRIBUTION PANEL AND TO THE OPTIONAL INVERTER VIA THE BATTERY SWITCH PANEL
4. OPTIONAL INVERTER CONVERTS 12VDC TO AC VOLTAGE AND POWERS AC PANEL (WITH THE EXCEPTION OF THE WATER HEATER)
5. OPTIONAL BATTERY CHARGER

NOTE: BE SURE THE BATTERY SELECTOR SWITCH ON THE BATTERY CHARGER IS IN THE PROPER POSITION FOR YOUR BATTERY TYPE.



### ⚠ DANGER ⚠

Fuel Fumes in the engine compartment can explode! Before working on any electrical wiring, ventilate the engine compartment and disconnect the batteries to prevent sparking.

Never use an open flame in a battery storage area.

Batteries can explode if a spark or flame ignites the free hydrogen given off during charging.

Batteries contain Sulfuric Acid and can cause severe personal injury if mishandled. Avoid contact, flush with water for at least 15 in. If swallowed, drink large quantities of milk of magnesia, beaten egg, or vegetable oil, and get medical attention immediately.

Never reset a breaker that has tripped without first correcting the problem. Electrical system devices can be damaged and be faulty which can cause fire. Always correct the problem causing the tripped breaker before re-energizing.


Alterations or extensions to your electrical system can cause electrical fire or shock.



# Hunter 31

## Optional Inverter System Layout

1. INVERTER
2. HOUSE BATTERY
3. HOUSE BATTERY OPTION
4. BATTERY SELECTOR PANEL
5. 200 AMP FUSE (UNDER NAV STATION STEP)
6. MAIN BREAKER PANEL
7. NEGATIVE BUS BAR



### ⚠ DANGER ⚠

Fuel Fumes in the engine compartment can explode! Before working on any electrical wiring, ventilate the engine compartment and disconnect the batteries to prevent sparking.

Never use an open flame in a battery storage area.

Batteries can explode if a spark or flame ignites the free hydrogen given off during charging.

Batteries contain Sulfuric Acid and can cause severe personal injury if mishandled. Avoid contact, flush with water for at least 15 in. If swallowed, drink large quantities of milk of magnesia, beaten egg, or vegetable oil, and get medical attention immediately.

Never reset a breaker that has tripped without first correcting the problem. Electrical system devices can be damaged and be faulty which can cause fire. Always correct the problem causing the tripped breaker before re-energizing.


Alterations or extensions to your electrical system can cause electrical fire or shock.




# Hunter 31

## 12 Volt DC Lighting



EXAMPLE SWITCH PANEL WIRING (PARALLEL CIRCUITS)



EACH CIRCUIT IN PARALLEL, BLUE (LOAD TO BREAKER) AND YELLOW NEGATIVE TO NEGATIVE BUS BAR (SEE EX.)



EXAMPLE LIGHT WIRING (PARALLEL CIRCUIT)



### ⚠ DANGER ⚠

Fuel Fumes in the engine compartment can explode! Before working on any electrical wiring, ventilate the engine compartment and disconnect the batteries to prevent sparking.

Never use an open flame in a battery storage area.

Batteries can explode if a spark or flame ignites the free hydrogen given off during charging.

Batteries contain Sulfuric Acid and can cause severe personal injury if mishandled. Avoid contact, flush with water for at least 15 in. If swallowed, drink large quantities of milk of magnesia, beaten egg, or vegetable oil, and get medical attention immediately.

Never reset a breaker that has tripped without first correcting the problem. Electrical system devices can be damaged and be faulty which can cause fire. Always correct the problem causing the tripped breaker before re-energizing.

Alterations or extensions to your electrical system can cause electrical fire or shock.






# Hunter 31

## 12 Volt DC Deck Lighting

### CAUTION


Always be aware of your surroundings when on the deck. Area's of the deck may be very slippery when wet. This could result in a fall, or a "Man Overboard"!



# Hunter 31

## AC Electric Wire Run Diagram

1. SHORE POWER INLET	6. DC PANEL
2. SHORE POWER BREAKER	7. WATER HEATER
3. AC OUTLET	8. MICROWAVE (OPTIONAL)
4. GFCI OUTLETS	9. ISOLATOR TRANSFORMER
5. AC PANEL	



NOTE: VANITY HEAD OUTLET NOT  
SUPPLIED IN SOME COUNTRIES.

**⚠ DANGER ⚠**

Never work on an energized circuit,  
Always treat any circuit as if it were live!

Electricity cannot be detected without  
specialized test equipment. Never think  
you know whether a circuit is "live",  
always have qualified, competent  
professionals inspect or make repairs to  
your electrical systems.

Always run the blowers for at least  
four minutes before starting any engines.


Internal combustion engines produce  
carbon monoxide, a dangerous,  
poisonous gas. Be sure and  
read the boating safety chapter  
concerning Carbon Monoxide before  
starting any engines.

Alterations or extensions to the electrical  
system can cause electrical shock or fire.  
Only trained, competent, and certified  
electricians should perform any electrical  
maintenance, work, or changes to your  
boats electrical system.



# Hunter 31

## Fresh Water Layout



A WATER TANK	G WATER FILTER	M HOT & COLD LINES TO GALLEY SINK
B TANK VENT HOSE	H WATER PUMP	
C TANK VENT	I HOT & COLD LINES TO HEAD	
D TANK FILL HOSE	J WATER HEATER	
E TANK FILL	K COLD LINE TO WATER HEATER	
F SHUT OFF VALVES	L HOT & COLD LINES TO COCKPIT SHOWER	

ALL WATER LINES ARE 15mm TUBING      TANK VENT HOSE IS 5/8" (16mm)      TANK FILL HOSE IS 1 1/2" (38mm)

### ⚠ WARNING ⚠

Allowing your boat to stay connected to dockside water supply while unattended, could result in a sunken boat.  
A major leak or break in the system could flood the bilges, excess water in the bilges could, flood the batteries and result in your boat sinking.

Before connecting to a dockside water source, make certain the water is suitable for drinking. Water that may be of questionable quality could result in serious illness or death.

Hydrogen gas may form in a water heater if not used. You should always open the valves!  
Do not smoke or use electrical appliances for several minutes before use.

### ⚠ CAUTION ⚠


Make sure that the water heater is full before energizing, bleed off any air by opening the hot water valve, close only when there is a steady flow of water, this will bleed the hot water system of air. Failure to follow these instructions could result in damage to the heating elements in your water heater.





# Hunter 31

## Waste System (Black Water System)



### Save Our Seas

It is illegal to dump plastic trash anywhere into the ocean or navigatable waters of the United States. Violation of these requirements may result in civil penalty up to \$25,000, a fine of \$50,000 and imprisonment for up to five years.

**PLASTIC** - Includes but is not limited to : plastic bags styrofoam cups and lids, sixpack holders, stirrers, synthetic fishing nets, ropes, lines, and bio or photo degradable plastics.

**GARBAGE** - Means paper, rags, glass, metal, crockery (generated in living spaces aboard the vessel-what we normally call trash), and all kinds of food, maintenance and cargo-associated waste "Garbage" does not include fresh fish or fish parts, dishwater and gray water.

#### INSIDE 3 MILES

(and in U.S. Rivers, Bays and Sounds)

#### PLASTICS

DUNNAGE, LINING AND PACKING MATERIALS THAT FLOAT  
ANY GARBAGE EXCEPT DISHWATER  
GRAYWATER, FRESH FISH PARTS

#### 3 TO 12 MILES

#### PLASTICS

DUNNAGE, LINING AND PACKING MATERIALS THAT FLOAT  
ANY GARBAGE NOT GROUND TO LESS THAN ONE SQUARE INCH

#### 12 TO 25 MILES

#### PLASTICS

DUNNAGE, LINING AND PACKING MATERIALS THAT FLOAT

#### 12 TO 25 MILES

#### PLASTICS

**DUNNAGE**-Material used to block and brace cargo, and is considered a cargo associated waste.


**DISHWATER**- Means the liquid residue from the manual or automatic washing of dishes and cooking utensils which have been pre-cleaned to the extent that any food particles adhering to them would normally interfere with the operation of automatic dishwashers.

**GRAYWATER**- Means drainage from a dishwasher, shower, laundry, bath, and washbasin, and does not include drainage from toilets, urinals, hospitals, and cargo spaces.




# Hunter 31

## Waste System (Bilge Water)



# Hunter 31

## Waste System (Optional Sump Water)





# Hunter 31 Exhaust System

**! DANGER !**

Direct exposure to Carbon Monoxide will cause brain damage or death!

Carbon Monoxide is colorless, odorless, and dangerous!


All engines, generators, and open flame appliances produce Carbon Monoxide!

Signs of exposure include  
nausea, dizziness and  
drowsiness!

Avoid blockage of exhausts!


Keep cabin and cockpit well ventilated!

See Owner's / Operator's Manuals for more details!



# Hunter 31


## Standing Rigging



HUNTER 31 CONVENTIONAL STANDING RIGGING						
ITEM	QTY	WIRE SIZE	FITTINGS	CP-CP OR CP- EOS		
1	D3	2	1/4" 6mm	T-TERMINAL 308-324 FORK 308-417	10ft 8 3/4"	3270 mm
2	V2	2	1/4" 6mm	EYE 308-362 EYE 308-362	10ft 6"	3200 mm
3	D2	2	5/32" 4mm	Stemball 308-510-01 Stemball Cups 306-572 +573 STD/FRK TB 174-472-06	10ft 5 1/2"	3190 mm
4	RD2	2	5/32" 4 mm	FORK 308-312-01 STD/T TB 174-472-21	9ft 11 1/2"	3035 mm
5	V1	2	1/4" 6 mm	Fork 308-417 STD/TGLE TB 174-324-09	11ft 8"	3560 mm
6	D1	2	1/4" 6 mm	Stemball 308-512-01 Stemball Cup 306-573 STD/TGLE TB 174-324-09	12ft 2 1/2"	3720 mm
7	RD1	2	5/32" 4 mm	FORK 308-312-01 STD/T TB 174-472-21	8ft 11 1/4"	2725 mm
8	FORESTAY	1	1/4" 6 mm	FURLEX 106-12 OVERALL CP-CP	33ft 3 3/4"	10155 mm
SELDEN MAST SRIG-0120						


HUNTER 31 FURLING STANDING RIGGING						
ITEM	QTY	WIRE SIZE	FITTINGS	CP-CP OR CP-EOS		
1	D3	2	1/4" 6 mm	T-TERMINAL 308-324 FORK 308-417	10ft 7 7/8"	3250 mm
2	V2	2	1/4" 6 mm	EYE 308-362 EYE 308-362	10ft 6 3/4"	3220 mm
3	D2	2	5/32" 4mm	T-TERMINAL 308-322 STD/FRK TB 174-472-05	9ft 8"	2945 mm
4	RD2	2	5/32" 4mm	FORK 308-312-01 STD/T TB 174-472-21	10ft	3050 mm
5	V1	2	1/4" 6 mm	FORK 308-417 STD/TGLE TB 174-324-09	11ft 8 1/4"	3560 mm
6	D1	2	1/4" 6 mm	T-TERMINAL 308-324 STD/TGLE TB 174-324-09	11ft 4 3/4"	3475 mm
7	RD1	2	5/32" 4 mm	FORK 308-312-01 STD/T TB 174-472-21	8ft 11 3/4"	2735 mm
8	FORESTAY	1	1/4" 6 mm	FURLEX 106-12 OVERALL CP-CP	33ft 3 3/4"	10155 mm
SELDEN MAST SRIG-0121						

1. CP = CENTER PIN; EOS = END OF STUD  
2. LENGTHS **DO NOT** INCLUDE SPREADER TIP LINKAGE.  
3. MEASURE T-TERMINALS & STEMBALLS FROM TOP OF FITTING.




V = VERTICAL  
D = DIAGONAL  
RD = REVERSE DIAGONAL

1 = LOWER  
2 = INTER.  
3 = UPPER




# Hunter 31


## Boom and Mainsheet Purchase Layout



ROPE VANG DETAILS (STANDARD)




BOOM WITH REEFING LAYOUT




RIGID VANG (FURLING OPTION)

- 1 ARCH BAIL (MAINSHEET PURCHASE END TIE OFF)
- 2 BOOM BAIL AND MAINSHEET BLOCK
- 3 ARCH MAINSHEET BRIDLE
- 4 MAINSHEET
- 5 MAINSHEET BOOM EXIT
- 6 MAINSHEET RUN INSIDE BOOM
- 7 MAINSHEET SHEAVE INSIDE FWD BOOM END
- 8 MAINSHEET BLOCK AT MAST STEP
- 9 MAINSHEET THRU BLOCK DEFLECTORS
- 10 MAINSHEET THROUGH BLOCK ORGANIZERS TO WINCH




DUEL ENDED MAINSHEET PURCHASE LAYOUT



# Hunter 31


## Running Rigging

### STANDARD RUNNING RIGGING



- 1 OPTIONAL SPINNAKER HALYARD
- 2 JIB HALTARD
- 3 #2 REEF
- 4 #1 REEF
- 5 MAINSHEET
- 6 MAIN HALYARD

### FURLING RUNNING RIGGING



- 1 OPTIONAL SPINNAKER HALYARD
- 2 JIB HALTARD
- 3 FURLING LINE
- 4 FURLING LINE
- 5 OUTHAUL
- 6 MAINSHEET
- 7 MAIN HALYARD

RUNNING RIGGING SPECIFICATIONS									
Boat: HUNTER 31 CONV.									
OPT/STD	ITEM	QTY	Line Size	Line Type	Color	End 1	Length	End 2	
1 STD	MAIN HALYARD	1	10mm (3/8")	32/3 pl	BLUE	307-046 SHACKLE/KNOT		BARE	
2 STD	JIB HALYARD	1	10mm (3/8")	32/3 pl	RED	307-046 SHACKLE/KNOT		BARE	
3 OPT	MAIN TRAVELER LINE	2	8mm (5/16")	16/16pl	WHITE	EYE		BARE	
4 STD	MAINSHEET	1	10mm (3/8")	16/16 pl	BLUE	EYE		BARE	
5 STD	REEFING LINE #1	1	10mm (3/8")	16/16 pl	GREEN	BARE		BARE	
6 STD	REEFING LINE #2	1	10mm (3/8")	16/16 pl	RED	BARE		BARE	
7 STD	JIB SHEET	2	10mm (3/8")	16/16 pl	RED	BARE		BARE	
8 OPT	CRUISING SPINN. SHEET	2	10mm (3/8")	16/16 pl	WHITE	BARE		BARE	
9 OPT	SPINNAKER HALYARD	1	10mm (3/8")	16/16 pl	YELLOW	307-207 SHACKLE/KNOT		BARE	
10 STD	LAZY JACK WIRE	2	4 mm (5/32")	Plastic Covered 7x19	WHITE	307-01 SHACKLE THIMBLE		THIMBLE	
11 STD	FIXED LAZY JACK LINE	2	8mm (5/16")	16/16 pl	WHITE	BARE		BARE	
12 STD	BOOM TOPPING LIFT	1	8mm (5/16")	16/16 pl	WHITE	307-013 SHACKLE/EYE		BARE	
13 STD	OUTHHAUL WIRE	1	4MM (5/32")	7X19 WIRE		THIMBLE		THIMBLE	
14 STD	OH JAM	1	8mm (5/16")	16/16 pl	WHITE	EYE WITH BLOCK 538-136		BARE	


RUNNING RIGGING SPECIFICATIONS									
Boat: HUNTER 31 FURL.									
OPT/STD	ITEM	QTY	Line Size	Line Type	Color	End 1	Length	End 2	
1 STD	MAIN HALYARD	1	10mm (3/8")	Dyneema	B/W	307-020 SHACKLE/EYE	28.1m 92ft	BARE	
2 STD	JIB HALYARD	1	10mm (3/8")	32/3 pl	RED	307-046 SHACKLE/KNOT	24.5m 80ft	BARE	
3 STD	MAIN TRAVELER LINE	2	8mm (5/16")	16/16 pl	WHITE	BARE	7.9m 26ft	BARE	
4 STD	MAINSHEET	1	10mm (3/8")	16/16 pl	BLUE	EYE	17m 56ft	BARE	
5 STD	JIB SHEET	2	12mm(1/2")	16/16 pl	RED	BARE	10.1m 33ft	BARE	
6 OPT	CRUISING SPINN. SHEET	2	10mm (3/8")	16/16 pl	WHITE	BARE	18.2m 60ft	BARE	
7 OPT	SPINNAKER HALYARD	1	10mm (3/8")	16/16 pl	YELLOW	307-207 SHACKLE/KNOT	25m 82ft	BARE	
8 OPT	RODKICKER TACKLE	1	10mm (3/8")	16/16 pl	WHITE	EYE	4m 13ft	BARE	
9 STD	BOOM TOPPING LIFT	1	8mm (5/16")	16/16 pl	WHITE	307-013 SHACKLE/EYE	25m 82ft	BARE	
10 STD	MAINSAIL FURLING LINE	1	10mm (3/8")	16/16 pl	YELLOW	BARE	12m 39ft	BARE	
11 STD	MAINSAIL OUTHAUL	1	10mm (3/8")	16/16 pl	WHITE	EYE	20m 65ft	BARE	






# Hunter 31

## Jib Furling Line Layout




# Hunter 31

## Optional Mainsheet Purchase Traveler Layout



# Hunter 31

## Arch Installation




FOR CLARITY, THE STERNRAILS ARE DEPICTED IN AN EXPLODED VIEW

### ARCH INSTALLATION: NOTES AND TOOL LIST

- NOTES:**
1. **IMPORTANT:** READ ALL OF THE INSTALLATION INSTRUCTIONS THOROUGHLY BEFORE BEGINNING.
  2. THIS JOB REQUIRES TWO PEOPLE. IT IS IMPORTANT THAT THE ARCH IS FIRMLY SUPPORTED UNTIL IT IS FULLY ATTACHED TO THE DECK.
  3. WHEN INSTALLING ARCH: TO AVOID POSSIBLE INJURY, ORIENT THE DIRECTION OF THE ARCH (LEANING FORWARD) PRIOR TO BEGINNING THE INSTALLATION PROCESS.
  4. SEE BELOW FOR A LIST OF TOOLS SUGGESTED FOR THE INSTALLATION PROCESS.
  5. **IMPORTANT:** REMEMBER TO CHECK ALL THE ARCH BOLTS / NUTS AFTER THE INITIAL SEA TRIAL AND RETIGHTEN AS NECESSARY

**SUGGESTED TOOL LIST:**  
DRILL AND 3/8" DRILL BIT (TO CLEAR SEALANT FROM HOLES)  
3/8" DRIVE RATCHET  
6" EXTENSION  
9/16" DEEP & REGULAR SOCKET  
9/16" WRENCH  
SCREW DRIVER-PHILLIPS HEAD (LARGE P-4)  
CAULK GUN  
TUBE OF SEALANT (3M 5200)  
NEVER SEIZE (BOLT LUBE)  
RAZOR KNIFE  
WIRE STRIPPERS/CRIMPS  
RAGS  
ACETONE OR LACQUER THINNER / CLEAN UP

1. REMOVE ALL ACCESSORIES STOWED IN THE COCKPIT LOCKERS. THIS WILL ENABLE EASIER ACCESS WHEN FASTENING THE ARCH BOLTS
2. WITH 3/8" DRILL BIT, REMOVE ANY SEALANT FROM PRE-DRILLED ARCH HOLES.
3. CLEAN AROUND THE MOUNTING HOLES USING ACETONE OR LACQUER THINNER.
4. APPLY A GENEROUS AMOUNT OF 3M 5200 SEALANT AT THE ARCH MOUNTING HOLE LOCATIONS ON THE FOOT DECK.
5. TO AVOID POSSIBLE INJURY, ORIENT THE ARCH (LEANING FORWARD) PRIOR TO PLACING IT ON THE BOAT.
6. BEFORE PLACING ARCH ONTO ARCH PADS, ALIGN STERNRAIL PIPES WITH RECEIVER CUPS ON ARCH AND JOIN. DO NOT BOLT UNTIL OTHER COMPONENTS ARE IN PLACE.
7. PLACE THE ARCH ON THE DECK OF THE BOAT. ALIGN THE ARCH FOOT HOLES ON ONE SIDE( EITHER PORT OR STARBOARD ) WITH THE CORRESPONDING PRE DRILLED DECK HOLES.
8. INSERT 3/8"(9.5mm) STAINLESS STEEL BOLTS THRU ALL HOLES IN ARCH FOOT AND INTO THE COAMING.
9. REPEAT STEP 8 WITH OTHER ARCH FOOT.
10. ACCESS THE UNDERSIDES OF THE DECK AT THE ARCH FOOT LOCATIONS AS FOLLOWS:  
STBD : THRU STARBOARD SIDE GULLWING LOCKER  
PORT: THRU PORT SIDE GULLWING LOCKER
11. INSTALL THE 1/8" (3.2mm) FENDER WASHERS ON THE INSIDE OF THE COAMING AND INSTALL LOCK WASHER AND S.S. NUT ON THE BOLT WHICH HAS BEEN INSERTED. TIGHTEN BOLT COMPLETELY. (IT IS IMPORTANT TO APPLY A SMALL AMOUNT OF NEVER SEIZE TO THE BOLT TO PREVENT "GAULING" OF THE THREADS.)
12. BE SURE TO INSTALL THE ARCH GROUNDING WIRE, LOCATED IN THE STARBOARD GULLWING LOCKER.
13. RECHECK THE ARCH FIT ONTO THE DECK. THE HEIGHT SHOULD MEASURE AT LEAST 6' 2" (1.88)
14. SECURELY TIGHTEN ALL THE NUTS AND BOLTS USING A CROSS TIGHTENING PATTERN. (DO NOT FORGET TO USE A SMALL AMOUNT OF LUBRICANT FOR THE BOLTS).
15. CLEAN EXCESS SEALANT FROM AROUND THE ARCH FEET AND COAMING AREAS USING ACETONE OR LACQUER THINNER..
16. RECHECK THE BOLTS AFTER THE INITIAL SEA TRIAL AND TIGHTEN AS NECESSARY.
17. AFTER ARCH IS SECURE, BOLT STERNRAIL FEET TO ARCH CUPS.




# Hunter 31

## Lazyjack Installation

1. LAZYJACK WIRE ATTACHED @UPPER SPREADER
2. LAZYJACK UPPER FIXED CABLE
3. THIMBLE OR BLOCK ON FIXED CABLE
4. 1/4" (6mm) LAZYJACK LINE (THRU THIMBLE / BLOCK)
5. AFT BAIL (SECURE L.J. LINE END)
6. FWD LAZYJACK BAIL

**NOTE: STBD. SIDE SHOWN, PORT SIDE LAZY JACKS ARE RAN THE SAME WAY.**




**SLIDE THE BOLTROPE INTO BOOM TRACK①. START FROM THE AFT END AND MAKE YOUR WAY FORWARD.**

**INSTALL THE PVC BATTENS② INTO EACH HALF OF THE SAIL COVER. THERE ARE POCKETS③ THAT OPEN TOWARDS THE FRONT, ON THE INSIDE OF THE COVER. SLIDE THE BATTENS INTO PLACE FROM THE FRONT, AND ROLL THE INSIDE LIP OF THE POCKET BACK IN ORDER TO HOLD THE BATTENS STATIONARY.**

**FEED THE LAZYJACK LINES ④ TO THE SAIL COVER ⑤ AND DEAD END THE LINES TO THE FWD AND AFT BAILS ⑥ ON THE SAIL COVER.**


**TIE THE AFT END OF THE SAIL COVER UP TO THE TOPPING LIFT LINE USING THE PIECE OF STRING PROVIDED⑦. USE HALF HITCH KNOTS TO SECURE THE COVER IN PLACE AT THE OUTER END OF THE BOOM. THE REEF LINES RUN OUT THROUGH THE COVER SLOTS⑧AND TIE OFF.**





# Hunter 31


## Optional Spinnaker Layout




# Hunter 31

## Lifting Points


Lifting Points with Propeller



- A AFT LIFTING POINT (INDICATED BY DECAL)  
PLACEMENT IS ALIGNED WITH INTERIOR  
STRUCTURAL SUPPORT PROVIDED BY  
BULKHEADS. ALSO BE SURE YOU ARE WELL  
FORWARD OF PROP SHAFT.
- B FWD LIFTING POINT (INDICATED BY DECAL)  
PLACEMENT IS FWD OF CHAINPLATE SO AS  
TO ALIGN WITH INTERIOR STRUCTURAL  
SUPPORT PROVIDED BY FWD SALON  
BULKHEAD.



Lifting Points with Saildrive



- A AFT LIFTING POINT (INDICATED BY DECAL).  
BE SURE YOU ARE WELL AFT OFF FOOT OF ENGINE.
- B FWD LIFTING POINT (INDICATED BY DECAL)  
PLACEMENT IS FWD OF CHAINPLATE SO AS  
TO ALIGN WITH INTERIOR STRUCTURAL  
SUPPORT PROVIDED BY FWD SALON  
BULKHEAD.

