

LEGEND 43 OWNER'S MANUAL TABLE OF CONTENTS

IV. ELECTRONICS

A.	Marine Shore Power Cable Set Instruction Sheet
B.	Autohelm ST-50 Speed Installation and Operations
C.	Autohelm ST-50 Depth Installation and Operations
D.	VHF (Owner's Manual
E.	Sound System Owner's Manual
F.	Battery Charger Owner's Manual
G.	Sea Power Multi Battery Isolator
H.	Solar Battery Charger

V. GALLEY/HEAD SYSTEMS

A.	Water Systems Operation
B.	SeaWard CNG Stove Instructions
C.	SeaWard Electric Water Heater Instructions
D.	Manual Marine Toilet
E.	Self-priming Mincerator Pump
F.	Automatic Water System Pump
G.	The Cold Machine - Installation & Operating Manual
H.	Grohe Faucets - Specialty, Kitchen & Bar, Centerset.

VI. SPECIFICATIONS & TECHNICAL INFORMATION

A.	Legend 43 Deck Plan - dwg. #H43A2628
B.	Legend 43 Interior Plan - dwg. #H43A2631
C.	Legend Thru-hull Location dwg. #H43A2643
D.	Legend 42 Water Supply System #H43A2629
E.	Legend 43 Waste System - dwg. #H43A2630
F.	Legend 43 Auto Bridge Pump Layout - dwg. #GHRNA2613
G.	Legend 43 Engine System - dwg. #H43A2632
H.	Pumps, Swainers, & Filters
I.	Legend 43 Pan Electrical System - dwg. H43A2614
J.	Legend 43 Headliner 110 Volt System - dwg. #H43A2633
K.	Legend 43 Solar Panel Instructions - dwg. #H43A2623
L.	Legend 43 12 Volt System - dwg. #H43A2633
M.	Legend 43 Light Bulb Specifications

LEGEND #3 OWNER'S MANUAL TABLE OF CONTENTS

VII. MAINTENANCE

- A. Inspections For Preparation For Bottom Painting
- B. Teak Care
- C. Maintenance

- 1. Engine, Transmission & DriveShaft
- 2. Steering

- 3. Electrical Systems

- 4. Plumbing Systems

- 5. Fuel Systems

- 6. General Care

- 7. Fabric Care

- 8. Winch Maintenance

- 9. General Hardware Maintenance

- D. Electrolysis & Galvanic Protection

- E. Alignment Procedures

- F. Alignment Diagram - dwg. #GTNA2619

- G. Storage & Winterization (2 pages)

- H. Vipelex Acrylics Care & Cleaning

- I. Corian® Care & Cleaning

- J. Edson Pectral Maintenance Centre

- K. Marine Rigging

- L. Burtens Service Manual #3

- M. Morse Marine Products - Owner's Manual

VIII. GENERAL INFORMATION & WARRANTY CARDS

- A. Edson International Registration Card

- B. UK Sailmakers/Warranty Registration Card

- C. Hunter Marine Limited Warranty

- D. Hunter Hive Year Bottom Blister Limited Warranty

- E. Compass Warranty & Information

- F. Tantal Spars

- G. Sovolcs Solar Systems Warranty

- H. Battery Information to be added by Dealer

- I. Seward Product Information & Warranty

LEGEND 43 OWNER'S MANUAL TABLE OF CONTENTS

General Information & Warranty Card (Continued)

- J. Racor Fuel Filter Information
- K. Globe America Limited Warranty
- 1. Specialty Faucet
- 2. Kitchen & Bar
- 3. Center Set
- L. Petko Water Strainer & Warranty Card
- M. Ross Rudder Information
- N. Lowmar Port Light
- O. Sump Pump
- P. Bilge Pump
- Q. Manual Bilge Pump (W/ke)

IX. BOATING SAFETY

- A. Coast Guard Auxiliary Public Education
- B. Courtesy Marine Examination
- C. Federal Requirements for Recreational Boats
- D. ASA Pamphlet
- E. Boating Basics - Blueprint For Safe Boating
- F. Visual Distress Signals for Recreational Boats
- G. Getting Help on the Water
- H. Tips for Safe Boating

X. ENGINE INFORMATION & WARRANTY

- A. Yanmar Owner's Manual - (4M1Z)
- B. Yanmar Warranty Card
- C. Mack Boring Bulletin
- D. Yanmar On-Board Spare Parts Kit
- E. Yanmar Diesel Engine Delivery Report

HUNTER MARINE'S OWNER AND FOUNDER WARREN R. LUHRS BRIEF HISTORY

Born in 1944 in East Orange, New Jersey, Warren R. Luhrs' ancestry goes back to his Great-grandfather, Henry, who helped pioneer railroad and clipper ships in America, and to his great-uncle, John, who helped build the famous St. Petersburg-to-Moscow railroad for Czar Alexander II.

Henry Luhrs owned shares in twenty-two different ocean-going vessels - barks, brigs and schooners - and was principal owner of the bark, "Sophia R. Luhrs", named after his wife. He was also a partner with Albert Sprout, who managed a shipyard in Melbridge, Maine, where the "Sophia R. Luhrs" was built.

The Luhrs' family sea tradition was carried on during the Great Depression by Warren Luhrs' father, Henry, who worked at a small boat manufacturer in Morgan, New Jersey, and later started his own company. When war broke out in Europe, the Coast Guard asked Henry Luhrs to repair their boats and install ice sheathing on their bows.

After World War II, Henry built 27-foot fishing boats and in 1948 began to construct custom-built pleasure craft. He then turned to skiffs and in 1952 incorporated as Henry Luhrs Sea Skiffs. He constructed lap strake sea skiffs using assembly-line techniques. Henry personally "shook down" his prototypes with family tips up the Hudson River to Lake Champlain.

The sea skiff is a class of boat which has been very popular, owing to its seaworthiness. It features a sharp bow, which reduces pounding in surf or choppy seas, and a hull whose forward section is rounded below the water line to increase stability in rough water or a following sea. Such skiffs can either be smooth-sided or of lapstrake construction.

Henry Luhrs' basic philosophy was to emulate the late Henry Ford in building an inexpensive boat for the average man, thus enabling him to enjoy the luxury of boating. He was both designer and engineer, creating innovative and progressive new models. He designed the change in the line of the bow from straight to curved at a time when all boats were being built with the straight square effect. It is believed he was also the first designer-builder to popularize a small boat with a fly-bridge.

In 1960, Luhrs acquired the Ulrichsen Boat Company, Marlboro, New Jersey. It was here, too, that the Luhrs' Alura Fiberglass Division was located. In 1965, Henry sold his company to Bangor-Arrestook Railroad, which was to become the recreational conglomerate, Bangor-Funta. It was also during this period that Silverton of Tom's River, New Jersey was purchased by John and Warren Luhrs.

Today, Warren R. Luhrs and his brother John, own Hunter Marine Corporation, Silverton Marine Corporation, Mainship Motor Yachts and Luhrs Fishing Boats with its Alura Division. Hunter Marine produces sailboats while the other companies produce powerboats.

Welcome To THE HUNTER MARINE FAMILY

Congratulations on your new sailing yacht manufactured by Hunter Marine. We have engineered and constructed your boat to be as fine a yacht as any afloat. In order to get the best performance and most enjoyment from your boat you should be familiar with its various elements and functions. Please take the time to study this manual and its recommendations for trouble-free sailing pleasure.

We stand behind the quality of your boat with a warranty which you should also review. *To insure your warranty is valid, please fill out the attached card and send it to us within ten (10) days of the purchase date.* Section 15 of the Federal Boat Safety Act requires first owners to be registered. The warranty data should also be recorded in the space below for your own reference.

You also need to fill out and mail the warranty cards on your diesel auxiliary, battery, stove, head, electric water pump and other accessories. These are enclosed in the manufacturers' manuals which are included in your owner's pouch.

OWNER INFORMATION CARD

HULL IDENTIFICATION NUMBER IS ON THE STARBOARD AFT SIDE OF THE HULL OR TRANSON
THIS NUMBER MUST BE GIVEN IN ALL NECESSARY COMMUNICATIONS.

HULL NO. _____ DATE DELIVERED TO OWNER _____

YACHT NAME _____

OWNER NAME _____

STREET ADDRESS _____

CITY _____ STATE _____ ZIP CODE _____

HOME PORT _____

MODEL _____ SIZE _____ HULL/KEEL * _____

ENGINE MODEL _____ SERIAL NO. _____ PROPELLER SIZE _____

DEALER _____

STREET ADDRESS _____

CITY _____ STATE _____ ZIP CODE _____

DEALER SIGNATURE _____

OWNER SIGNATURE _____

A copy of Chapman's *Pleating, Seamanship and Small Boat Handling* is provided with your Hunter Marine boat as part of the standard equipment. Any questions regarding the meaning of terminology used in this manual may be referenced in your Chapman's.

GLOSSARY OF SAILING TERMS

Terms which are referred to in the text without a full explanation are included in the glossary. Some other terms which are clearly defined in the book are not included.

A
Aback: describes a sail when the wind strikes it on its lee side.
Abate: towards the boats stem.
Abeam: at right angles to the center-line of the boat.
Aft: at or near the stern.
Aids: the center of beam means that an object is at right angles to the center-line.
Antifouling: a poisonous paint compound used to protect the underwater part of a hull from marine growths.
Apparent wind: the direction and speed of the wind felt by the crew. It is a combination of true wind and that created by the movement of the boat.
Astern: behind the boat to go astern is to drive the boat in reverse.
Awbarships: at right angles to the fore-and-aft line of the boat.

B
Back: when a wind backs, it shifts anticlockwise.
Back a sail: to sheet it to windward so that the wind fills on the side that is normally to leeward.
Backstay: a stay that supports the mast from aft and prevents its forward movement.
Baggywinkle: rope, leased out, plied together and wound around stays, shrouds etc., to prevent chafing.
Ballast: extra weight, usually lead or iron, placed low in the boat or externally on the keel to provide stability. Ballast keel: a mass of ballast bolted to the keel to increase stability and prevent a keel boat from capsizing.
Balm: a light flexible strip, sailing between a beam reach and a run, when the wind blows over the quarter.
Bulkhead: partition wall in a boat normally fitted athwartships.
C
Catamaran: a sailing boat with twin hulls, connected by crossbeams, developed from Polynesian craft.
Calboat: a boat with a single sail.
Caulk: to make the seams between wooden planks watertight by filling with cotton, oakum or a compound.
Cavitation: the formation of a vacuum around a propeller, causing loss in efficiency.
Center-board: a board lowered through a slot in the keel to reduce leeway.
Center-line: center of the boat in a fore and aft line.
Center-tine: center of the moor a boat, 3, a sleeping place on board.
Bight: a bend or loop in a rope.
Blige: the lower, round part inside the hull where water collects.
Block: a pulley in a wooden or plastic case, consisting of a sheave around which a rope runs. It is used to change the direction of pull.
Boot-topping: a narrow coloured stripe painted between the bottom paint and the topside enamel.

Boltscrew: see Rigging screw.
Broach: when a boat running downwind slews broadside to the wind and heels dangerously. It is caused by heavy following seas or helm's error.
Broad reach: the point of sailing between a beam reach and a run, when the wind blows over the quarter.
Bulkhead: partition wall in a boat normally fitted athwartships.
Calboat: a boat with a single sail.
Caulk: to make the seams between wooden planks watertight by filling with cotton, oakum or a compound.
Cavitation: the formation of a vacuum around a propeller, causing loss in efficiency.
Center-board: a board lowered through a slot in the keel to reduce leeway.
Center-line: center of the boat in a fore and aft line.
Center-tine: center of the moor a boat, 3, a sleeping place on board.
Bight: a bend or loop in a rope.
Blige: the lower, round part inside the hull where water collects.
Block: a pulley in a wooden or plastic case, consisting of a sheave around which a rope runs. It is used to change the direction of pull.
Boot-topping: a narrow coloured stripe painted between the bottom paint and the topside enamel.

Boltscrew: see Rigging screw.
Broach: when a boat running downwind slews broadside to the wind and heels dangerously. It is caused by heavy following seas or helm's error.
Broad reach: the point of sailing between a beam reach and a run, when the wind blows over the quarter.
Bulkhead: partition wall in a boat normally fitted athwartships.
Calboat: a boat with a single sail.
Caulk: to make the seams between wooden planks watertight by filling with cotton, oakum or a compound.
Cavitation: the formation of a vacuum around a propeller, causing loss in efficiency.
Center-board: a board lowered through a slot in the keel to reduce leeway.
Center-line: center of the boat in a fore and aft line.
Center-tine: center of the moor a boat, 3, a sleeping place on board.
Bight: a bend or loop in a rope.
Blige: the lower, round part inside the hull where water collects.
Block: a pulley in a wooden or plastic case, consisting of a sheave around which a rope runs. It is used to change the direction of pull.
Boot-topping: a narrow coloured stripe painted between the bottom paint and the topside enamel.

Boltscrew: see Rigging screw.
Broach: when a boat running downwind slews broadside to the wind and heels dangerously. It is caused by heavy following seas or helm's error.
Broad reach: the point of sailing between a beam reach and a run, when the wind blows over the quarter.
Bulkhead: partition wall in a boat normally fitted athwartships.
Calboat: a boat with a single sail.
Caulk: to make the seams between wooden planks watertight by filling with cotton, oakum or a compound.
Cavitation: the formation of a vacuum around a propeller, causing loss in efficiency.
Center-board: a board lowered through a slot in the keel to reduce leeway.
Center-line: center of the boat in a fore and aft line.
Center-tine: center of the moor a boat, 3, a sleeping place on board.
Bight: a bend or loop in a rope.
Blige: the lower, round part inside the hull where water collects.
Block: a pulley in a wooden or plastic case, consisting of a sheave around which a rope runs. It is used to change the direction of pull.
Boot-topping: a narrow coloured stripe painted between the bottom paint and the topside enamel.

Boltscrew: see Rigging screw.
Broach: when a boat running downwind slews broadside to the wind and heels dangerously. It is caused by heavy following seas or helm's error.
Broad reach: the point of sailing between a beam reach and a run, when the wind blows over the quarter.
Bulkhead: partition wall in a boat normally fitted athwartships.
Calboat: a boat with a single sail.
Caulk: to make the seams between wooden planks watertight by filling with cotton, oakum or a compound.
Cavitation: the formation of a vacuum around a propeller, causing loss in efficiency.
Center-board: a board lowered through a slot in the keel to reduce leeway.
Center-line: center of the boat in a fore and aft line.
Center-tine: center of the moor a boat, 3, a sleeping place on board.
Bight: a bend or loop in a rope.
Blige: the lower, round part inside the hull where water collects.
Block: a pulley in a wooden or plastic case, consisting of a sheave around which a rope runs. It is used to change the direction of pull.
Boot-topping: a narrow coloured stripe painted between the bottom paint and the topside enamel.

GLOSSARY OF SAILING TERMS

Chart datum: reference level on a chart below which the tide is unlikely to fall. Soundings are given below chart datum. The datum level varies according to country and area.

Chine: the line where the bottom of the hull meets the side at an angle.

Claw ring: a fitting, which slips over the boom like a claw, to which the main sheet is attached after reefing the mainsail.

Cleat: a wooden, metal or plastic fitting around which a rope is secured.

Clevis pin: a locking pin through which a split ring is passed to prevent accidental withdrawal.

Clew: the after, lower corner of a sail where the foot and leech meet.

Close-hauled: the point of sailing closest to the wind; see also *beat*.

Close reach: the point of sailing between close-hauled and a beam reach, when the wind blows forward of the beam.

Close-winded: describes a boat able to sail very close to the wind.

Coamings: the raised structure surrounding a hatch, cockpit etc., which prevents water entering.

Contra: a trail of condensation left behind a jet aircraft, giving weather clues.

Cotter pin: soft, metal pin folded back on itself to form an eye.

Course: the direction in which a vessel is steered, usually given in degrees; true, magnetic or compass.

Cringle: 1, a rope loop, found at either end of a line of reef points; 2, an eye in a sail.

D

Dead run: running with the wind blowing exactly aft, in line with the center-line.

Deviation: the difference between the direction indicated by the compass needle and the magnetic meridian; caused by object aboard.

Displacement: 1, the weight of water displaced by a boat is equal to the weight of the boat; 2, a displacement hull is one that displaces its own weight in water and is only supported by buoyancy, as opposed to a planing hull which can exceed its hull, or displacement, speed.

Downhaul: a rope fitted to pull down a sail or spar.

Drift: the vertical distance from the waterline to the lowest point of the keel.

Drag: 1, an anchor drags when it fails to hold; 2, the force of wind on the sails, which impedes the boat's progress.

Drift: 1, to float with the current or wind; 2, US the speed of a current (rate UK); 3, UK: the distance a boat is carried by a current in a given time.

Drop keel: a retractable keel which can be drawn into the hull, when entering shallow waters and recovering on to a trailer.

E

Eye of the wind: direction from which the true wind blows.

F

Fair: a well-faired line or surface is smooth with no bumps, hollows or abrupt changes in direction.

Fairlead: a fitting through which a line is run to alter the direction of the lead of the line.

Fathom: the measurement used for depths of water and lengths of rope. 1 fathom=6ft=1.83m.

Fid: a tapered tool used for splitting heavy rope and for sail-making, often hollow.

Fiddle: a raised border for a cabin table, chart table etc. to prevent objects falling off when the boat heels.

Fix: the position of the vessel as plotted from two or more position lines.

Forestay: the foremost stay, running from the masthead to the stemhead, to which the headsail is hanked.

Freeboard: vertical distance between the waterline and the top of the deck.

G

Genoa: a large headsail, in various sizes, which overlaps the mainsail and is hoisted in light to fresh winds on all points of sailing.

Gimbals: two concentric rings, pivoted at right angles which keep objects horizontal despite the boat's motion; e.g. compass and cooker.

Go about: to turn the boat through the eye of the wind to change tack.

Gooseneck: the fitting attaching the boom to the mast, allowing it to move in all directions.

GLOSSARY OF SAILING TERMS

- Lee shore:** a shore on to which the wind is blowing.
- Leeward:** away from the wind; the direction to which the wind blows.
- Leeway:** the sideways movement of a boat off its course as a result of the wind blowing on one side of the sails.
- Let fly:** to let a sheet go instantly, spilling the wind from the sails.
- Lifeline:** a wire or rope rigged around the deck to prevent the crew falling overboard.
- Lumber holes:** gaps left at the lower end of frames above the keel to allow water to drain to the lowest point of the bilges.
- List:** a boat's more or less permanent lean to one side, owing to the improper distribution of weight, e.g., *hull-fast* or water.
- Log:** 1, an instrument for measuring a boat's speed and distance travelled through the water; 2, to record in a book the details of a voyage, usually distances covered and weather.
- Luff:** the forward edge of a sail. To luff up is to turn the boat's head right into the wind.
- Luff groove:** a groove in a wooden or metal spar into which the luff of the headsail is fed.
- Lurch:** the sudden rolling of a boat.
- M**
- Marlin spike:** a pointed steel or wooden spike used to open up the strands of rope or wire then splicing.
- Mast Step:** the socket in which the base of the mast is located.
- Heaving line:** a light line suitable for throwing ashore.
- Heel:** to lean over to one side.
- Goosewing:** to boom-out the headsail to windward on a run by using a whisker pole to hold the sail on the opposite side to the main-sail.
- Ground tackle:** general term used for anchoring gear.
- Guard rail:** a metal rail fitted around the boat to prevent the crew falling overboard.
- Gudgeon:** a rudder fitting. It is the eye into which the pintle fits.
- Guy:** a steadying rope for a spool; a spinnaker guy controls the fore-and-aft position of the spinnaker pole; the foreguy holds the spinnaker pole forward and down.
- Gybe:** to change from one tack to another by turning the stern through the wind.
- H**
- Halyard:** rope used to hoist and lower sails.
- Hank:** fitting used to attach the luff of a sail to a ring.
- Hatch:** an opening in the deck giving access to the interior.
- Have pipe:** see Navel pipe.
- Head-to-wind:** when the bows are pointing right into the wind.
- Headsail:** a streamlined sail surrounded to a foresay, with a groove into which a headsail luff slides.
- Heads:** the toilet.
- Headway:** the forward movement of a boat through the water.
- Heave-to:** to back the jib and lash the tiller to leeward; used in heavy weather to encourage the boat to lie quietly and to reduce headway.
- Heaving line:** a light line suitable for throwing ashore.
- Heel:** to lean over to one side.
- Heaving line:** a light line suitable for throwing ashore.
- Heel:** to lean over to one side.
- Goosewing:** to boom-out the headsail to windward on a run by using a whisker pole to hold the sail on the opposite side to the main-sail.
- Ground tackle:** general term used for anchoring gear.
- Guard rail:** a metal rail fitted around the boat to prevent the crew falling overboard.
- Gudgeon:** a rudder fitting. It is the eye into which the pintle fits.
- Guy:** a steadying rope for a spool; a spinnaker guy controls the fore-and-aft position of the spinnaker pole; the foreguy holds the spinnaker pole forward and down.
- Gybe:** to change from one tack to another by turning the stern through the wind.
- H**
- Halyard:** rope used to hoist and lower sails.
- Hank:** fitting used to attach the luff of a sail to a ring.
- Hatch:** an opening in the deck giving access to the interior.
- Have pipe:** see Navel pipe.
- Head-to-wind:** when the bows are pointing right into the wind.
- Headsail:** a streamlined sail surrounded to a foresay, with a groove into which a headsail luff slides.
- Heads:** the toilet.
- Headway:** the forward movement of a boat through the water.
- Heave-to:** to back the jib and lash the tiller to leeward; used in heavy weather to encourage the boat to lie quietly and to reduce headway.
- Heaving line:** a light line suitable for throwing ashore.
- Heel:** to lean over to one side.
- Heaving line:** a light line suitable for throwing ashore.
- Heel:** to lean over to one side.
- Keel:** the main backbone of the boat to which a ballast keel is bolted or through which the center-board passes.
- Keel:** a two-masted sailing vessel with a *mizzen* mast slightly smaller than the main and stepped forward of the rudder stock/post.
- Kicking strap:** a line used to pull the boom down, to keep it horizontal, particularly on a reach or run.
- L**
- Lanyard:** a short line attached to one object, such as a knife, with which it is secured to another.
- Leech:** 1, the after edge of a triangular sail; 2, both side edges of a square sail.
- Leehelm:** the tendency of a boat to *heave away* from the wind.
- Leeward:** away from the wind; the direction to which the wind blows.
- Leeway:** the sideways movement of a boat off its course as a result of the wind blowing on one side of the sails.
- Let fly:** to let a sheet go instantly, spilling the wind from the sails.
- Lifeline:** a wire or rope rigged around the deck to prevent the crew falling overboard.
- Lumber holes:** gaps left at the lower end of frames above the keel to allow water to drain to the lowest point of the bilges.
- List:** a boat's more or less permanent lean to one side, owing to the improper distribution of weight, e.g., *hull-fast* or water.
- Log:** 1, an instrument for measuring a boat's speed and distance travelled through the water; 2, to record in a book the details of a voyage, usually distances covered and weather.
- Luff:** the forward edge of a sail. To luff up is to turn the boat's head right into the wind.
- Luff groove:** a groove in a wooden or metal spar into which the luff of the headsail is fed.
- Lurch:** the sudden rolling of a boat.
- M**
- Marlin spike:** a pointed steel or wooden spike used to open up the strands of rope or wire then splicing.
- Mast Step:** the socket in which the base of the mast is located.
- Heaving line:** a light line suitable for throwing ashore.
- Heel:** to lean over to one side.
- Heaving line:** a light line suitable for throwing ashore.
- Heel:** to lean over to one side.
- Goosewing:** to boom-out the headsail to windward on a run by using a whisker pole to hold the sail on the opposite side to the main-sail.
- Ground tackle:** general term used for anchoring gear.
- Guard rail:** a metal rail fitted around the boat to prevent the crew falling overboard.
- Gudgeon:** a rudder fitting. It is the eye into which the pintle fits.
- Guy:** a steadying rope for a spool; a spinnaker guy controls the fore-and-aft position of the spinnaker pole; the foreguy holds the spinnaker pole forward and down.
- Gybe:** to change from one tack to another by turning the stern through the wind.
- H**
- Halyard:** rope used to hoist and lower sails.
- Hank:** fitting used to attach the luff of a sail to a ring.
- Hatch:** an opening in the deck giving access to the interior.
- Have pipe:** see Navel pipe.
- Head-to-wind:** when the bows are pointing right into the wind.
- Headsail:** a streamlined sail surrounded to a foresay, with a groove into which a headsail luff slides.
- Heads:** the toilet.
- Headway:** the forward movement of a boat through the water.
- Heave-to:** to back the jib and lash the tiller to leeward; used in heavy weather to encourage the boat to lie quietly and to reduce headway.
- Heaving line:** a light line suitable for throwing ashore.
- Heel:** to lean over to one side.
- Heaving line:** a light line suitable for throwing ashore.
- Heel:** to lean over to one side.

GLOSSARY OF SAILING

- Measured mile:** a distance of one nautical mile measured between buoys or *transits* ashore, and marked on the chart.
- Member:** a part of the skeleton of the hull, such as a *stringer* laminated into a fiberglass hull to strengthen it.
- Meridian:** an imaginary line encircling the Earth which passes through the poles and cuts at right angles through the Equator. All lines of longitude are meridians.
- Mizzen:** 1, the shorter, after-mast on a *ketch* or *yawl*; 2, the fore-and-aft sail set on this mast.
- N**
- Navel pipe:** a metal pipe in the foredeck through which the anchor chain passes to the locker below.
- Noon sight:** a vessel's latitude can be found, using a sextant, when a heavenly body on the observer's meridian is at its greatest altitude. The sight of the sun at noon is the one most frequently taken.
- O**
- Off the wind:** with the *cheer* stacked off, not *close-hauled*.
- On the wind:** *close hauled*.
- Outhaul:** a rope used to pull out the foot of a sail.
- Overall length (LOA):** the boat mid-way between the stern and the beam, on the quarter means about 45 degrees *abft* the beam.
- P**
- Painter:** the bow line by which a dinghy, or *tender*, is towed or made fast.
- Pay out:** to let a rope out gradually.
- Plinle:** a rudder fitting with a long pin which slips into the *gudgeon* to form a hinged pivot for the rudder.
- Pitch:** 1, the up and down motion of the bows of a boat plunging over the waves, 2, the angle of the propeller blades.
- Point of sailing:** the different angles from the wind on which a boat may sail; the boat's *course* relative to the direction of the wind.
- Port:** the left-hand side of a boat, looking forward (opp. of *starboard*).
- Port tack:** a boat is on a port tack when the wind strikes the port side first and the mainsail is out to *starboard*. A boat on the port tack gives way to a boat on a *starboard* tack.
- Position line/line of position:** a line drawn on a chart, as a result of taking a *bearing*, along which the boat's position must lie. Two position lines give a *fix*.
- Puppit:** a metal guard rail fitted at the bows of a boat to provide safety for the crew.
- Pushpit:** a metal guard rail fitted at the stern.
- Q**
- Quarter:** the portion of the boat mid-way between the stern and the beam, on the quarter means about 45 degrees *abft* the beam.
- R**
- Rake:** the fore-and-aft deviation from the perpendicular of a mast or other feature of a boat.
- Range:** 1, see *Transit*; 2, of tides, the difference between the high- and low-water levels of a *tide*; 3, the distance at which a light can be seen.
- Rating:** a method of measuring certain dimensions of a yacht to enable it to take part in handicap races.
- Reach:** to sail with the wind approximately on the *beam*; all sailing points between running and *close-hauled*.
- Keel:** to reduce the sail area by folding or rolling surplus material on the boom or *forestay*.
- Keeling pennant:** strong line with which the *luff* or leech *cringle* is pulled down to the boom when reefing.
- Rhumb line:** a line cutting all meridians at the same angle; the *course* followed by a boat sailing in a fixed direction.
- Riding light or anchor light:** an all-round white light, usually hoisted on the *forestay*, to show that a boat under 50 ft (15 m) is at anchor. It must be visible for 2 miles (3 km).
- Riding sail:** a small sail hoisted to enable a boat to maintain *steerage way* during a storm.
- Rigging screw:** a deck fitting with which the tension of *standing rigging*, e.g. *stays*, *shrouds*, is adjusted.
- Roach:** the curved part of the leech of a sail which extends beyond the direct line from head to *clew*.
- Run:** to sail with the wind *aft* and with the *sheets* eased well out.
- Running rigging:** all the moving lines, such as *sheets* and *halyards*, used in the *setting* and *trimming* of sails.

GLOSSARY OF SAILING TERMS

S

Sailmaker's palm: a strong leather protective loop which fits across the palm of the hand. It has a hole for the thumb and metal reinforced plate on the palm to accept the eye of a needle, and is worn when mending sails or splicing ropes.

Schooner: a boat with two or more masts, with the mainmast aftermost.

Scope: the length of rope or cable paid out when mooring or anchoring.

Scuppers; holes in the *sole* *raff* which allow water to drain off the deck.

Seacock: a valve which shuts off an underwater inlet or outlet passing through the hull.

Sea room: room in which a boat can manoeuvre, clear of land or dangers.

Seize: to bind two ropes together, or a rope to a spar with a light line.

Sever: to cover and protect a splice or part of a rope with twice bound tightly against the lay.

Serving mallet: tool with a grooved head, used when serving a rope to keep the twine at a constant and high tension.

Set: 1, to hoist a sail; 2, the way in which the sails fit; 3, the direction of tidal current or stream.

Shackle: a metal link with a removable bolt across the open end, of various shapes: D, U.

Sheave: a grooved wheel in a block or spar for a rope to run on.

Sheet: the rope attached to the clew of a sail or to the boom, enabling it to be controlled or trimmed.

Shrouds: ropes or wires, usually in pairs, led from the mast to *chain plates* at deck level to prevent the mast falling sideways; part of the standing rigging.

Sloop: a single-masted sailing boat with a mainsail and one headsail.

Spar: a general term for any wood or metal pole, e.g., mast or boom, used to carry or give shape to sails.

Spindrift: spray blown along the surface of the sea.

Spinnaker: a large, light, balloon-shaped sail set when reaching or running.

Splice: to join ropes or wires by unlaying the strands and interweaving them.

Split pin: see *Cotter pin*.

Spreaders: horizontal spars attached to the mast, which extend to support the mast help to support the mast.

Stall: a sail stalls when the airflow over it breaks up, causing the boat to lose way.

Stanchion: upright metal post bolted to the deck to support *guard rails* or *lifelines*.

Standing part: the part of a line not used when making a knot, the part of a rope which is made fast, or around which the knot is led.

Standing rigging: the shrouds and stays which are permanently set up and support the masts.

Starboard: right-hand side of a boat looking forward (opp. of port).

Starboard tack: a boat is on the starboard tack when the wind strikes the starboard side first and the boom is out to port.

Stay: wire or rope which supports the mast in a fore-and-aft direction; part of the standing rigging.

Steerage way: a boat has sufficient speed to allow it to be steered, or to answer the helm.

Stem: the timber at the bow, from the keel upwards, to which the planking is attached.

Sternway: the backward, stem-first movement of a boat.

Stringer: a fore-and-aft member, fitted to strengthen the frames.

Tack: 1, the lower forward corner of a sail; 2, to turn the boat through the wind so that it blows on the opposite side of the sails.

Tacking: working to windward by sailing *close-hauled* on alternate courses so that the wind is first on one side of the boat, then on the other.

Tack pennant: a length of wire with an eye in each end, used to raise the tack of a headsail some distance off the deck.

Tackle: a purchase system comprising rope and blocks which is used to gain mechanical advantage.

Tang: a strong metal fitting by which *standing rigging* is attached to the mast or other spar.

Tender or dinghy: a small boat used to carry stores and people to a yacht.

Terminal fitting: fitting at the end of a wire rope by which a shroud or stay can be attached to the mast, a tang or a rigging screw with a nut or a rigging screw with a nut.

Tide: the vertical rise and fall of the oceans, caused principally by the gravitational attraction of the moon.

GLOSSARY OF SAILING TERMS

Toe rail: a low strip of metal or moulding running around the edge of the deck.
Topping lift: a line from the masthead to a spar, normally the boom, which is used to raise it.
Topside: the part of a boat's hull which is above the waterline.
Track: 1, the course a boat has made good; 2, a fitting on the mast or boom into which the slides on a sail fit; 3, a fitting along which a traveller runs, used to alter the tension of the sheets.
Transit: two fixed objects are in transit when seen in line; two transits give position fix.
Traveller: 1, a ring or hoop which can be hauled along a spar; 2, a fitting which slides in a track and is used to alter the angle of the sheets.
Trim: 1, to adjust the angle of the sails, by means of sheets, so that they work most efficiently; 2, to adjust the boat's load, and thus the fore-and-aft angle at which it floats.
True wind: the direction and speed of the wind felt when stationary, at anchor or on land.
Turnbuckle see Rigging screw.

Under way: a boat is under way when it is not made fast to the shore, at anchor or aground.
Uphaul: a line used to raise something vertically, e.g., the spinnaker pole.

U

Wake: the disturbed water left astern of a boat.
Waterline: the line along the hull at which a boat floats.
Waterline length (WL): the length of a boat from stem to stern at the waterline. It governs the maximum speed of a displacement hull and affects a boat's range.
Weather helm: (opp. of lee helm).
Weather side: the side of a boat on which the wind is blowing.
Wetted surface: the area of the hull under water.
Whisker pole: a light pole used to hold out the clew of a headsail when running.
Winch: a mechanical device, consisting usually of a metal drum turned by a handle, around which a line is wound to give the crew more purchasing power when hauling (cut a line, e.g., a jib sheet).
Windage: those parts of a boat which increase drag, e.g., rigging, spars, crew, etc.
Windlass: a winch with a vertical shaft and a vertical handle, used to haul up the anchor chain.
Windward: the direction from which the wind blows; towards the wind (opp. of leeward).

W

Yawl: a two-masted boat with the mizzen stepped aft of the rudder stock/post.

PRE-DEPARTURE CHECK-LIST

- Check bilge for excess water.
- Check weather conditions and tides.
- Check food supply.
- Foul weather gear.
- Linen, sleeping bags.
- Fuel.
- Water.
- Sunscreens and sunglasses.
- Tools.
- Docking and anchor gear.
- Check radio operations.
- Navigation charts and instruments.
- Float plans to a friend or Coast Guard. (See next page.)
- Fuel for stove.
- Cooking and eating utensils.
- Check battery water level.
- Oil level, tight V-belts.
- Check for loose electrical connections in engine room.
- Secure tools or any loose equipment in engine room so as not to get fouled in engine.
- AC systems off; electrical cord stowed.
- Doors and drawers secured.
- Check steering lock to lock.
- Check mast for rigging irregularities and tightness.
- Halyards and sheets are clear and ready to run.
- No lines or other obstructions near the propeller or bow.
- Anchor ready to run.
- Check lifelines for tightness.
- Turn on fuel and water lines.
- Stow all loose gear.
- Open engine cooling water intake thru-hull valve.

FLOAT PLAN

1. Name of person reporting and telephone number:

2. Description of boat:

NAME _____ TYPE _____

MAKE _____ LENGTH _____ REGISTRATION # _____

HULL COLOR _____ STRIKE COLOR _____ TRICK COLOR _____

OTHER DISTINGUISHING MARKS _____

3. Persons aboard:

NAME _____ AGE _____ PHONE# _____

NAME _____ AGE _____ PHONE# _____

NAME _____ AGE _____ PHONE# _____

NAME _____ AGE _____ PHONE# _____

4. Engine:

TYPE _____ H.P. _____ FUEL CAPACITY _____

5. Safety equipment:

PFDs Flares Mirror Flashlight

Food Water EPIRB Raft/Dirigby

6. Radio:

TYPE _____ FREQUENCIES _____

7. Trip expectations:

DEPARTING AT (APPROX TIME) _____ ON (DATE) _____ FROM (LOCATION) _____

GOING TO (LOCATION) _____ RETURNING (DATE) _____ IN NO EVENT LATER THAN (TIME & DATE) _____

8. Automobile:

LICENSE # _____ STATE _____

MARK _____ COLOR _____ PAIRED AT _____

9. If not returned by _____, call the Coast Guard on _____

CLOSING UP YOUR BOAT AFTER SAILING

When leaving your Hunter, Legend or Vision at the dock for more than a short time, it is a good idea to review the following check list to make sure everything is in order. This will help protect the various parts of your boat and add considerably to their attractiveness and usable life.

- Fold and bag headsails and stow below.
- Full mainsail and cover, or remove and also bag.
- Remove and stow all portable deck hardware such as snatch blocks, winch handles, etc.
- Secure the boom to the topping lift and set it firmly and ships with the mainsheet purchase. (It is also a good idea to rig a line from the steering wheel or tiller to a convenient cleat to keep the rudder from swinging back and forth with the motion of the water.)
- Attach the shackle ends of all halyards to convenient fittings and take up slack.
- Clear and coil halyard falls and permanent sheets, hanging them off the deck to promote drying.
- Coil and stow all other lines.
- Cover the winches and steering pedestal when leaving the boat for several days or more.
- Close all fuel lines and gate valves.
- Turn off the electrical system.
- Pump the bilge.
- Check air vents, secure ports and hatches, and swab the deck, particularly if you have operated on saltwater.
- Make a final check of mooring lines, chafing gear, fenders, etc.

FOR SAFE BOATING

BE PREPARED

Take a safe boating course from the Coast Guard. You can call 800-336-BOAT for information on courses in your area.

Carry all safety equipment required by federal and state law. Federal requirements are discussed in "Federal Requirements for Recreational Boats" which can be acquired from U.S. Coast Guard Office of Boating, Public, and Consumer Affairs, Washington, D.C. 20593. State requirements will come from your local State Boating Administration. The Coast Guard also recommends a first-aid kit, a pump or bailer, a wetsuit or weather robe, extra fuel, a paddle, anchor and line, and extra drinking water, also, if not a requirement, flares.

Get a Coast Guard Auxiliary Courtesy Examination. This is a free, confidential safety inspection. Call your local Coast Guard Auxiliary for details.

Be familiar with the use of distress signals and PFDs.

AVOID FIRES

Handle fuels carefully.

Read labels on any stove fuels.

Read the engine owner's manual for proper fuel-system maintenance and inspect your engine's fuel system periodically. Head fire extinguisher regulations and keep them in good condition.

While refueling:

- Fill the portable tanks on the dock.
- Lock the boat securely.
- Extinguish cigarettes and all flames on the boat. Turn off all engines and electrical equipment.
- Keep the hose away from the fuel tank or fill.
- Wipe up all fuel spillage.
- Ventilate the engine and fuel compartment.
- Check boat for fumes.

BEFORE GETTING UNDERWAY

Leave a float plan. (See example under Float Plan)
Perform pre-departure check list. (See Pre-departure Check List)
Check the weather; do not venture out if the weather is threatening.

WHITE UNDERWAY

PFDs should be worn by children and non-swimmers at all times. *Everyone should wear them if conditions become hazardous.*

Do not operate a boat if intoxicated, fatigued or stressed. These human factors cause 50 percent of all boating accidents. Keep a good lookout. This is especially true of sailboats. Keep a watch to leeward under the headsail. Keep away from swimmers, divers and skiers.

Obey state and federal laws. Know your local laws and "rules of the road."

Respect bad weather: try to get in shore if the weather turns bad. Get and carry a radio with a NOAA "weather band" or FM 162.40-162.55MHZ.

IF TROUBLE OCCURS

Radio for help. Use the emergency VHF, channel (i.e., 156.8MHZ).

Put on PFDs immediately.

Stay with the boat. In calm water, buddle together to prevent hypothermia.

FIAT PLAN

Make copies of the float plan page and use before each trip. Fill it out and leave it with a reliable person who will notify the Coast Guard or other rescue organizations if you fail to return on time. Do not forget to cancel the float plan upon your return.

GENERAL HANDLING & OPERATION

Diesel Engine

An engine owner's manual is supplied with your boat and should be read thoroughly. The manual contains technical specifications, tuning instructions and maintenance schedule on lubricants and fluids. For long engine life, follow routine maintenance schedules.

You should check engine oil, transmission fluid and coolant levels. Water, rust, scale and dirt will cause serious damage to the injectors on diesel engines. You should check your filters frequently and change when necessary.

If you start your engine, run it a minimum of 15 minutes to bring it up to operating temperature. This insures that any condensation is evaporated. Your engine should "run-out" at 3/4 throttle at least once a month to clean out carbon build-up and moisture.

Starting:

1. Visually check engine compartment to see that the throttle linkage, shifting controls, electrical connections and fuel lines are properly secured.
2. *Before each start* check oil in engine and transmission.
3. Insure that engine shut-off cable is properly secured and operating.
4. Place the shift lever in the neutral position.
5. Move the throttle or "fuel" lever forward to approximately the half-speed position.
6. Insert the starter key and turn to the "on" position.
7. Press the starter button and hold until engine starts, then release. The buzzer and/or light should then go off.
8. Back the throttle off to an idle position (700 to 800 rpm); allow cold engine to warm up a minimum of five minutes.
9. Check that the tube oil pressure warning light and the charge lamp go off. If any of the warning lamps do not go off above 1,000 rpm, the engine is malfunctioning and should be stopped immediately. Consult your nearest engine dealer.

NOTE: To stop engine at any time, pull "engine stop" lever all the way out. Before stop ping, however, it is a good idea to idle the engine in neutral for about five minutes, then race it to the full-throttle position for a moment, then return to idle and stop engine.

CAUTION: Do not turn safety main switch to "off" while engine is running. This can seriously damage the alternator.

Motoring:

If your boat is equipped with 110V shore power, remember to unplug it upon departure. When engine is warm, move the shift lever to forward and reverse to insure that it engages properly. To increase RPM's push throttle lever forward and pull back to decrease RPM's.

GENERAL HANDLING & OPERATION

Motoring Continued:

CAUTION: Your rigging will conduct electricity. Always check for overhead high tension wires before proceeding. Once clear, you may increase your speed in a reasonable and safe manner as desired.

IMPORTANT: Do not shift from forward to reverse or back without first lowering engine rpm to idle. When sailing, it is best to start the engine before the sails are lowered. This way, it is still possible to maneuver if the engine should not start.

Electrical System

Your Hunter is fitted with an electrical system designed for both AC (AC not available on the 26.5 and smaller) and DC. While in port, you can operate any tool, appliance or other device designed to function on regular house current (120V) simply by plugging your deckside power cord into a convenient outlet on shore and turning your AC main breaker on.

CAUTION: Do not allow your deckside power cord to come in contact with the water. Never operate any AC power tool or other electrical equipment while you or the device are in contact with the water.

This allows you to use the ship's lights and other equipment designed to operate on direct current. Keep in mind that your DC power source is a 12-volt battery and, just as with your automobile, it must be charged regularly by operating the engine. Unless a state of charge is maintained, there may not be enough power to operate the starter motor. Dangerous situations can result if the engine cannot be started when needed.

Make a regular visual check of battery(ies) to insure proper water level and inspect terminals for signs of corrosion. If your boat sits for long periods without use, it is often a good idea to remove the battery(ies) and attach them to a trickle charger to keep them fully charged and ready to use.

Water System

The water heater operates either on 120 volts AC or when the engine is running. To obtain hot water from the engine, it must run a minimum of one-half hour.

CAUTION: Do not tam the water heater on until you are sure the tank is filled with water. To do so will destroy the heating element, which is not covered by the warranty.

Pressure water pumps are the demand type. Once the circuit breaker switch is on, opening the faucet will produce water flow.

NOTE: Intermittent operation of the freshwater pump while all faucets are closed usually indicates a leak somewhere in the lines. Trace the lines to locate the leak and repair.

Please refer to your manual under Heads & Galley systems for more specific information.

GENERAL HANDLING & OPERATION

Toilet:

IMPORTANT: When not in use, lever must be left in the "dry" position to prevent flooding.

Before using, place the lever in the "wet" position and pump slowly to partly fill and wet the inside of the bowl. Return to "dry" position.

After using, return the lever to the "wet" position for flushing and pump until the bowl is thoroughly cleaned. Continue with several more full strokes to flush discharge lines. Return lever to the "dry" position and pump slowly until bowl is empty.

Note: Always close seacocks when sailing or when boat is not in use.

Pumps:

All pumps should be checked frequently to insure proper operation. This is an especially important regular maintenance item since functioning of a pump could save your vessel from serious damage at some future time.

Inspect all hoses for chafing and dry rot. See that hose clamps are tight. Check that the pump impeller area is clean and free of obstructions. Inspect electrical wiring for corrosion. Make sure boat switch moves freely and is making an electrical connection.

Docking:

Docking your boat should be handled carefully to avoid potential damage. Under normal wind and water conditions, the following considerations should be made:

1. Whenever possible, your approach should be made against the prevailing wind and current to assist in stopping the boat. Where these conditions are contrary, the strongest should be used to determine approach.



2. Approaching the dock-dock lines and fenders should be at ready, loose gear stowed and decks cleared. Determine the direction of wind and current, and, once you decide which side of the boat will be against the dock, rig the stern cleat opposite the side that will be against the dock. **NOTE:** If the boat is to be against a piling, rig a fender board across two or more fenders.

GENERAL HANDLING & OPERATION

3. Tying up—attach bow and stem lines to dock, hauling

boat in with tenders against dock. Rig crossing

spring lines to turn motor forward and aft. Be sure

to allow some slack in all lines to compensate for tidal

activity if present. Never use bow rail, stem rail or

stanchions to secure vessel, even for brief periods. For other types of moorings, or for abnormal wind or water conditions, consult your *Chapman's* or other approved boating guide.

Anchoring:


Your Hunter comes with an on-deck anchor well and a burying-type anchor as standard equipment. The anchor is selected to suit the size and weight of your boat under normal anchoring conditions, and provides its best holding characteristic in muddy or sandy bottoms.

When anchoring, pay particular attention to the scope of your anchor rode (i.e., the relationship between the depth of the water and the length of the rode). A good rule of thumb is to allow a scope of about 7:1 (a rode seven times as long as the vertical distance from the bow to the bottom). A helpful aid is to mark the rode every 20 feet or so with knots or other types of indicators. Before dropping anchor, make sure the bitter end is secured to the cleat in the anchor well.

Also, be sure to consider wind direction, currents, mean low tide depths and other local conditions when anchoring, as well as the positions of any boats already anchored nearby.

CAUTION: Anchoring in unusual water and/or weather conditions will require additional precautions. Consult your *Chapman's* or other approved guide for suggestions.

To weigh anchor, motor or sail (under main only) slowly forward. When at a point directly above the anchor, a quick tug should free it from the bottom. Take care not to damage the topsides when hauling the anchor aboard. It is good practice to thoroughly clean the anchor prior to placing it in the anchor well.



- 42'-6" LWA
- 39'-0" LWL
- 14'-4" BOM
- 5'-12" DECK
- 21,800 LBS DISPLACEMENT
- 7,600 LBS BALLAST
- 955 SQ FT SAIL AREA
- 714 SQ FT VHS 1300 JIB
- 7'-4" ST
- 16'-0" L
- 12'-4" T
- 54'-0" MAST HEIGHT
- 5'-0" FROM DECK

HUNTER

LEGEND 43 SAID PLAN H43APK01

SAILS & RIGGING

Tuning the Conventional Fractional Rig (Hunter 27OB, 27IB, 28, 30, 33.5, and Legend 35.5, 37.5 and 43.



Tuning the Rigging:

After raising your mast, attach the headstay, backstay, upper shrouds and lower shrouds. Set the headstay turnbuckle at half open and then tighten backstay turnbuckle to medium tension.

To center the mast athwartships, start with only slight tension on the upper and lower shrouds. Check that the mast is centered in the boat by measuring from the masthead to the chapelets with a steel tape measure hoisted completely up the main halyard. Adjust the upper shroud until the measurements port and starboard are exactly the same. Now the spar is plumb athwartships, tension both uppers equally, counting turnbuckle revolutions as you go. Tighten uppers until you have approximately one inch of "prebend" fore and aft in the mast. This is achieved because the swept spreaders will push the middle part of the mast forward as you increase tension of the uppers.


Now tighten the lower shrouds evenly, making sure the mast remains straight athwartship. Sight up the luff groove to assure this straightness. Lower shrouds should end up almost as tight as the uppers. (The uppers should always be the tightest.) The 28, 30, 33.5, and Legend 35.5, 37.5 & 43 are equipped with double spreaders. The three shrouds should be made progressively tighter toward the top of the rig; the uppers should be the tightest of all. Tighten backstay to a luff position: perhaps eight to ten turns past your original tension. Check the mast tuning by sailing in medium winds (10-12 knots). Sometimes fine tuning the upper and lower shrouds is necessary when the spar is loaded in sailing conditions. Bail on both tacks, sighting up the luff groove to check athwartship straightness. Both upper and lower shrouds should be taut on the leeward side.

When mast tuning is complete, install cotter pins in all turnbuckles and tape over sharp edges of the cotter pins with chafe tape. (Refer to the drawing on Conventional Fractional Rig).



HUNTER

DOUBLE SPREADER FRACTIONAL RIG
W/ SWEEP BACK SPREADERS GENA260



- Ⓐ HEAD FURLER #915
- Ⓑ SCHAEFER #501-39
- Ⓒ SCHAEFER #300-32
- Ⓓ SCHAEFER #34-46
- Ⓔ SCHAEFER #300-31
- Ⓕ SCHAEFER #300-35

NOTES REGARDING ENDLESS FURLING LINE:

RUN FURLING PART OF THE LINE THROUGH BLOCKS




'E' AND STANCHION BASES

RUN UNFURLING PART OF LINE THROUGH STANCHION

BASES ONLY.

HUNTER

LEGEND 43 HEAD FURLING SYSTEM H43A2636




- ④ CHAIN PLATE
- ③ LOWER
- ② INTERMEDIATE
- ① UPPER OR CAP

HUNTER


ISOMAT RIGGING ASSEMBLY GENVAZ60J

- A STEM BALL
- B STEM BALL ADAPTER CUP
(Q,1 OR 2PC.)
- C CLEVIS PIN
- D SHOCK ABSORBER
- E (2) SET SCREWS
- F LOCKING RING
- G INSIDE TIP CASTING
- H OUTSIDE TIP CASTING
- I END COVER




HUNTER

ISOMAT SPREADER DETAIL GEN. 2607




1. REEF #1
2. YANG
3. MAINSHEET
4. REEF #2
5. GENOA HAL YARD
6. SPINNAKER POLE TOPPING LIFT (OPTIONAL)
7. SPINNAKER HAL YARD
8. MAIN HAL YARD



HUNTER


LEGEND 43 MAST STEP DETAIL H43A2639



- (A) SCHAEFFER #701-03
- (B) SCHAEFFER #701-45N
- (C) SCHAEFFER #10-55
- (D) SCHAEFFER #701-13
- (E) SCHAEFFER #08-09

HUNTER


LEGEND 43 MAST AND VANG LAYOUT HA3A2527



- (A) SCHAEFFER 500-32 SWIVEL SHEAVE
- (B) SCHAEFFER 72-39 8 WHEEL TRAVELLER CAR
- (C) BARKENT 24-45 WINCH
- (D) BARKENT 21-30 WINCH
- (E) GARRAUER WIND SHEET STOPPER
- (F) SCHAEFFER 74-50 END CONTROL BLOCK
- (G) GARRAUER DECK ORGANIZER

HUNTER

LEGEND 43 RUNNING RIGGING H43RA2634




A CONTROL BLOCK SCHAEFER #74--60

B FAIRLEAD BLOCK SCHAEFER #500-32


C DOUBLE BLOCK W/BECKETT SCHAEFER #SK-6448

D TRAVELLER CAR SCHAEFER #72--89



HUNTER


LEGEND 43 MAINSHEET TRAVELLER H43A2640




HUNTERA

RIGGING LENGTHS GENA2605

- ① REEF #1
- ② REEF #2 (RUNS THE SAME AS REEF #1)




VARIATIONS:



HUNTER

BOOM AND REEF LAYOUT
 ISUREEF GENA2609



HUNTER



LEGEND 43 DECK HARDWARE 1143A2638

LEGEND 43 DECK HARDWARE LAYOUT (See Diag.)

1.	Stem plate w/roller	Southcoast	NA	HW1614
2.	Reefter furler	Hood	915	RJ0423
3.	Moorlog cleat	Y/S	YS7107R-10"	HW0977
4.	Bow rail	Southcoast	NA	HW2411
5.	Stanchions	Southcoast	NA	HW2100-A
6.	Flatch fwd.	Bomar	10<9-10	HW0070
	Tunn hog	Bomar	NT2049	HW0070-A
	Screen	Bomar	NS2049-ex	HW0070-B
7.	Handrail, fwd.	Custom	NA	HW2440
8.	Hunter vent hatch, fwd	Custom	NA	WC01001
9.	Deck organizer	Garhauer	NA	HW0172
10.	Hunter hatch, mid	Custom	NA	WC010011
11.	Port light	Lewmar	8902	HW0043
12.	Hatchall aft	Custom	NA	HW1700
13.	Port light	Lewmar	HSK0341	HW0008
14.	Turning block	Schaefer	08-09N	HW0270
15.	Primary winch	Harlem	28CSI	HW2550
16.	Stem rail	Custom	NA	HW2289
17.	Swim ladder	Southcoast	NA	HW1701
18.	Loc rail	Tifton	NA	HW2501
19.	Water tank fill	Perko	521-W00	PL1141
20.	Waste deck plate	Perko	NY6146-00	PL1140
21.	Genoa track	Schaefer	SK6096	HW0257
	Hand stop	Schaefer	74-36.6	HW0215
22.	Mainsteeet traveller	Schaefer	SK6447	HW0152
	Traveller car	Schaefer	72-89	HW0239
	Piddle block w/becket	Schaefer	10-55	HW0223
	Double block w/becket	Schaefer	SK-6448	HW0159
	Forehead block	Schaefer	500-32	HW0197
23.	Companionway grab rail	Southcoast	NA	HW2433
24.	Sheet stopper, quad.	Garhauer	11-11	HW1274
25.	Cpway slider track	Bomar	NA	HW0148
26.	Foreboard track	Bomar	NA	HW0147
27.	A. Hatyard winch	Harlem	24-45	HW2542
27.	B. Hatyard winch	Barlem	21-33	HW2546
28.	Stanchion gate (stb)	Southcoast	NA	HW2117
	Stanchion gate (port)	Southcoast	NA	HW2118
29.	Manual bilge pump	Rule	14RM	PL0361
30.	Diesel fuel fill	Perko	520 1000	PL1143
31.	Stem rail	Southcoast	NA	HW2289
32.	Inspection port	Eyrl	DP40-W	HW0045

HUNTER 43

LEGEND 43 SPINNAKER PACKAGE H43A264I



LEGEND 43 SPINNAKER PACKAGE (Page Two)

DECK FITTINGS

#	Item	Quantity	Vendor & Model	Notes
1.	Spinnaker sheet winches	2	Barent 28CST	
2.	Spinnaker sheet blocks	2	Schaefer 10-15	
3.	After guy blocks	2	Schaefer 10-15	
4.	Pad eyes sheet & guy	4	Schaefer 78-25	Mount on keel
5.	Spinnaker pole with ends	1	Isomat	Tip pole style
6.	Spinnaker pole car		Isomat	Car & adj. gear
7.	Pad eye for foreguy	1	Schaefer 78-25	Just behind anchor well
8.	Fall lead eyes for foreguy	8	Schaefer 78-51	Along edge of house
9.	Hayard exit plate	1	Schaefer 34-46	Guide through keelwood above genoa track
10.	Block with snap shackle	1	Schaefer 701-09	Foreguy
11.	Sheet stoppers	3	Garhauer single, S.S.	2 port, 1 std.
12.	Spinnaker sheet donuts	4	Schaefer 45-50	2 green, 2 red
13.	Spinnaker hayard stopper	1 (sb)	Schaefer 70-86	On house side
14.	Spinnaker hayard stopper	1 (port)	Schaefer 70-85	On house side

Letter Item	Line	Length	Shackles	Vendor
A. Spinnaker halyard (XLS extra)	7/16"	130'	Nicro Fico NF 1500S	Seco South
B. Spinnaker pole tapping till	7/16"	130'	Nicro Fico NF 1100S	Seco South
C. Spinnaker Sheets	7/16"	2/80'	Nicro Fico NF 15000 FR	Seco South
D. Spinnaker after guys (X) & extra 1/2"	2/65"	Nicro Fico NF 15000 FR	Seco South	
E. Spinnaker foreguy	7/16"	1700'	Nicro Fico NF 1500S	Seco South
F. Spinnaker car control line	3/8"	30'	Isomat	Isomat

LINE

DUTCHMAN[®]

Martinus Van Breen, Inc.
571 Riverside Avenue Westport, CT 06880
Tel 203-454-0322 FAX 203-454-1455



Notes to the Dealer for rigging the Dutchman on the Hunter Legend & Passage Series

May 1981

The new Hunter Legend and Passage series are coming standard with the Dutchman System B. The Dutchman system consists of vertical control lines of Nylon Monofilament that weave through custom nylon "anchors" in the sail. The control lines are finished in Dacron rippled ribs sewn into the base of the sail, sandwiched between nylon discs on both sides of the rib. The attachment and proper adjustment of the control line is described at length in the Owners Manual.

The System B also includes our Continuous Topping Lift (CTL) System. The position of the clamps can be adjusted from the end of the boom by raising the CTL Line. Boom height is adjusted normally.

A. Parts Check

Make sure the following 2 components are included in the parts bag.

- 2 white dyes per control line to attach the control lines to the ribs sewn in the foot of the sail.
- 1 Assembled Continuous Topping Lift (CTL) System. This is made up with the following parts:
 - The CTL Line, which is 1/4" - 3/16" braided Dacron line.
 - Control lines of 400 - 500 lb test Nylon Monofilament.
 - 1 block, 1 jam cleat, and 1 shackle attached to the CTL Line.
 - Black clamps that attach the control lines to the CTL line.

Illustrations and descriptions of these parts can be found on Pages 3 & 4 of the Owners Manual. The Owners Manual should be with the other Owners Manuals and Ship's Papers.

B. Rigging the Continuous Topping Lift System

The CTL System will arrive with the clamps, control lines, block, jam cleat, and shackle attached.

1. If a mast adjuster (anyward type) is being fit, install the CTL after the mast is stepped by attaching the back of the CTL to the topping lift adjusting line, and raising up the CTL.
2. After the boom is attached to the gooseneck fitting, attach the jam cleat to the topping lift adjusting line with the shackle provided.

(over)

C. Adjusting the CTL Clamps

1. Hoist the main. Pull the main sheet and topping lift adjusting the vang. Sight up the vertical rows of grommets.
2. Hip over the V shaped jam cleat. Slacken the topping lift and raise the CTL Line from the end of the boom until the uppermost clamp is directly above the forward vertical rows of fairleads, then reversion the topping lift. Mark where the CTL passes around the jam cleat with a pen.
3. Adjust the lower clamps if needed. This is done by rotating the CTL to get the clamp to deck level, loosening the 4 screws in the clamp, sliding it up or down, tightening the screws, and repositioning the CTL. Again it helps to slacken the topping lift when marking the CTL. See Page 9 of the Owners Manual.

D. Threading the Control Lines

1. With the sail raised, count the number of fairleads in either one of the vertical rows. Drop the sail.
If an even number of fairleads, insert the control lines in the uppermost fairleads on the same side of the sail as the tabs seen in the last row.
If an odd number, begin weaving the control lines through the opposite fairleads on the opposite side of the sail as the tabs are on.
2. Weave the control lines through all of the fairleads in each vertical row. The end of the control lines should exit through the lower fairlead on the same side of the sail as the tabs.
3. Use two people, one on either side of the sail to pass the control line back and forth.

3. Open the zipper in the tab and pull the control line through the hole at the top of the tab. Install the deck and batten. The line should face the sail. See Page 10 of the Owners Manual. Then hook the sail to adjust the control line length.

E. Adjusting the Control Line Length

The control lines should be slack enough that sail shape is not affected by the tension on the control lines with the sail raised. To adjust the control line length, the sail must be fully raised with the main sheet and topping lift tensioned. Refer to Page 11 of the Owners Manual.

The control lines should have enough slack to allow 1 inch of play up or down.

F. Final Adjustments

1. Make certain that the topping lift adjusting line is long enough to allow the topping lift to be slackened with the sail raised.
2. Make sure the jam cleat is in the locked position (pointing up). Using fixing tape, tape the CTL line just above the jam cleat to prevent the CTL line from rotating.

G. Using the Dutchman

When dropping the sail, the first few times, be careful that the tack crop or the correct sides of the boom. First, straighten the folds at the aft, then work aft and tug aft on the leech. After a few weeks the sail will develop a memory of the folds and the straightening will be needed.

Slacken the topping lift after the sail is raised. With a Mast Adjusted Topping Lift, tighten the topping lift before the sail is dropped.

Please contact us if you have any questions, problems, or if the clamps need adjustment.

LEGEND 43 RIGGING SPECIFICATIONS

STANDING RIGGING

FITTINGS

Description	Wire Size	Upper End	Lower End*	Overall Length
Forestay	3/8	marine eye	12-20-20	54" 11 3/4"
Backstay uppers	1/4	marine eye	marine eye	36" 6 1/8"
Bridles	3/16	marine eye	6-12-12	34" 4 1/4" 2pcs
Uppers	3/8	stemball w/shell	12-20-20	52" 6" 2 pcs
Intermediate	1/4	stemball w/ cup	8-16-16	35" 6 1/4" 2pcs
Lower	3/8	stemball w/no cups	12-20-20	18" 5 1/4" 2 pcs
Inner forestay (opt.)	9/32	marine eye	removable turnbuckle approx. 42"	

(Use Norsman)

All wire is 1 x 19 stainless steel.

Backstay is attached to bridge with two splitter plates and three pins - 1/2" x 3/8" x 3/8". Tie a 5/8" eye/jaw rope to forestay.

*The three numbers represents the turnbuckle size as follows:

Wire size, body size, pin diameter in 32nd's of an inch.

Example: 12-20-20 is a turnbuckle that accepts a 12/32" wire, has a 3/8" (12/32) thread diameter in the body, and uses a 3/8" (12/32) pin.


RUNNING RIGGING

Line / Size: Attachments Overall Length


Main Halyard	7/16"	Headboard shackle	134"
Genoa Halyard	7/16"	Swivel snapshackle	120"
Main Sheer	7/16"	Eye splice	76"
Genoa Sheels	1/2"	B. B. E.	55' 2 pcs.
Furling Line	7/16"	B. B. E.	89'
Traveler Control Lines	3/8"	Eye splice	29' 2 pcs.
Vang Line (short)	1/2"	Eye splice w/shackle O.E.	86"
Vang Line (long)	3/8"	Eye splice	46"
Topping Lift	3/8"	Shackle	70"
Anchor Line	5/8"	Shackle	250"

Main & genoa halyard is Spectra


All rigging is supplied by Seco South.



COVER PLATE




BACKING PLATE




HUNTER

LEGEND 42 INNER STAY CHAIN PLATE H47 '42

MODIFICATION REQUIRED TO INNER FORESTAY TURNBUCKLE
 TOGGLE FOR STAY SAILSAIL TACK ATTACHMENT.



ATTACH TO CHAMFLEAF WITH
 1/2\"/>




HUNTER
 INNER FORESTAY TURNBUCKLE MODIFICATION
 FULL SCALE
 142A2.12

Legend 43

Dutchman System B for the Hunter Marine

OWNERS MANUAL




Martinus Van Breems, Inc.
571 Riverside Avenue Westport, CT 06880
Tel. 203-454-0232 FAX 203-454-1445

DUTCHMAN®



The purchase price of the Dutchman system includes a prepaid royalty for a limited license to use our Patented system. Each Dutchman installation **MUST** have our numbered labels sewn onto the tabs in the sale.

These labels are used to identify properly licensed systems. An example of what the label looks like is pictured below. Please check your sale. If the labels are missing or incorrect, contact us immediately.



Dutchman is a trademark of Martinus Van Breeam, Inc. The Owners Manual is Copyright 1987 by Martinus Van Breeam, Inc. 571 Riverside Avenue, P.O. Box 2875 Saug. Sta., Westport, Connecticut. 06880, U.S.A., 203-454-0222.

U.S. Patent #4685506. Foreign Patents Pending. Construction, purchase, or use of unauthorized systems may result in legal action. Martinus Van Breeam, Inc. reserves the right to change all prices, hardware, and specifications without notice at any time.

The Dutchman system is unconditionally guaranteed against defects in materials supplied by Martinus Van Breeam, Inc. for a period of five (5) years. Defective items may be returned to Martinus Van Breeam, Inc., and will be replaced or repaired at the option of Martinus Van Breeam, Inc. Return of defective products should be accompanied by a letter giving name, address, phone number, date of purchase, place of purchase, and identification of installing company, as well as an explanation of the defect in maintenance, and the conditions under which the product was being used. This warranty does not apply to or include any product that was improperly installed, or subjected to misuse, negligence, accident, or subjected to unauthorized modification or repair. Normal wear of wire or rope on all equipment is excluded. This warranty is in lieu of all other implied, express, and statutory warranties and guarantees, and in no event shall Martinus Van Breeam, Inc., be liable for special, incidental or consequential damages.

Introduction

Thank you for your selection of a Dutchman Sail Handling System. The System Hardware installed into your sail is specifically designed for easy adjustment and replacement of the control lines. Please spend a few minutes learning how to best use and maintain your system, and keep this Manual handy for future reference.


The control lines are attached at the base of the sail to Dacron tabs your sailmaker has installed. The control lines are run through the hole in the top of the tab and are fastened with round nylon discs. The length of the control line can be adjusted easily by opening the zipper in the tab and loosening the screws. The control lines then run through nylon grooves that your sailmaker has installed into the sail, and attach to the continuous lapping lift clamps.

The Dutchman Continuous Topping Lift System allows for easy installation and adjustment of the control lines on the lapping lift. The continuous loop can be rotated, much like a clothesline, allowing the position of the clamps to be adjusted from the end of the boom. This makes the installation or replacement of the control lines plus removal of the sail considerably easier. In addition, the easy adjustment will also be helpful if a sun awning is rigged above the boom.

With the continuous loop arrangement, one of the topping lift lines is held securely by the clamps while the other line runs freely through the clamps. Depending on which way the lapping lift is rotated, the clamps can be moved up or down the lapping lift line. If the distance between the clamps has to be altered, the clamps can easily be dropped down and adjusted.

We hope you enjoy your Dutchman, and we wish you many pleasant voyages. Like most innovative companies, we welcome your input and look forward to your comments.

And remember — when all else fails, read the instructions!



Martinus van Breeom

Table of Contents

<u>Subject</u>	<u>Page</u>
Section One Introduction	
A Letter from the Designer	1
B Parts List	3-4
C Definition of Terms	5
D Tools Required for Installation	5
Section Two Installation Procedures	
A Configuration of the CTL System	6
B Attaching the CTL System	7
C Adjusting the CTL Lane Length	7-8
D Adjusting the CTL System Clamps	9
E Threading the Control Lines	10
F Fastening the Control Lines	10
G Adjusting the Control Line Length	11
Section Three Using the Dutchman	
A Lowering the Sail	11
B Downwind	12
C Keeling	12
D Check Adjustment	13
E Release Feature	13
F Recovering the Sail	14
Section Four Maintenance	
A Installing New Control Lines	15
B Replacing the Existing CTL Line	15
Section Five Installing a New CTL Line	
A Measure and Insert the CTL Line	16
B Attach the Uppermost Clamp	17
C Attach the Rest of the Clamps	18

The Dutchman System Parts List

Attachment Tabs (tabs) Dacron cloth, with canvas inner lining and access zipper. The tabs are sewn into the foot of the sail by your sailmaker. Each system has a six-digit number printed on the label. One tab is installed for each control line.


Discs (discs) round, white nylon. The discs fasten the control lines to the sails. Two are supplied for each control line.

Two 8-32 x 1/2" (4 x 12mm) slotted round-head machine screws and two 8-32 (4mm) lock nuts are supplied for each set of discs.

Grommets (grommets) round, white nylon with vertically-oriented, cigar-shaped hole. Installed by sailmaker into the sail. Used for protecting the sail where the control lines run through it.

2" grommets: 1/8" (3.5mm) for boats with P (uff) measurements up to 30',
 5/32" (4mm) for boats with P measurements up to 40',
 2 1/2" grommets: 5/32" (4mm) for boats with P measurements up to 50',
 3/16" (4.5 to 5mm) for boats with P measurements over 50'.

Topping Lift (clamps) (clamps) black, glass-filled nylon parts, rectangular shape, with 2 hex-shaped and 2 round-shaped recesses each. Used to attach the control line to the topping lift and to join the two ends of the topping lift together. Two halves are supplied for each control line.
 Four 8-32 x 1" (4 x 25mm) slotted round-head machine screws and four 8-32 (4mm) lock nuts are supplied for each set of clamps.




Jam Cleat (cleat) black, glass-filled nylon part, triangular shape. The jam cleat is used to attach and secure the lower end of the continuous topping lift. The topping lift line is run through and wedged into the narrow end of the cleat to keep the topping lift from rotating when the clamps are under tension. The wide end of the cleat is used when rotating the line during adjustment. One is supplied with each system.

Long D Shackle (shackle) stainless steel, 1/4" (6 mm) pin, 1/2" (13 mm) jaw width, 1 3/4" (44 mm) or longer inside length. Fastens the cleat to the boom. One is supplied with each system.

Single Block (block) stainless steel and high impact plastic with clevis pin. For 1/4" (6 mm) line. Schaefer Marine Series 01-03 (Series 200-03 for boats over 40 feet). Attached to the top of the mast with the topping lift line run through it. One is supplied with each system.

Continuous Topping Lift Line (CTL line) 1/4" (6 mm) low-stretch braided Dacron line. Length should be twice the distance from the top of the mast to the end of boom. Supplied by the sailmaker.

Control Line (control line) braided Dacron cord with low stretch and smooth outside surface characteristics. Runs from the CTL line to the tabs through the rows of grooves in the sail. The length of the control line should be enough to run from the topping lift, through the sail, to the attachment tab with 1 to 2 feet (30 to 60 cm) of extra line. Supplied by the sailmaker.



If any parts are missing, please contact us immediately.

Definition of Terms

Boom Adjusted Topping Lift — A topping lift which is fixed at the top of the mast. Tension adjustment is usually done at the aft end of the boom.

Mast Adjusted Topping Lift — A topping lift fixed at the end of the boom with a shackle and run to the top of the mast, over a sheave, and back down to the base of the mast. Adjustment is usually done at the base of the mast.


Point X — The point on the topping lift where the control line attaches. This location is found when the fall is raised and the vertical row of grommets is sighted up to the topping lift. On a two line system, there will be 2 Point X's.

CTL System — The Continuous Topping Lift System, which includes the clamps, block, jam cleat, and the CTL line.

Section One-D

Tools Required for Installation

- colored tape to mark CTL line
- knife to cut control line
- vice grips (or locking pliers)
- medium size slotted screwdriver
- bosun's chair (for boom adjusted topping lift)
- matches, whipping line, or clip to seal line ends



Section Two

Installation Procedures

Briefly, to install the Dutchman sail handling system, the CTL System is installed then the control lines are fastened to the CTL line, threaded through the grooves in the sail, and secured to the tabs with the clips.

If your CTL System is not already made up, please go to Section Five,

Page 16.

The first step is to run the CTL line in place of the original topping lift. Next, you will have to adjust, if needed, the length of the CTL line and the position of the clamps.


Section Two-A

Configuration of the CTL System

Boom Adjusted Topping Lifts and Mast Adjusted Topping Lifts have different configurations of the shackle and block in relation to the boat's adjusting lines.


Mast Adjusted Topping Lift

- block is fastened to the end of the boat's topping lift line.
- shackle fastens the cleet to the end of the boom in a fixed position.



Boom Adjusted Topping Lift

- block is fixed on the masthead fitting where the boat's topping lift was attached.
- shackle fastens the cleet to the boom's adjusting line.



Attaching the CTL System

Many sailmakers will construct the CTL System on the loft floor with the clamps attached, requiring you only to do the installation and adjustment on the boat.

1. Remove the tension from the topping lift by releasing the boom. Either drop the boom to the deck, secure it with the main halyard, or support with a hydraulic vang. The control lines should not be threaded through the sail yet. For that matter, the sail does not have to be on the boom yet.

Boom Adjusted Topping Lift

2. Rig a buson's chair, and hoist a person up the mast until they are at the masthead fitting. Disconnect the old topping lift from the masthead and reconnect the CTL System by fastening the block to the buson's chair in the buson's chair can now be lowered to the deck.

3. Raise the boom and connect the cleat on the bottom of the CTL line to the boat's topping lift adjusting line with the shackle provided. The narrow end of the cleat should be pointed down in the shackle. Hoist the boom up to its normal position.

- ### Mast Adjusted Topping Lift
2. Connect the block to the existing fixture at the end of the boat's topping lift. Hoist the block to within one foot (35cm) of the top of the mast.
 3. Connect the cleat at the bottom of the CTL line to the end of the boom with the shackle provided. The narrow end of the cleat should be pointed down in the shackle. Hoist the boom up to its normal position.

Adjusting the CTL Line Length

Determine whether the length of the CTL line is correct. You should have enough adjustment capability with your rig to be able to hoist the end of the boom up enough to get it clear of the cockpit. You should also be able to lower the boom enough so that it won't interfere with sail shape.

1. Raise the boom up to the highest level you normally would raise it to clear the cockpit. Then raise it an additional 5 inches (13 cm).

Boom Adjusted Topping Lift

2. Make sure that the adjusting line on the boom is long enough so that you can drop the boom down to its sailing position.

Mast Adjusted Topping Lift

2. The block should be far enough (approximately one foot) from the top of the mast so that the boom can drop down to its sailing position.

3. Estimate whether the CTL line has to be shortened. If it needs to be shortened, proceed with Step 4. If the length is correct, skip on to the next section, Adjusting the CTL System Clamps.

Booy Adjusted Topping Lift

4. Flip the cleat with the base of the triangle up so that the CTL line can rotate. Rotate the CTL line to drop the clamps down. Mark the location of the lower clamp on the CTL line with colored tape.
- Loosen the clamp's screws (do not take the clamps apart). Continue raising the CTL line until you get the uppermost clamp down to your level.

5. Open the uppermost clamp. Remove and shorten the end of the CTL line that goes up to the block. Do not shorten the line leading to the lower clamp. Torser the rope end from unravelling by melting, clipping, or seizing.

If you need to shorten the CTL System by one foot, you will have to shorten the CTL line by two feet.


6. Remove any twists that may have appeared in the CTL line. (See a figure-8 knot in end of the CTL line and put it tight.

Leave 1/2" (12mm) of line remaining beyond the knot after the line is pulled tight.

7. Fit the knot into the center cavity of the clamp. Lead both of the lines between the screw tubes then out of the clamp.

8. Attach the other half of the clamp. Tighten until you begin to feel the rope compress. Pull as much of the CTL line out of the clamp as possible, then tighten clamp securely.

9. Raise the CTL System and double-check the new length.



Adjusting the CTL System Clamps

In this section, you will check and adjust the position of the clamps. When the sail is raised and you sight up the vertical row of groomers to check the position of the clamps, you will notice that the groomers are on a somewhat curved line. This is normal because the groomers are designed to follow the huff curve. Also note that the uppermost clamp cannot be moved, since it is used to join the two ends of the CTL line together.


1. Install the sail on the boom. The control lines should not be threaded through the groomers. Hoist the sail with the lopping lift and main sheet tight.

2. Sight up each vertical row of groomers to check the position of the clamps. The clamps should be directly in line with the vertical row of groomers, plus or minus 2 inches (5cm). If the lopping lift clamps are within 2 inches of Point X, then skip over to next section. Thread the Control Lines.


3. If the position of the clamps needs to be adjusted, flip the clear so that the CTL line can raise. Raise the CTL line until the uppermost clamp is in line with the forward row of groomers at the correct Point X. Mark the CTL line at the clear with colored tape for future reference.

4. With the sail raised visually estimate how much the next lower clamp has to be moved to get it in line with its Point X. Rotate the CTL line until the next lower clamp is at deck level, and reposition it by loosening the screws and moving the clamp to the correct position.

5. Tighten the screws, and raise the clamps until you reach the clear's reference mark on the CTL line. Sight up the groomers and check the repositioned clamp. If not at Point X, repeat Step 4. Also double check that the uppermost clamp is in the correct position.
6. For a 3 or more line system, repeat Steps 4 and 5 for the next lower clamps. Always start with the uppermost clamp and work down.



PLEASE STAY ON BOARD
 LOWERED WITH SLOW
 OUT TO THE TAIL
 TAIL HEAD



If you have running backstays, keep them away from the mainsail while it's being raised or lowered. Also keep the sail away from the spreader tips while it's being raised or lowered. The Dutchman grommets have a rounded edge that possibly could catch on running backs or spreader tips.

Respectably in winds of over 10 knots, you may want to head so the wind is 15 to 20 degrees off the bow. You will then keep the boom clear of the cockpit. Because the sail stays on the boom, you can lower the sail out to the side to protect your head in the cockpit.

When lowering the sail, the topping lift should be tensioned, the boat headed to the wind, and the main sheet let off. The Dutchman will not work properly if the sail is not luffing freely in the wind. The system works better in more wind, so you do not need to slow down your motor. It helps to push or pull the luff (or forward edge) of the sail to alternate sides of the boom as the sail comes down. After the sail is dropped, straighten the luff edge of the sail by tugging it all.

Lowering the Sail

Section Three-A

The control line should automatically release from the tab if too much strain is placed on the system, which may happen if the control line catches on the rigging or if the sail is violently luffing.

1. Have the sail fully raised with the topping lift and main sheet tight. This can be done while out sailing or on the dock.
 2. Loosen the screws securing the discs.
 3. Open the zipper and adjust the control line length until the slack is 2 to 2 inches (5cm).
 4. Tighten down the screws and check the tension again. Do not over-tighten the screws. After the discs begin to grab the line, 3 or 4 more turns on each screw will suffice. The screws can always be tightened down farther if the control line pulls out of the tab in moderate conditions.
- To check the adjustment of the control line length, the sail must be fully raised with the main sheet and topping lift tensioned. This can be done while out sailing. The control lines should have enough slack to allow 2 inches (5cm) of play up or down. The control lines should be adjusted if there is more or less play.

Adjusting the Control Line Length

Section Two-C


Section Three-B

Downwind

There is a very remote possibility that when turning downwind with the salt touching the spreader, a control line may become snagged on a spreader tip if the tip is not well faired. If this were to happen, the salt could be jammed when it is sheeted in. Therefore, when initially turning downwind with the Dutchman, check how close the control line is to the spreader tip.

You may also want to install a spreader hook or similar device that prevents lines from snagging on the spreader tip.


Your sailmaker has already set the location of the control line a certain distance away from the spreader tip when building the system into your sail to prevent this type of damage from happening.



Section Three-C

Reefing

One of the greatest advantages of the Dutchman is how it assists in Jiffy or Slab reefing. The sail is always held in top off the boom, so in most cases, you will not need to tie off the intermediate reef points. The Dutchman will only work with Jiffy or slab reefing. Roller reefing systems cannot be used.



Section Three-D

Check Adjustment

The rule of thumb is to tighten the control lines if the sail falls off the boom, loosen them if sail shape is affected.

You should loosen the control lines if the topping lift cannot be slackened enough so as to keep the control lines from affecting the sail shape. On the other hand, you should tighten the control lines if the sail always falls partly off the boom as you drop it. The control line length will also need to be adjusted if you adjust the position of the clamps. There should be about 1 to 2 inches (5 cm) of play.

Keep an eye on the adjustment of the clamps and the control line length. You should have no problem in doing this yourself. The only tool you will need is a medium slotted screwdriver. The clamps should never be more than 2 inches (5cm) out of alignment with the vertical rows of grooves. See Section Two-G if they are.

The topping lift may need to be eased while sailing to allow the leach of the sail to develop twist. You may want to give a tug on the control lines after you let off on the topping lift.

You cannot hoist the boom abnormally high with a mast topping lift, nor drop the boom too much if you have a boom topping lift, without over-tensioning the control lines. However, it is possible to rotate the clamps down to slacken them.

Section Three-E

Release Feature

The discs and tabs are designed to release the control line if too much pull is placed on the control line. This is to protect the grooves. Such stresses could be placed on the control line if the sail is flogging in winds over 25 knots, if the control line were to catch part of the rigging, or if an accidental jibe occurs. If this happens, loosen the discs and adjust the control lines.

Do not tighten down the control lines more than the specified amount (see Section Two-G), unless you find that the control lines are being released in moderate conditions. And never be knos in the control line.

WARNING: Do not apply more than 400 pounds of strain to the topping lift. Never let people hang off the boom when it's supported by the topping lift.

Section Three-F

Removing the Sail

The easiest way to store your sail is to keep the control lines with it. Before you remove the sail, it helps to tie a slip knot directly above the uppermost grounnet. This will keep the sail from spilling all over the deck as you pull the foot of the main forward off the boom. If you position out the flukes and roll the sail up, you will also help the sail to 'remember' where it's supposed to take while stored.

Maxim Adjusted Topping Lift

1. Use the main halyard to support the boom. Flip the cleat and rotate the CTR line to lower the clamps down. Loosen the screws and remove the control line from the clamp.

1. Drop the CTR System down and remove the hook from the boat's existing topping lift.

2. Keep the entire CTR system and control lines with the sail. Attach the boat's topping lift to the aft end of the boom.

2. Tie a slip knot directly above the uppermost grounnet. Reassemble the clamp and repeat for the rest of the clamps. Wrap up the clamps with canvas or plastic to protect from UV exposure.

Section Four

Maintenance

The most important maintenance required is a periodic check of the CTR line and control lines. At least twice a season, the CTR line should be checked for chafe or deterioration at Point X. The control lines should be replaced at least once a season. The control lines will tend to pick up dirt in more polluted or polluted areas. Replacing the control lines keeps the sail cleaner, as you will notice streaks in the sail where the control lines lie against it. Replace the control lines with an equivalent low-stretch Dacron cord, according to the specifications in the beginning of this Manual. Also check that the lead is not corroded from the topping lift line.

Installing New Control Lines

When you are ready to replace the control lines, it is easiest to do so while the existing control lines are still threaded through the sail. Estimate the correct length of control line by using the old control lines as guides.

- Boom Adjusted Topping Lift**
1. Flip the cleat and rotate the CTL line to drop the clamps down. Loosen the lower clamp screws and continue rotating the line until you get to the uppermost clamp.
 2. Open the clamps, and replace the control lines. Make sure to use a figure-8 knot, and leave 1/2" free in the end after the knot. Reassemble the clamps.
 3. Tape the top end of the old control lines to the bottom end of the new control lines. Gently pull through the sail. Raise the sail as you do so. Remove the old control line. See Sections Two-F and Two-G, Pages 10-11 for more information on how to raise and adjust the new control lines.

Replacing the Existing CTL Line

Use these instructions if you are replacing a CTL line. The CTL line may need replacing after a number of years from UV damage. It will also need to be replaced if abraded in any way at the clamps or cleat.

- Boom Adjusted Topping Lift**
1. Flip the cleat and rotate the CTL line to drop the clamps down. Disassemble the lower clamps and continue rotating the line until you get to the uppermost clamp.
 2. Disassemble the uppermost clamp, and carefully lace the new CTL line to the old CTL line end for end, so it will fit through the block at the masthead. Do not use too much tape.
 3. Pull the new CTL line through the block, and back down to the deck.
 4. Assemble the new clamps with the control lines on to the topping lift and raise CTL system into position. See Sections Two-F through Two-G, Pages 9-11 to adjust the clamps, control lines, and complete the installation.
- Mast Adjusted Topping Lift**
1. Use the main halyard to support the boom. Drop the CTL system to the deck.
 2. Disassemble the clamps, and pull the old CTL line through the cleat and block.
 3. Slide the block and jam cleat onto the new CTL line. Arrange the new line on the ground so it roughly is in the same position the old line was in before it was disassembled, with the block and the jam cleat at their respective ends.

Section Five

Installing a New CTL Line

If you no longer have the CTL line, or if your boat came without the CTL line made up with the clamps, block, and jarn clear attached, you will have to assemble it yourself. This is not a very difficult job. The following Steps 1, 2, and 3 should be done with the mast unsteepped, if possible.

Have enough line to reach from the end of the boom to the top of the mast, and back down again. You can use the main halyard and a messenger line to measure this distance. CTL line specifications are given in Section One-B on Page 4.

Section Five-A

Measure and Install the CTL Line

1. Drop boom down to the deck or into a boom crutch.
2. Thread the CTL line through the block and clear. Temporarily tie the two ends of the CTL line together.

3. Remove the old topping lift. If the mast is stepped, send one person aloft in a boson's chair to remove the old topping lift, and fasten the block at the top of the mast. Lower the rest of the CTL line to the base of the mast.

4. At this point, the mast must be stepped. First, rig the main halyard as a temporary topping lift. Then raise the boom up to the highest level you normally would raise it to clear the cockpit, then raise it an additional 5 inches (13cm). Tape and cut the CTL line so that both ends of the line just touch the end of the boom. Protect the rope ends from unraveling by melting, dipping, or sealing.

Bottom Adjusted Topping Lift
 5. Make sure that the adjusting line on the boom is long enough so that you can drop the boom down to the sailing position.

Mast Adjusted Topping Lift
 5. The block should be approximately one foot (30cm) from the top of the mast.

Attach the Uppermost Clamp

1. Tie a figure-8 knot in each end of the line.


Make certain that there is 1/2 inch (14 mm) of line remaining beyond the knot after it is pulled tight.

2. Sight up and remove any twists that may have appeared in the CTL line. The length of line that runs over the top of the block should then be placed in the lengthwise passage that runs along the straight side of the clamp.

3. Put the figure-8 knots into the cavity in the center of one of the clamp halves, lead the lines between the screw holes, then out of the clamp. Make sure that the cleat is located on the CTL line below the clamp.

4. Tie a figure-8 knot into the end of the longest of the control lines, leaving 1/2 inch (14mm) of line remaining beyond the knot. Fit this knot into the outer cavity of the clamp. Lead the control line out through the downward-facing small passage.

5. Attach the other half of the clamp using the screws and locking nuts. Tighten the screws and you begin to feel the rope curving. Pull as much topping lift line out of the clamp as possible; then tighten the clamp securely.

**Boom-type Topping Lift**

6. Fasten the cleat to the end of the adjusting line on the boom using the shackle provided. The narrower end of the cleat should be pointed down in the shackle.

Mast-type Topping Lift

6. Fasten the cleat to the end of the boom using the shackle provided. The narrower end of the cleat should be pointed down in the shackle.

Attach the Rest of the Clamps

1. After the first clamp is attached to the CTL line, hoist the mast(s) and pull the CTL system snug.
2. Estimate the distance between the uppermost grommet of the forward control line and the uppermost grommet of the second control line. Raise the CTL line until the uppermost clamp is roughly the same distance away from the end of the boom. This does not have to be exact.
3. Attach the second clamp. Make certain there are no twists in the line. The upper part of the CTL line should be placed in the lengthwise passage next to the long side of the clamp. The lower CTL line will be run straight through the center cavity between the machine screw holes with no figure-8 knots.
4. Attach the control line by tying a figure-8 knot into the end of the corner of the control line, leaving 1/2 inch (14 mm) of line remaining beyond the knot. Fit this knot into the center cavity of the clamp. Lead the control line out through the forward-facing small passage. Loosely tighten the screws.
5. Attach the rest of the clamps, if any, by repeating steps 2, 3, and 4. To do the final adjusting and installation of the control lines, see Section 5 Two-II through Two-Cl), Pages 10-11.

This licensing card will help us to provide you with product updates, identify properly licensed systems and allows us to keep in touch with you. We may also send you information on new products we are developing. We will not sell or give your name to any other firm. Thank you.

Fill out and return the attached licensing card.

MARINCO SHORE POWER CABLE SET

INSTRUCTION SHEET

WARNING - To minimize shock hazard, connect and disconnect cable as follows:

1. Turn off the boat's shore connection switch before connecting or disconnecting shore power cable.
2. Connect shore power cable at the boat first.
3. If polarity warning indicator is activated, immediately disconnect cable and have the fault corrected by a qualified electrician.
4. Disconnect shore-power cable at shore outlet first.
5. Close inlet cover tightly.

DO NOT ALTER SHORE-POWER CABLE CONNECTORS.

STORAGE

Your MARINCO shore power cable set is intended for use outdoors. To prolong the life of the set, store indoors when not in use.

MAINTENANCE

WARNING - To prevent electrocution, always disconnect from power source before performing maintenance.

General:

The metallic parts of your MARINCO cable set are made to resist corrosion. In salt water environments, use of the product can be increased by periodically wiping the exposed parts with fresh water, drying and spraying with a moisture repeller. A salted cable can be cleaned with grease cutting household detergent. A periodic application of vinyl protector will help both ends and cable maintain their original appearance.

In case of Salt Water Ingression:

Rinse plug end and/or connector end thoroughly in fresh water, shake or blow out excess water and allow to dry. Spray with a moisture repellent before re-use.

REPAIR

If either plug or connector end requires replacement (equipment or molded type), it can be replaced with the following MARINCO device:

CABLE RATING	PLUG	COVER	CONNECTOR	COVER
30A-125V 2 pole, 3 wire	30SCR2P	102	30SCR2C	103R
30A-125 V 2 pole, 3 wire	6361CR	7117	6360CR	7115CR
30A-125/250V 3 pole, 4 wire	6365CR	7117	6364CR	7112CR

USER'S GUIDE

VIGIL RT-80
VHF Radio

Table of Contents

Specifications	1
Introduction	2
Equipment Supplied	2
Optional Equipment	2
Installation	
Mounting Methods	3
Speaker Mounting	3
Microphone Mounting Plate	3
Electrical Wiring	4
Speaker Wiring	4
Operation	
General Information	5
Normal Mode	6
Memory Mode	6
Priority Mode	7
16 Mode	7
WX Mode	7
Hall Mode	7
ICM (Intercom) Mode	8
Pushbutton Functions	8
Programmable Channels	9A
Channel Usage	
USA Channel Usage Chart	10
International Channel Usage Chart	12
Weather Channel Usage Chart	13
Operating Techniques	
Warranty	14
	15

Specifications

General

Compliance: FCC Regulations Parts 15, 80, 805 and 807
Canadian Regulations DCC, CAT V

Channels:

All US and International (ITU Appendix 19)

10 Watters:

42 Programmable

Frequency Range:

Transmit - 156.000 to 159.175 MHz
Receive - 156.025 to 163.775 MHz

Frequency Stability: $\pm 0.01\%$ from -20°C to $+50^{\circ}\text{C}$

Input Power:

11-18 VDC (13.8 VDC Nominal)

0.6 Ampere Receive

6 Amperes Transmit

Operating Temperature Range: -20°C to $+50^{\circ}\text{C}$

Transmitter

Power Output: 1 or 25 watts selectable

Modulation: Frequency Modulated (FM)

Modulation Limiting: ± 5 kHz deviation

Spurious Emissions:

-70 dB @ 25 watts output

-56 dB @ 1 watt output

Output Impedance: 50 Ohms

Antenna Mismatch:

Built in VSWR protection with fault warning

Amplifier

Audio:

Less than 10% distortion at 3 kHz deviation,
 $+8$ dB per octave pre-emphasis

Physical

Width: 4-3/8 inches

Height: 4-3/8 inches

Depth: 6 inches

Weight: 3-3/4 pounds

HalfWattercorn Output:

8 watts into external 8 ohm speaker with less
than 10% distortion @ 14.5 VDC input

16 watts into external 4 ohm speaker with less
than 10% distortion @ 14.5 VDC input

Audio:

-8dB per octave de-emphasis. Less than 1.0%
distortion at 8.5 watts to external speaker

Spurious Response: -70 dB min

Squelch Threshold: 0.20 μV max

Selectivity: -6 dB max at 7.5 kHz

Sensitivity: 0.25 μV max for 12 dB S/N

Receiver

Introduction

These forms are available at any FCC field office, or by writing to the Federal Communications Commission, P.O. Box 1020, Gettysburg, PA 17326.

Equipment Supplied

VHF Radiotelephone with Power Cable, Output Cable, Microphone Cable, and Hall and Intercom Speaker Cables attached.

Mounting Spacer

Waterproof Microphone

Microphone Mounting Plate

Waterproof Speaker with mounting bezel

Mounting Hardware

Optional Equipment

Hall Speaker

Intercom Speaker

The RT-80 is a fully waterproof, digitally synthesized FID transceiver operating in the frequency range of 155-163 MHz and can provide reliable communications between ships, and from ships to public or private shore stations. It is capable of operating on all USA, International and Weather channels and in addition, may be programmed to operate on 42 additional channels (U.S. models only).

It can receive 10 weather channels which include all U.S., NOAA and Canadian channels.

The transceiver is a panel mounted design allowing the user to custom install it into the vessel's instrument panel. A spacer is provided to allow the user to control the "thickness" of the bezel to further customize the installation and match other instruments that may be also installed in the panel.

Channel Number and status annunciations are provided on a liquid crystal display (LCD) which is lighted for low ambient light conditions.

An external waterproof microphone and speaker are provided.

In addition, the transceiver contains both a powerful marine and intercom system that may be used with optional speakers.

License Requirements

All radio stations aboard US flag vessels must be licensed by the Federal Communications Commission. A marine VHF station license is obtained by submitting FCC form 505 to the Federal Communications Commission, Gettysburg, PA. This form includes a temporary operating authorization which will allow you to use your RT-80 while the FCC is processing your license application.

Operator License

If you plan to only sail in domestic or international waters without docking in any foreign port, you do not need an operator's permit. If however, you plan to dock in a foreign port, you must have, at least, a RESTRICTED RADIO/TELEPHONE OPERATORS PERMIT.

To obtain this permit you must file FCC form 753. There is no test requirement and the permit is good for a lifetime.

Installation

Mounting Methods

The RT-80 can be mounted in basically two ways. The first mounting method places the mounting spacer on the back of the unit which will space the RT-80 up to the same height as some other instruments.

The second method drops the unit all the way down to the Redline Gasket which is placed directly against the instrument panel.

Mounting

Tap the template provided onto the mounting surface and mark the center. Using this center mark, drill or cut a 4 inch hole into the mounting surface. Drill four 1/16" holes (one in each corner) into the mounting surface.

Mounting with Spacer

If the spacer is to be used, feed all the wires coming from the back of the RT-80 through the Redline gasket, through the spacer and then through the hole in the panel. Apply a thin film of non-corrosive Silicone Beading (GE Silicone II or equal) to the back of the mounting spacer.

Secure the RT-80 to the mounting surface with the four stainless screws provided. Do not overtighten. See figure 1.




FIGURE 1

Mounting without Spacer

If the spacer is not to be used, feed all the wires coming from the back of the RT-80 through the Redline gasket and then through the hole in the panel.

Secure the RT-80 to the mounting surface with the four stainless screws provided. Do not overtighten.

Plastic Plugs

After the RT-80 is mounted by either of the above methods, press the four plastic plugs (provided) into the screw holes on the face of the Radio. This will hide the screws and provide a clean look to the RT-80.

Speaker Mounting

Select a location for the external speaker provided with the RT-80. This location should be at least 3-4 feet away from any compass on the vessel, including autopilots, sat-ravs, etc. The chosen location should position the speaker in such a way as to ensure that it can be easily heard by the operator while the vessel is underway.

The speaker can be mounted either as a surface mount by using the spacer provided, or by drilling a hole through the instrument panel and "flush" mounting it.

Through Instrument Panel

Using this center mark in the template, drill or cut a 4 inch hole into the mounting surface. Pass the speaker wire through the Redline gasket and then through the mounting hole.

Carefully position the speaker on the panel and using the speaker (seat as a guide, drill four 1/8" holes (one in each corner) into the mounting surface.

Secure the speaker to the mounting surface with the four stainless screws provided. Do not overtighten.

Surface Mount

Drill a 1/4" hole at the location of the hole in the lower left hand side of the mounting spacer. This

channel scanning function. When the SCAN function is ON, the SCAN Annunciator will be displayed on the LCD.

Please note that when the SCAN is turned off, then on again, scanning will start from the displayed channel upward.

ALL CHANNEL SCAN

To initiate ALL CHANNEL SCAN, first select the NORM mode and then press the SCAN button. This will first scan all US channels and then all INTL channels continuously. When activity is detected on a channel, scanning will stop until 1 second after activity ceases. Scanning of all channels will then resume.

To halt the scanning, either press the SCAN button, rotate the Channel Select Knob or press the microphone button. If the mic is keyed while in the SCAN mode, the SCAN mode will be canceled, and the RT-80 will transmit on the displayed frequency.

MEMORY SCAN

To activate the MEMORY scan mode, it is first necessary to store desired channels into the memories. See the MEM mode section for details on how to do this.

To select MEMORY SCAN mode first select MEM SCAN button. This will cause the RT-90 to scan all of the channels programmed into the memory. Any blank memories (not programmed by the user) will be skipped. When activity is detected on a channel, scanning will stop until 1 second after activity ceases. MEMORY SCAN will then resume. Scanning may be stopped by pressing the SCAN button again, turning the Channel Select Knob or by pressing the microphone button.

If the mic is keyed while in the MEMORY SCAN mode, the SCAN mode will be cancelled, and the RT-80 will transmit on the displayed frequency.

WX SCAN

To activate the WX SCAN mode, select WX by turning the Function Knob. Press the SCAN button and the RT 80 will scan all 10 weather channels until one is found with activity.

When the microphone push-to-talk button is pressed, the operator's voice will be amplified and sent to the optional hall speaker. To increase or decrease the HALL volume, turn the VOL Knob as you would the radio volume in the NORM mode.

All receive and transmit functions of the radio are disabled when operating in this mode.

ICM Mode

The use of the Intercom (ICM) mode will allow the operator to communicate with an optional remote anywhere else in the vessel. Turn the Function Knob to ICM. "IC" will be displayed on the LCD to indicate that the Intercom mode is in use and that normal receive and transmit functions disabled. The Volume Knob will control the volume coming from and going to the optional external intercom speaker.

To talk to the remote station, simply press the microphone push-to-talk and speak into the microphone. To listen for a reply, release the button.

Pushbutton Functions

Refer to Figure 3 for the location of all pushbuttons.

DIM Button

The Liquid Crystal Display (LCD) may be lit for night use by pressing the DIM button until the desired illumination intensity is achieved. There are four levels of brightness available, LOW, MEDIUM, HIGH and OFF. Successive presses of the DIM button will increment through the four available levels.

U/I Button

The use of this button will allow the user to toggle between US and International channels. The LCD will display either USA or INTL depending on which type is selected by the user.

This key also functions as the LEFT ARROW Key in certain modes of operation (such as MEM and PRI). See these sections for details on this alternate action.

SCAN Button

There are four different modes of scanning available in the RT-90. These are the ALL CHANNEL, MEMORY, PRIORITY and WEATHER. The SCAN button alternately turns on and off the

To exit this mode, either press the SCAN button again, or rotate the Channel Select Knob.

PRIORITY SCAN

The PRIORITY SCAN is commonly used to maintain a listening watch on channel 16 (the calling and distress channel), while operating on some other channel. In addition, the RT-80 allows the operator to select a different priority channel. To program the priority channel and/or the normal channel see the PRI mode section of this manual.

The PRIORITY SCAN function allows the user to monitor any two channels at the same time. One channel is the currently selected channel (Normal) and the other is a predetermined priority channel.

In the PRIORITY Mode, the RT-80 will switch from the selected channel to the priority channel once each second to check for a squelch break. If the priority channel is active, the RT-80 will stay on the channel until activity stops.

The transceiver will then resume checking both channels for traffic. While in the priority mode, the RT-80 will only transmit on the selected non-priority channel (the Normal channel). However, if the microphone is keyed while there is a squelch break on the priority channel, the radio will transmit on the priority channel and the Scan mode will be cancelled.

The Function Knob should be turned to PRI and then the SCAN button is pressed to activate the PRIORITY SCAN mode. The LCD will show the Normal (non-priority) channel in the left window and the priority channel in the right window. The RT-80 and the SCAN Annunciators will be displayed.

Please note that the unit switches very quickly from the active normal channel to the priority channel and may be difficult at times to tell that the scanning is actually occurring unless the LCD is displaying the SCAN Annunciator.

The PRIORITY SCAN mode is alternately engaged and disengaged by pressing the SCAN button.

The SCAN button also functions as the RIGHT ARROW button in some modes to exit from certain programming modes. See MEM and PRI Mode sections for details of this alternate action.

H/L BUTTON

The H/L button toggles the transmitter output power between 1 watt and 25 watts. To turn the low power mode on or off, press the H/L button. The LCD will indicate LOW when the transmitter power is reduced to 1 watt.

On certain channels (such as 13 and 57), the output power is automatically set to 1 watt by the microprocessor in the RT-80. To override the microprocessor, press and continue to hold down the H/L button during the entire transmission. If the H/L button is released at any time during the transmission, the RT-80 will revert the power to the 1 watt setting.

Channels 15, 17, 75 and 78 have the output power limited to 1 watt, but can be switched to High Power with the H/L button just like the other channels. They just default to 1 watt initially.

Programmable Channels

The Programmable Channel Mode allows the user to the RT-80 to assign any frequency between 156.025 and 159.175 Mhz to Channels 29 to 59 or channels 89 to 99. This will allow the RT-80 to accommodate any future frequency allocations without modification. In programming these new channels note that the channel spacing must be maintained at 25 KHz.

Important Notice!!!
The use of unauthorized channels can cause harmful interference to Safety Services other than the marine service.

The Programmable Channel Mode allows the user to the RT-80 to assign any frequency between 156.025 and 159.175 Mhz to Channels 29 to 59 or channels 89 to 99. This will allow the RT-80 to accommodate any future frequency allocations without modification. In programming these new channels note that the channel spacing must be maintained at 25 KHz.

Press the button below the RIGHT ARROW to accept the data and to exit back to the Channel Select mode. The new data will have been stored in the RT-80's electronic memory, and the radio will remain in the Channel Programming mode. After storing the new data above, you may select another programmable channel to be reviewed or changed by rotating the Channel Select Knob to the desired channel.

You may exit the Channel Programming mode at any time by pressing the button below the RIGHT ARROW. If terminating from the left window, you must press this button below the RIGHT ARROW twice.

Entering the Programmable Channel Program Mode

To enter this mode, hold down the UI and SCAN key simultaneously for approximately 2 seconds until 29 is shown in the right hand display. The RT-80 is now in the Programmable Channel Programming Mode.

Reviewing Stored Data

To review the frequency information stored for a programmable channel, enter the desired channel number in the right hand display by rotating the Channel Select Knob. The programmed data will be displayed in the left hand digits.

If the selected channel was not previously programmed, the data in the left display will show as 00. At this point, you may store new information, review another channel, or exit the Programming Mode.

Storing Information

To store new data in a programmable channel, press the button below the LEFT ARROW to activate the left display digits. The left display will begin flashing to indicate that new data is expected.

Rotate the Channel Select Knob to change the data in the display to the data from Table 1 that corresponds with the desired frequency of operation.

Programmable Channel

TABLE 1

Frequency Simplex Duplex Frequency Simplex Duplex Frequency Simplex Duplex

156.000	N/A	80	157.075	2B	AB	158.150	58	58
156.225	01	81	157.100	2C	AC	158.175	57	57
156.450	02	82	157.125	2D	AD	158.200	58	58
156.675	03	83	157.150	2E	AE	158.225	59	59
156.900	04	84	157.175	2F	AF	158.250	5A	5A
157.125	05	85	157.200	30	B0	158.275	5B	5B
157.375	06	86	157.225	31	B1	158.300	5C	5C
157.625	07	87	157.250	32	B2	158.325	5D	5D
157.875	08	88	157.275	33	B3	158.350	5E	5E
158.125	09	89	157.300	34	B4	158.375	5F	5F
158.375	0A	8A	157.325	35	B5	158.400	60	60
158.625	09	03	157.350	36	B6	158.425	61	61
158.875	0C	8C	157.375	37	B7	158.450	62	62
159.125	0D	8D	157.400	38	B8	158.475	63	63
159.375	0E	8E	157.425	39	B9	158.500	64	64
159.625	0F	8F	157.450	3A	BA	158.525	65	65
159.875	10	80	157.475	3B	BB	158.550	66	66
160.125	11	01	157.500	3C	BC	158.575	67	67
160.375	12	92	157.525	3D	BD	158.600	68	68
160.625	13	93	157.550	3E	BE	158.625	69	69
160.875	14	94	157.575	3F	BF	158.650	6A	6A
161.125	15	95	157.600	40	C0	158.675	6B	6B
161.375	16	96	157.625	41	C1	158.700	6C	6C
161.625	17	97	157.650	42	C2	158.725	6D	6D
161.875	18	98	157.675	43	C3	158.750	6E	6E
162.125	19	99	157.700	44	C4	158.775	6F	6F
162.375	1A	9A	157.725	45	C5	158.800	70	70
162.625	1B	9B	157.750	46	C6	158.825	71	71
162.875	1C	9C	157.775	47	C7	158.850	72	72
163.125	1D	9D	157.800	48	C8	158.875	73	73
163.375	1E	9E	157.825	49	C9	158.900	74	74
163.625	1F	9F	157.850	4A	CA	158.925	75	75
163.875	20	A0	157.875	4B	CB	158.950	76	76
164.125	21	A1	157.900	4C	CC	158.975	77	77
164.375	22	A2	157.925	4D	CD	159.000	78	78
164.625	23	A3	157.950	4E	CE	159.025	79	79
164.875	24	A4	157.975	4F	CF	159.050	7A	7A
165.125	25	A5	158.000	50	D0	159.075	7B	7B
165.375	26	A6	158.025	51	D1	159.100	7C	7C
165.625	27	A7	158.050	52	D2	159.125	7D	7D
165.875	28	A8	158.075	53	D3	159.150	7E	7E
166.125	29	A9	158.100	54	D4	159.175	7F	7F
166.375	2A	AA	158.125	55	D5			

N/A is Not Available, 156.000 is not available because 00 code indicates a blank programmable channel. Duplex indicates that the received frequency is 4.6 MHz above the transmit frequency listed in the left column.

Channel Usage

United States VHF Marine Channel Usage Chart

CHANNEL	CHANNEL ASSIGNMENT	RECEIVER FREQ (MHZ)	TRANSMITTER FREQ (MHz)
01	Port Operations	158.050	158.050
02	Port Operations	158.100	158.100
03	Inter-Ship & Coast to Coast	158.150	158.150
04	Port Operations	158.200	158.200
05	Port Operations, Inter-Ship, Coast to Coast	158.250	158.250
06	Ship to Ship, Safety Only	158.300	158.300
07	Commercial, Inter-Ship, Ship to Coast	158.350	158.350
08	Commercial Ship to Ship	158.400	158.400
09	Commercial & Non-Commercial Ship to Ship, Ship to Coast	158.450	158.450
10	Commercial & Non-Commercial Ship to Ship, Ship to Coast	158.500	158.500
11	Commercial & Non-Commercial Ship to Ship, Ship to Coast	158.550	158.550
12	Port Operations Ship to Ship, Ship to Coast	158.600	158.600
13	Navigation, Ship to Ship	158.650	158.650
14	Port Operations Ship to Ship, Ship to Coast	158.700	158.700
15	Environmental Ship to Ship, Ship to Coast	158.750	158.750
16	DISTRESS, SAFETY, CALLING	158.800	158.800
17	State Control	158.850	158.850
18	Commercial Ship to Ship, Ship to Coast	158.900	158.900
19	Commercial Ship to Ship, Ship to Coast	158.950	158.950
20	Port Operation Ship to Ship, Ship to Coast	161.500	161.500
21	US Government Only Ship to Ship, Ship to Coast	157.050	157.050
22	US Coast Guard Liaison	157.100	157.100
23	US Government Only	157.150	157.150
24	Public Correspondence	161.800	161.800
25	Public Correspondence	161.850	161.850
26	Public Correspondence	161.900	161.900
27	Public Correspondence	161.950	161.950
28	Public Correspondence	162.000	162.000
29	Public Correspondence	162.050	162.050
30	Public Correspondence	162.100	162.100
31	Public Correspondence	162.150	162.150
32	Public Correspondence	162.200	162.200
33	Public Correspondence	162.250	162.250
34	Port Operations	158.175	158.175
35	Port Operations	158.275	158.275
36	Port Operations	158.325	158.325
37	Commercial, Missesport, River	158.375	158.375
38	Non-Commercial	158.425	158.425
39	Non-Commercial	158.475	158.475
40	Digital Selective Calling (Do Not Use as a Working Channel)	158.525	158.525
41	Non-Commercial	158.575	158.575
42	Non-Commercial	158.625	158.625
43	Non-Commercial	158.675	158.675
44	Port Operations	158.725	158.725
45	Port Operations	158.825	158.825
46	Port Operations	158.925	158.925
47	Port Operations	159.025	159.025
48	Port Operations	159.125	159.125
49	Port Operations	159.225	159.225
50	Port Operations	159.325	159.325
51	Port Operations	159.425	159.425
52	Port Operations	159.525	159.525
53	Port Operations	159.625	159.625
54	Port Operations	159.725	159.725
55	Port Operations	159.825	159.825
56	Port Operations	159.925	159.925
57	Port Operations	160.025	160.025
58	Port Operations	160.125	160.125
59	Port Operations	160.225	160.225
60	Port Operations	160.325	160.325
61	Port Operations	160.425	160.425
62	Port Operations	160.525	160.525
63	Port Operations	160.625	160.625
64	Port Operations	160.725	160.725
65	Port Operations	160.825	160.825
66	Port Operations	160.925	160.925
67	Port Operations	161.025	161.025
68	Port Operations	161.125	161.125
69	Port Operations	161.225	161.225
70	Port Operations	161.325	161.325
71	Port Operations	161.425	161.425
72	Port Operations	161.525	161.525

Channel Usage

United States VHF Marine Channel Usage Chart

CHANNEL	CHANNEL ASSIGNMENT	RECEIVER FREQ (MHz)	TRANSMITTER FREQ (MHz)
73	Port Operations Ship to Ship, Ship to Coast	158.875	158.875
74	Port Operations Ship to Ship, Ship to Coast	159.725	159.725
75	Guard Channel	158.775	158.775
76	Guard Channel	158.825	158.825
77	Port Operations Ship to Ship	158.875	158.875
78	Non-Commercial	158.925	158.925
79	Commercial	158.975	158.975
80	Ship to Ship, Ship to Coast Commercial	157.025	157.025
81	US Government Only	157.075	157.075
82	US Government Only	157.125	157.125
83	US Government Only	157.175	157.175
84	Public Correspondence	157.825	157.825
85	Public Correspondence	157.875	157.875
86	Public Correspondence	157.925	157.925
67	Public Correspondence	161.975	161.975
68	Commercial Ship to Ship	167.425	167.425

* 1 West in Italy

** 4 MHz will manual over to 28 MHz

Channel Usage

International VHF Marine Channel Usage Chart

CHANNEL	CHANNEL ASSIGNMENT	RECEIVER FREQ (MHZ)	TRANSMITTER FREQ (MHZ)
01	Port Operations	160.650	155.050
02	Port Operations	160.700	155.100
03	Public Correspondence	160.750	155.150
04	Port Operations	160.800	155.200
05	Port Operations	160.850	155.250
06	Ship to Ship Safety Only	160.900	155.300
07	Public Correspondence	160.950	155.350
08	Commercial	161.000	155.400
09	Port Operations	161.050	155.450
10	Port Operations	161.100	155.500
11	Port Operations	161.150	155.550
12	Port Operations	161.200	155.600
13	Port Operations	161.250	155.650
14	Port Operations	161.300	155.700
15	On Board Communications	161.350	155.750
16	Distress, Safety, Calling	161.400	155.800
17	On Board Communications	161.450	155.850
18	Port Operations	161.500	155.900
19	Port Operations	161.550	155.950
20	Port Operations	161.600	156.000
21	Port Operations	161.650	156.050
22	Port Operations	161.700	156.100
23	Public Correspondence	161.750	156.150
24	Public Correspondence	161.800	156.200
25	Public Correspondence	161.850	156.250
26	Public Correspondence	161.900	156.300
27	Public Correspondence	161.950	156.350
28	Public Correspondence	162.000	156.400
29	Port Operations	162.050	156.450
30	Port Operations	162.100	156.500
31	Port Operations	162.150	156.550
32	Port Operations	162.200	156.600
33	Port Operations	162.250	156.650
34	Port Operations	162.300	156.700
35	Port Operations	162.350	156.750
36	Port Operations	162.400	156.800
37	Port Operations	162.450	156.850
38	Port Operations	162.500	156.900
39	Port Operations	162.550	156.950
40	Port Operations	162.600	157.000
41	Port Operations	162.650	157.050
42	Port Operations	162.700	157.100
43	Public Correspondence	162.750	157.150
44	Public Correspondence	162.800	157.200
45	Public Correspondence	162.850	157.250
46	Public Correspondence	162.900	157.300
47	Public Correspondence	162.950	157.350
48	Public Correspondence	163.000	157.400
49	Public Correspondence	163.050	157.450
50	Public Correspondence	163.100	157.500
51	Government Only	157.075	157.075
52	Government Only	157.125	157.125
53	Government Only	157.175	157.175
54	Public Correspondence	157.225	157.225
55	Public Correspondence	157.275	157.275
56	Public Correspondence	157.325	157.325
57	Public Correspondence	157.375	157.375
58	Port Operations	156.425	156.425
59	Port Operations	156.475	156.475
60	Port Operations	156.525	156.525
61	Port Operations	156.575	156.575
62	Port Operations	156.625	156.625
63	Port Operations	156.675	156.675
64	Port Operations	156.725	156.725
65	Port Operations	156.775	156.775
66	Port Operations	156.825	156.825
67	Port Operations	156.875	156.875
68	Port Operations	156.925	156.925
69	Port Operations	156.975	156.975
70	Commercial	156.025	156.025
71	Port Operations	156.075	156.075
72	Commercial	156.125	156.125
73	Port Operations	156.175	156.175
74	Port Operations	156.225	156.225
75	Port Operations	156.275	156.275
76	Port Operations	156.325	156.325
77	Commercial	156.375	156.375
78	Port Operations	156.425	156.425
79	Port Operations	156.475	156.475
80	Ship to Ship, Ship to Coast	157.025	157.025
81	Government Only	157.075	157.075
82	Government Only	157.125	157.125
83	Government Only	157.175	157.175
84	Public Correspondence	157.225	157.225
85	Public Correspondence	157.275	157.275
86	Public Correspondence	157.325	157.325
87	Public Correspondence	157.375	157.375

Channel Usage

International VHF Marine Channel Usage Chart

CHANNEL	CHANNEL ASSIGNMENT	RECEIVER FREQ (MHZ)	TRANSMITTER FREQ (MHZ)
79	Port Operators	181.575	156.975
80	Port Operators	181.825	157.025
81	Port Operators	161.675	157.075
82	Port Operators	181.725	157.125
83	Public Correspondence	181.775	157.175
84	Public Correspondence	161.825	157.225
85	Public Correspondence	181.875	157.275
86	Public Correspondence	161.925	157.325
87	Public Correspondence	181.975	157.375
88	Public Correspondence	162.025	157.425

* 1 Watt Int'l only

VHF Marine Weather Channel Usage Chart

CHANNEL	CHANNEL ASSIGNMENT	RECEIVER FREQ (MHZ)	TRANSMITTER FREQ (MHZ)
WX0	NOAA Weather	163.275	162.400
WX1	NOAA Weather	162.550	162.475
WX2	NOAA Weather	162.475	162.400
WX3	NOAA Weather	162.425	162.350
WX4	NOAA Weather	162.475	162.400
WX5	NOAA Weather	162.425	162.350
WX6	NOAA Weather	162.475	162.400
WX7	NOAA Weather	162.425	162.350
WX8	NOAA Weather	162.475	162.400
WX9	NOAA Weather	162.425	162.350
WX9	Canadian Weather	161.850	161.775
WX9	Environmental Weather	161.850	161.775

Transition on Weather Frequencies is not allowed

Operating Techniques

Monitor Channel 16 if your radio is turned on and not in use. This channel is monitored 24 hours a day by the Coast Guard. If help is needed, it can be on its way in short order, either from the Coast Guard or by other vessels in your area. **MAYDAY** is the distress call. Use **MAYDAY** only if there is an immediate danger of loss of life or property. A vessel simply running out of fuel does not constitute such a situation.

PAN is the urgency signal. It is pronounced "paw". It is used when the safety of a person or vessel is in jeopardy. **Pan** has priority over all other traffic except distress (**MAYDAY**) traffic. **SECURITY** is the safety signal. It is used for messages concerning the safety of navigation or giving storm warnings.

Example Distress Call
 "Mayday, Mayday, Mayday, this is the yacht Nora A, Nora A, Nora A - Have struck a log and am taking on water - Position is 17°16 North of Can #13 off Eatons Neck - 4 persons on board and need immediate assistance - Over"

Example Urgency Call
 "Pan, Pan, Pan, this is the yacht Nora A, Nora A, Nora A - Have run out of fuel at Can #13 off Eatons Neck - I have anchored but need assistance - Over"

Phonetic Alphabet	
A - ALPHA	M - MIKE
B - BRAVO	L - LIMA
C - CHARLIE	K - KILO
D - DELTA	J - JULIET
E - ECHO	I - INDIA
F - FOXTROT	H - HOTEL
G - GOLF	G - GOLF
H - HOTEL	F - FOXTROT
I - INDIA	E - ECHO
J - JULIET	D - DELTA
K - KILO	C - CHARLIE
L - LIMA	B - BRAVO
M - MIKE	A - ALPHA
N - NOVEMBER	O - OSCAR
O - OSCAR	P - PAPA
P - PAPA	Q - QUEBEC
Q - QUEBEC	R - ROMEO
R - ROMEO	S - SIERRA
S - SIERRA	T - TANGO
T - TANGO	U - UNIFORM
U - UNIFORM	V - VICTOR
V - VICTOR	W - WHISKEY
W - WHISKEY	X - X-RAY
X - X-RAY	Y - YANKEE
Y - YANKEE	Z - ZULU
Z - ZULU	

Your VIGIL RT-80 VHF Transceiver is easy to use and very reliable. The increasing popularity of such equipment has led to areas where the signal radio techniques when you are transmitting will help to reduce the congestion. Below are a few tips or hints which will help everyone using the Marine VHF Service.

Listen BEFORE you transmit. Assume that you will not interfere with traffic already in progress on the channel.

Give absolute priority to Distress Calls. Continue to listen but do not transmit in response to a distress call unless you are in a position to help. **Agree on a working channel,** and switch to that channel as soon as you have established contact on the calling channel (6. All calls on channel 16 should be less than 30 seconds long.

Wait 2 minutes before calling another station again after getting no response to your first call. Keep transmissions short as possible and still get your message across. Use professional operating procedures. This is not a CB band. Do not use profanity. It is illegal.

Do not transmit false distress signals. The FCC takes a dim view of this and violators may be prosecuted under FCC regulations, which carry a maximum fine of \$10,000 and a year in prison. Keep your equipment in good working order. Have it checked periodically by a qualified licensed technician. Radiotelephone conversations are private. It is unlawful to make use of any information intended for others.


Register with your local Coast Station. If you plan to use the Marine Operator Services in your area, it is a good idea to register your station with them. It provides billing information to them and saves much time on the air. The helmsman of each commercial vessel must monitor Channel 13. Don't hesitate to call if there is any doubt about either his or your navigation.

Warranty

The VIGIL RT-80 is fully guaranteed to be free from defects in material or workmanship for two years from date of purchase. Claims under warranty must be accompanied by a copy of proof of purchase.


Please include your name and address, the serial number of the instrument and the reason for return.

IMI VIGIL Electronics
Customer Service Department
New Whitfield Street
Guilford, CT 06437
(800)-CALL IMI
(203) 453-4374




Microphone Mounting Plate

Radio Drilling Template



Speaker Drilling Template



Speaker Drilling Template

ELECTRONICS

INI VIGIL

THE I/O PERFORMANCE TEAM: ADELBERG • ALLEN • ALTMAN • AMERICA • BARBER • COMBI
FRANCOIS • HAN • ISOMIT • KENNY • KATLYN • KENNON • SPAIN • SPANBORGH • VIGIL ELECTRONICS

INI VIGIL Electronics
Post Office Box 308
New Whitfield Street,
Gutford, CT 06437

TEL: (800) 225-5464 • (203) 453-4874

SURE POWER MULTI-BATTERY ISOLATOR APPLICATION AND

INSTALLATION INSTRUCTIONS

The installation of a Sure Power multi-battery isolator is quite simple as long as you carefully read and understand these instructions and most importantly, view the application chart below, before you begin.

First, make sure you have all the tools, wire, connectors and circuit breakers you will need. Sure Power offers a range of isolator wiring kits that make the job a snap. See the table that follows for the "right kit" for your installation.

For optimum system performance it is recommended that a battery located "Deep Cycle" be used in the auxiliary position. Finally, Sure Power multi-battery isolators are designed for alternator systems with negative ground, and batteries of the same nominal voltage. Batteries of differing voltages cannot be used. For positive ground systems, marine outboard systems, or heavy duty truck systems, contact Sure Power for the proper isolator for your specialized application.

PLEASE READ INSTRUCTIONS COMPLETELY PRIOR TO STARTING INSTALLATION

MULTI-BATTERY ISOLATOR APPLICATION CHART

ALTERNATOR TYPE	SURE POWER MODEL NUMBER		RECOMMENDED WIRE SIZE	
	MAXIMUM	ALTERNATOR OUTPUT	UP TO	25 FT TO 30 FT

GROUP #1 Original Equipment Delco (GM), except Delco GM CS series alternators (CS series used on most 1985 and newer GM vehicles), Motorcraft (Ford) A1 models, all years; Mopar (Chrysler) A1 models, all years; Japanese imports with external sensing alternators using external voltage regulator or Motorola Load Handler Series GM Remote Sense Series.	Up to 70 Amps	702	#8 ga. 50 Amp	#8 ga. 50 Amp	(1)	15 Ft. to 20 Ft.	25 Ft. to 30 Ft.
	Up to 95 Amps	\$52 or \$523A	#8 ga. 50 Amp or 50 Amp	#6 ga. 50 Amp or 50 Amp	(1) (5)	20 Ft. to 25 Ft.	25 Ft. to 30 Ft.
	Up to 120 Amps	1202 or 1203A	#6 ga. 80 Amp or 80 Amp	#4 ga. 80 Amp or 80 Amp	(7) (5)	20 Ft. to 25 Ft.	25 Ft. to 30 Ft.
	Up to 160 Amps	1602	#7 ga. 120 Amp	#2 ga. 120 Amp or 120 Amp	(7)	20 Ft. to 25 Ft.	25 Ft. to 30 Ft.

GROUP #2 Delco (GM) equipped with Delco GM CS series alternators (most 1985 and newer), Deep vehicles equipped with Delco GM CS series alternators (most 1985 and newer), Toyota 1985 and newer equipped with Nippondenso alternator	Up to 95 Amps	\$523A**	#8 ga. 50 Amp	#6 ga. 50 Amp	(1)	15 Ft. to 20 Ft.	25 Ft. to 30 Ft.
	Up to 120 Amps	1203A**	#6 ga. 80 Amp	#4 ga. 80 Amp	(4)	20 Ft. to 25 Ft.	25 Ft. to 30 Ft.

GROUP #3 Motorola (other than Load Handler) Boech (requiring regulator sensing)	Up to 70 Amps	703R	#8 ga. 50 Amp	#8 ga. 50 Amp	(3)	15 Ft. to 20 Ft.	25 Ft. to 30 Ft.
	Up to 95 Amps	952R	#8 ga. 50 Amp	#6 ga. 50 Amp	(1)	20 Ft. to 25 Ft.	25 Ft. to 30 Ft.
	Up to 120 Amps	1203R	#5 ga. 80 Amp	#4 ga. 80 Amp	(7)	20 Ft. to 25 Ft.	25 Ft. to 30 Ft.

All Group #3 isolators may also be used in Group #1 applications - except the "R" terminal.

GROUP #4
For alternators with internal voltage sensing in some Mitsubishi and Hitachi, or Delco alternators.
A SOLENOID PRIORITY SYSTEM, NOT AN ELECTRONIC ISOLATOR

GENERAL INSTALLATION INSTRUCTIONS RELEVANT TO ALL SIZES OF ISOLATORS,

INCLUDING THOSE SHOWN ON THE SIMPLIFIED APPLICATION CHART,

CAUTION: IF YOU ARE INSTALLING AN ISOLATOR ON A TOTAL ALTERNATOR GROUP TYPE (A) SEE SPECIAL TOYOTA INSTRUCTION. IF YOU ARE INSTALLING AN ISOLATOR ON A MOTOROLA OR BOSCH (A) TERMINATOR GROUP TYPE (B) SEE SPECIAL MOTOROLA AND BOSCH INSTRUCTIONS BEFORE DISCONNECTING ANY PART OF THE EXISTING SYSTEM.

SURE POWER MULTI-BATTERY ISOLATOR INSTALLATION INSTRUCTIONS.

1. You need only a simple tool to install your isolator - See Appendix A for driver's set.



- Nut with 1/8" ID
- Wire stripper
- Driver - Open end
- Wrench set - 3/8"
- Flat driver

2. You will also need an adequate length of automotive grade wiring for terminals and built-in connectors. Use the Isolator Wire Size chart to determine the proper size and type.




We also recommend the use of a circuit breaker when applicable to protect your auxiliary battery circuit. See application chart for battery circuit. See application chart for the proper size and type.

3. To avoid possible electrical shock and injury, remove the wire from the negative (-) terminal of the vehicle's battery. Do not let the engine start with the battery disconnected. Do not connect the negative (-) lead of each coil to any other coil. Do not let the engine start with the battery disconnected. Do not connect any terminal wires and do not make rear the battery or engine compartment.

4. Mount the isolator in a convenient location as near to the alternator as possible end away from the exhaust manifold. An external manifold, if low for proper ventilation, do not remove on the engine. Drill 1/2" holes and mount provided.



5. Install hardware in the studs in the order shown in diagram, being careful not to over-torque the bottom flange. Failure to install bottom flange may result in jamming and will void warranty.



NUT INSTRUCTION
Install hardware in the studs in the order shown in diagram, being careful not to over-torque the bottom flange. Failure to install bottom flange may result in jamming and will void warranty.

6. Locate the "BAT" terminal at the rear of the alternator. It is usually the largest connection wires include disconnecting the regulator wire. If present from the "BAT" terminal of the alternator, disconnect those battery wires to the "BAT" terminal of the battery isolator. Lengthen the wires, if necessary, by using proper splicing technique. NOTE: Disconnecting or cutting these wires in a location other than at the alternator may result in improper functioning of the charging system.



7. Connect one end of a new wire of the proper size (see Isolator Application Chart - Recommended Wire Size) to the battery. The other end to the alternator. The isolator's "BAT" terminal is located to either of these terminals.



8. Mount a circuit breaker as near to the auxiliary battery as practical, and away from engine or exhaust heat (see application chart). Connect one end of a new wire of the proper size (see Isolator Wire Size Chart) to the "BAT" terminal of the circuit breaker and connect the other end to the positive (+) terminal of the auxiliary battery.





9. For three or four battery isolator applications, install one auxiliary battery connecting terminal "3" to auxiliary battery "3" through its circuit breaker terminal. Connect the other terminal "4" through its circuit breaker, etc.



10. If your installation falls in the ALTERNATOR GROUP (THE A OR B) OTHERWISE PROVIDED TO SPECIFIC TYPES FOR THAT RELEVANT GROUP. IF YOUR INSTALLATION FALLS IN OTHERWISE PROVIDED TO SPECIFIC TYPES FOR THAT RELEVANT GROUP.

11. Connect all of the auxiliary loads (headlights, stereo, wipers, etc.) to the positive post of the auxiliary battery or battery terminal receptacle. The ground cables removed in step 3. Also, make sure the negative (-) terminals of the auxiliary battery are properly grounded with a conventional ground strap.

12. Perform electronic tests (Page 4) to assure proper operation.



SCHEMATICS OF TYPICAL MULTI-BATTERY INSTALLATIONS USING ELECTRONIC ISOLATORS.

GROUP #2 ALTERNATORS (Continued)

TOYOTA, When installing an isolator to a Toyota alternator, follow general installation instructions.


1. Locate the small sensing wire that runs from the alternator to the wiring harness. Check that you have the right wire by stripping a small section of wire and then determining that voltage is present only when the key is in the "run" position but not in the "accessory" position. Do not interrupt wire.

2. After completing Steps 3-8 of general instructions, connect an excitation wire from the point located in Step #1 above, to the "E" terminal of the isolator. **NOTE:** The Group #2 isolator may be used in applications not requiring the excitation by one connecting the "E" terminal.


GROUP #3 ALTERNATORS: Carefully review the individual set errors shown below and then follow the specific installation instructions related to the type of alternator and vehicle with which you are working.

FOR BOSCH ALTERNATOR USING ALTERNATOR MOUNTED REGULATOR SYSTEM (AS USED ON VOLKSWAGEN VANAGONS)

FOR ALTERNATOR EQUIPPED VOLKSWAGEN VANS USING AN EXTERNAL MOUNTED REGULATOR, CONSULT FACTORY.



1. After connecting Step #1 of standard instructions, remove the two screws attaching the regulator to alternator. With great care, remove the regulator. Use a downward, rolling motion to prevent breaking off the brushes. Bend the connector prong of the alternator as illustrated so that it will no longer mate with the internal connection strip of the regulator. (The regulator connector may need to be bent also to insure no contact.)
 2. Strip an appropriate length of wire to the regulator connector. Strip the outer insulation from the wire to the regulator connector. The inner insulation may suggest a set blade to hold the brushes in place. Replace mounting screws from the regulator so it will not be dished or in the way.
 3. Connect the other end of the wire that was soldered or the regulator to the "E" terminal on the isolator.
 4. Disconnect the wire (B) going to the "D" terminal of the alternator. Reconnect these same wire(s) to the "E" terminal of the isolator. The wire connected in Step #5.
- INSTRUCTIONS:**
8. Now proceed to Step #11 of the GENERAL ISOLATOR INSTALLATION.



GENERAL MOTORS DELCOTRON, Before proceeding with any installation it is recommended that you look closely at your Delcotron alternator to determine its type. The average circuit is maintained in close proximity to the output stud - verify that you have the correct size isolator. Delcotron GM Series alternators will be occupying more and more common in the late 1970's on vehicles manufactured by General Motors in North America.

When installing an isolator on a GM "CS" series alternator equipped with a general isolator installation instructions should be followed. However, this alternator requires external excitation and external wiring. An isolator with an excitation terminal "E" and a plug connector (not of type) are required.

The following procedure refers to 3A isolators and installation kit #114 and #115.

1. Locate and remove the plug-in connector from the alternator. This may be done by inserting a small screwdriver under the locking tab.
2. Cut the wires (brown and/or pink/black) at a convenient location within 3" of the connector plug and, **NOTE:** If the existing Delco connector has a wire in the "S" position, replacement of this connector is not necessary. Proceed to Step #7.
3. Remove the rubber dust cover (if installed) from the old plug-in connector and install it on the new plug-in connector provided in the kit #114 or #115.
4. Strip the insulation from the out wire(s) (Step 2) and insert the wires into the plug connector of the new plug-in connector and firmly, making brown and/or pink/black wires). Secure all loose wires.
5. Route the remaining set wire of the plug-in connector to terminal "E" of the bus Power isolation. Do not connect to terminal "E" and the "E" of the wiring terminal supplied. Now connect to terminal "E" of the external excitation connection. The "E" post of the isolator requires connection to an ignition switched source such that power is applied only in the "run" position. **BE SURE POWER IS NOT APPLIED WHEN THE KEY IS SWITCHED TO ACCESSORY POSITION.** On this size vehicle this point may be one of the spare ignition terminals marked "IGN" on the fuse center. Contact one end of the yellow wire strip to one of these spare ignition terminals. Route the other end of the yellow wire to the "E" terminal of the isolator. (If using the recommended 10 amp circuit breaker installed with the kit, insert the circuit breaker in the yellow wire strip on the supplied 40 amp terminal or current rating, strip end clamp on the supplied 40 amp terminal. Do not use double breaker. If used, now connect the yellow wire to the "E" terminal of the isolator with the lock washer end nut.
6. Now proceed to Step #11 of the GENERAL ISOLATOR INSTALLATION.

GALLEY/HEAD SYSTEMS

WATER SYSTEM OPERATION

Fill fresh water tank at deck fill. The tank filler cap will be marked "water". When tank is full, water will back up through the vent hose and exit through a vent located on the side of the hull

To activate the water system, flip the "water pressure" switch on the electrical panel. This will start the pump and pressurize the system. When the pressure builds, the pump will shut off. With continued use of fresh water the pressure in the system is reduced, automatically re-starting the pump. Make sure there is water in the system while pump is in operation to prevent damage to the motor.


If pump kicks in frequently without system use, you may have a leak in the system and it should be checked. ~~Do not activate water heater unless there is water in the system.~~

Opening the faucet will allow the pump to empty the tank. Pushing the tank and lines will be necessary for winterization. Refer to Maintenance & Winterization section for more information.

To operate shower, turn on hot & cold faucets until desired temperature is reached, while shower head is retracted at sink. Pull the shower head out and use. An "on-off" valve is located on the upper most portion of the shower head. This can be used to stop water flow at the head. However, this will not stop water flow at the sink. The faucets must be turned off to prevent system drainage.


LEGEND

43




HUNTER

LEGEND 43 DECK PLAN H43A2628




HUNTER

LEGEND 43 INTERIOR PLAN 11434226



HUNTER

LEGEND 43 THUR-HULL LOCATION NO. 643



LINE TYPES

- 1 1/2" SANITATION HOSE
- 1 1/2" SHIELD/VAC
- 1" SHIELD/VAC
- 1" SHIELD/PL/EX
- 3/4" SHIELD/VAC


- ⊙ BRONZE THRU-HULL W/ BALL VALVE
- PLASTIC THRU-HULL

LEGEND

- ① FORWARD SHOWER SUMP PUMP
- ② BILGE PUMP
- ③ MANUAL BILGE PUMP
- ④ MACERATOR
- ⑤ WASTE PUMP OUT STATION GIECKO
- ⑥ AFT SHOWER SUMP PUMP
- ⑦ MANUAL BILGE PUMP GIECKO

HUNTER

LEGEND 43 WASTE SYSTEM H43A2/3



LEGEND




- ① FORWARD WATER TANK VENT
- ② FORWARD WATER TANK DECK FILL
- ③ HOT WATER HEATER
- ④ MIDSHIP WATER TANK DECK FILL
- ⑤ MIDSHIP WATER TANK VENT
- ⑥ WATER FILTER
- ⑦ WATER PUMP
- ⑧ HEAT EXCHANGER
- ⑨ COCKPIT SHOWER
- ⑩ TANK SELECTOR VALVES

LINE TYPES

- HOT WATER ——— 3/8" POLYBUTYLENE
- COLD WATER - - - - 3/8" POLYBUTYLENE
- WATER HEATER ——— 5/8" SHROTTIFLEX
- TANK VENT HOSE ——— 3/4" SHIELDVAC
- FRESH WATER FILL HOSE ——— 1 1/2" SHIELDVAC

HUNTER

- [A] BILGE PUMP
- [B] AUTO FLUAT SWITCH
- [C] HOSE CLIP
- [D] HOSE CLAMP
- [E] CHECK VALVE
- [F] SHEELDVAC HOSE
- [G] WJUD SACKING BLOCK
- [H] THRU-HULL FITTING




HUNTER

AUTO BILGE PUMP LAYOUT GENA2613


PUMPS, STRAINERS AND FILTERS

LEGEND 43

<u>COMPONENT</u>	<u>MANUFACTURER AND PART NUMBER</u>
Dig pump (automatic)	Rule 1500
(automatic)	Rule 800 or Mayfair 800 (SHOWER SUMP)
(manual)	Rule 148 M
Waste pump	ITT Jabsco #13500-500
Water pump	ITT Jabsco Flo-Jet 4405-143-C
Water strainer	ITT Jabsco 354000-1000
Engine strainer	3/4" Ferko 458-006 PLB
Fuel filter	Racor 112



ENGINE ROOM DETAIL



LEGEND


- ① WATER HEATER
- ② FUEL RETURN
- ③ FUEL SUPPLY
- ④ ENGINE EXHAUST, THRU HULL
- ⑤ ENGINE HEAT EXCHANGER
- ⑥ WATER STRAINER
- ⑦ ENGINE INTAKE
- ⑧ MUFFLER
- ⑨ FUEL FILTER

LINE TYPES

- FUEL LINE ——— 1/4" FUEL LINE
- WATER HEATER ——— 5/8" SHIELDWELFX
- COOLING WATER ——— 1" SHIELDWELFX
- ENGINE EXHAUST ——— 3" EXHAUST HOSE

HUNTER


LEGEND 43 ENGINE SYSTEM H43A2632



- 12 GAUGE _____
- 8 GAUGE _____
- 10# CABLES _____
- 4 GAUGE _____
- ENTIRE HARNESS _____
- 14/3 BUNA CABLE _____
- 2 BUNA CABLE _____

HUNTER

LEGEND 43 PAN ELEC. SYSTEM H43: 14







300 OUTLET

⊕ GROUND FAULT RECEPTACLE

RECEPTACLES ——— 14/3 BC WIRE

HUNTER

LEGEND 43 HEADLINER 110 VOLT SYSTEM '3A2633




LINE TYPES

2/0 WIRE

14 GA. WIRE

HUNTERA

SOLAR PANEL INSTALLATION HUNNA262



- STAR PANEL
- ⊕ COMPASS
- ⊙ SPEAKER
- ▬ 24" FLUORESCENT
- ▬ 16" FLUORESCENT
- ⊖ OUTLET
- ⊖ REVERSING LIGHT
- ⊖ CHART LIGHT
- ⊖ BUNGE LIGHT
- ⊖ STARBOARD RUNNING LIGHT
- ⊖ PORT RUNNING LIGHT
- ⊖ STERN LIGHT
- ⊖ COCKPIT LIGHT
- LIGHT SWITCH

NOTE

WIRES LEADING TO HELM AND SWIVEL LIGHTS ARE IN PAIRS OF 16 GAUGE BLACK AND BLUE W/WHITE STRIPE. WIRES LEADING TO BOW LIGHTS ARE IN PAIRS OF 16 GAUGE BLACK AND GRAY W/WHITE STRIPE. WIRES LEADING TO STERN LIGHT ARE IN A PAIR OF 16 GAUGE BLACK AND GRAY. WIRES LEADING TO PORT SIDE SPEAKERS ARE RAY IN PAIRS IN 16 GAUGE BLACK AND YELLOW. WIRES LEADING TO STARBOARD SIDE SPEAKERS ARE RAY IN PAIRS OF 16 GAUGE BLACK AND BROWN.

--- LIGHTING
 - - - - - SPEAKERS
 _____ NAVIGATION LIGHTS

HUNTER

LEGEND 43 LIGHT BULB SPECIFICATION

Your Legend 43 has 28 interior lights and 7 exterior lights. Of the interior lights, 10 are dome lights, 9 swivel lights, 6 fluorescent lights, 2 courtesy tube lights, and 1 light which is removable from its bracket and installed over the chart table. Of the exterior lights, 3 are navigation lights, 3 are on the mast, and 1 on the cockpit table.

LIGHT

REPLACEMENT BULB

Interior

Dome	#1572 and Wagner #S8-1141
Swivel	#1831 and Wagner #S8-1073
Fluorescent (16")	#F8T5CW/GE
Fluorescent (24")	#F15T5CW/GE
Courtesy tube	Vista TAC15'-3'CL
Chart	Aqua Signal #90400282

Exterior

Red bow	Hella #78292 (12v25w)
Green bow	Same as above
Stern	Hella #78206 (12v10w)
Anchor	Perko #375-12v-10w
Steaming	Forespar CAT #132025
Deck	Forespar CAT #132027
Cockpit	Guest #A22998

INSTRUCTIONS FOR PREPARATION FOR BOTTOM PAINTING

WARNING!

Do not use any sanding, sandblasting or other abrasive preparation of the bottom as this will void your hull blistering warranty. More information on the warranty is available in this owner's manual.

BOTTOM PAINTING

Choose a bottom paint system that suits the environment in your area.

Follow the procedure recommended by the manufacturer of the paint, while making sure not to void the Hunter Hull Blistering Warranty. The procedure for preparing for and painting the bottom varies between paint manufacturers, but should always include degreasing, etching and sometimes priming of the surface.

The rudder should always be bottom painted using a white bottom paint, to avoid heat build-up in the rudder, which colored paints can contribute to, when the boat is on land. For further instructions on preparation of the rudder, see the instructions sheet from *Foss Form, Inc.* under the General Information heading within this manual.

3525 STONEYWAY NORTH
 SEATTLE, WA 98103
 (206) 633-4200

DAFS

This process may be repeated as many times as needed to bring damaged area back up to its original finish. If you have trouble with getting the same sheen, you may apply with a completely dampened rag, a very light coat over this area and/or whole surface area to get an even sheen.

1. Take 150 to 220 grit wet/dry sand paper to smooth out rough spots.
2. Wipe clean of dust and dirt with a clean rag. Note - before applying oil wood surface must be dry.
3. Wipe or brush on oil, allow to penetrate 5-15 minutes while surface is still wet.
4. Sand until smooth with a 400A wet/dry sand paper.
5. Wipe dry with a clean rag. Allow 8-12 hours drying time.
6. Apply 2nd coat, and repeat above procedure.

steps:

When wood work is damaged from scrapes or abrasions that go into or thru the finish, take the following

REPAIRS

When oiled surfaces require renewing, simply wipe the surface area free of loose dirt, dust or other contaminants. Dampen a cloth with the SealIn Teak Oil and wipe on. Let stand for 5-15 minutes then polish dry.

MAINTENANCE

Teak wood is a high quality, extremely durable wood with a high oil content. In order to help you protect the original beauty of your teak interior, we have sealed the beauty of your interior with a 3 to 4 coat finish system of high quality SealIn Teak Oil, manufactured by Dufys (wood finishing products). This material is a penetrating oil that tries to a low sheen to seal and protect the wood from moisture and weathering. It creates a durable, non slip surface to repel water and resist wear. It won't chip, peel or blister. It reduces work and maintenance cost because it is easy to maintain and repair. With proper maintenance it will out live urethane varnish on interior and even exterior surfaces. (Boat, bulkheads, trim wood & furniture).

TEAK CARE

MAINTENANCE

Engine, Transmission and Drivetrain

ENGINE: Follow the fuel and lubrication requirements in the Engine Manual. Check the engine oil level before and after operation and use quality motor oil (refer to Engine Manual). Be certain the proper amount of oil is in the crankcase at all times.

Engine alignment: The engine should be aligned by experienced marine service personnel. Final alignment should be done after launching, with all normal gear aboard. A description of the procedure follows:

The coupling flanges must come together evenly at all points, a feeler gauge is used to check the gap. If adjustment is necessary, the engine is tilted up or down and/or side to side until the flanges meet evenly. Severe vibration will result from misalignment and can cause strut bearing and shaft damage.

Alignment should be checked again after several weeks of use.

(Refer to this manual's alignment drawing)

Any questions or problems concerning the engine, please contact our distributor, Mack Horing at (201) 964 0700.

TRANSMISSION: Follow the lubrication requirements of the Engine Manual. The oil level should be checked immediately after operation.

DRIVETRAIN: The shaft log (stuffing box) should be inspected periodically.

The stuffing box is held to the shaft log tube by a rubber tube secured by hose clamps. The clamps should be tight and no water should leak from this location. A slight drip from the stuffing box at the shaft exit is necessary (four drops a minute) and is normal.

To adjust, loosen the lock nut, tighten gland nut one-quarter turn, and retighten lock nut. If excessive water flow persists after adjustment, replace the packing and then adjust as above.

Steering

Refer to the manufacturer's instructions for maintaining pedestal steering system. Cables should routinely be inspected for proper tension. Lightly oil all cables.

Electrical Systems

The electrical system is a 12-volt, negative ground installation. The owner should weekly inspect battery(ies), terminals and cables for signs of corrosion, cracks, and electrolyte leakage. Battery terminals are to be kept clean and greased. Refer to separate instructions on batteries, wiring diagrams, and electronics.

MAINTENANCE

Plumbing Systems

All pumps should be checked frequently to insure proper operation. This is an especially important regular maintenance item since proper functioning of a pump could save your vessel from serious damage in the future.

Inspect all hoses for chafing and dry rot. See that hose clamps are tight. Check that the pump impeller area is clean and free of obstructions.

Inspect electrical wiring for corrosion. Make sure float switches move freely and are making an electrical connection. Refer to Engine Manual.

The owner should become familiar with the layout of the water and waste systems by walking through the boat with the diagrams provided in this manual. It is especially important that the owner know all thru-hull valve locations and inspects for leaks frequently. Refer to plumbing diagrams in Spec & Tech section.

(General Thru-hull List (varies from boat to boat-see diagrams in Spec & Tech info.)

- 1) Engine cooling system
- 2) Chiller tank
- 3) Head tank
- 4) Head roller (water intake)
- 5) Holding tank discharge
- 6) Scupper drains

Fuel System

The owner should inspect the condition of fuel lines for cracks or leaks. A primary source of fuel-related problems is water in the system. The owner should seek out only well maintained fueling facilities and make sure fuel fill caps are tightly secured after filling. Check and maintain fuel filters periodically. Refer to your Engine Manual for additional information.

General Care

CLEANING FIBERGLASS SURFACES: Fiberglass surfaces should be cleaned regularly. Normal accumulations of surface dirt can be removed simply by occasional rinsings with water. If your boat is operated in salt water, more frequent rinsing will be required. To remove stubborn dirt, grease or oil, use a mild detergent and a soft brush. Rinse with clean fresh water.

It is also a good idea to wax the fiberglass once or twice a year to maintain a deep, glossy appearance. Your local marine supply should be able to provide an appropriate wax.

Sail Care: Sunlight is a sail's worst enemy, so cover the sails when they are not in use. An ultraviolet guard, fitted down the leech of a roller headset, will protect the exposed part from the weathering effect of the sun and from dirt and grit. Mildew, which discolors, is prevented by storing sails dry and by hand-washing twice a season.

Check all fittings regularly to be sure screws are tight. Occasionally lubricate (use silicone lubricant) all moving parts on such fittings as blocks, turnbuckles and cam cleats, as well as the locking pins of snatch blocks, truck slides, spinnaker poles, etc. Inspect chocks, cleats and fairleads for roughness and smooth with fine grained emery paper if necessary. Also, replace any missing or damaged corner pins in turnbuckles and shackles, and either tape them or use protective covers manufactured for that purpose.

General Hardware Maintenance

Follow the maintenance instructions prescribed by the winch manufacturer. We recommend a minimum of an annual cleaning and light greasing.

Winch Maintenance

If wet, prop cushions vertically to promote airflow around each cushion. Cushions can be cleaned by most dry cleaners. Dry clean only.

Fabric Care

The headsail, neatly rolled and fastened, can be temporarily stowed along the lifelines. To stow below, flake it into a length; 1. dien roll from luff to leech; 2. Take care not to crease the leech. Pack in a clearly marked bag.

To stow the mainsail, start at the leech and flake it on to the boom, left and right, in about 18-in. (46-cm) folds, while pulling the leech aft. Secure with a sail tie and continue to the luff. Lash to the boom with sail ties or shock cord.

Check all sails regularly for chafe, particularly where they chafe on deck fittings or rigging, at reef points, batten sleeves and the foot of the headsail. Sail batten pockets should be inspected on a regular basis.

Sail care continued.

MAINTENANCE

To prevent electrolysis in sea water, the difference between the voltage of two adjacent metals should not exceed 0.20V. Zinc and carbon steel, for example, used together, risk corrosion, while lead and active stainless steel are compatible. Metals with a high voltage corrode faster and need a larger area to diffuse the electro-chemical reaction.

It is not enough to know that your boat does not suffer from electrolysis; a newcomer in the marina berth may start a too-friendly association with metal components on it. An easy place to fit an anode is on the propeller shaft, or covering the propeller nut. The anode should not be painted because this will only defeat the purpose.

Salt water allows electric current to flow from anodic to cathodic material. Any two metals from two components, and their relative positions in the galvanic rating table, will determine which loses material (the anode) and which remains largely undisturbed (the cathode). The rate of wear is determined by the distance apart on the galvanic table of two metals. Thus a sacrificial zinc anode is often fitted to the underwater area of a boat to attract any destructive currents away from bronze or steel propeller shafts, for example.

Electrolysis and Galvanic Protection


MAINTENANCE

MAINTENANCE

Alignment Procedure


1. Separate the coupling, move the shaft end back to clear the pilot in the center.
2. Establish the shaft in the center of the shaft log by raising the shaft until it touches the top of the log - note position - lower the shaft until it touches bottom of the log - note position - repeat sidewise and locate shaft in the center; block shaft in this position, using a block of wood under the shaft packing gland.
3. Now, adjust the engine mounts to allow the pilot on the coupling halves to slip together without moving shaft up, down, or sideways.
4. Adjust the engine mounts as necessary until a 0.004" feeler gauge will not enter anywhere along the edge of the flange between the faces.
5. Tighten the locks on the adjustable mounts.
6. Re-check coupling with feeler, re adjust if necessary.
7. Check stuffing box (allow to drip slightly).

STEP 1



STEP 2

USE FEELER GAUGE TO CHECK
COUPLING GAP. THE TOLERANCE
SHOULD BE .004". MAKE SURE
TO CHECK ALL THE WAY
AROUND THE COUPLING.



NOTE: CHECK COUPLING GAP
WITHOUT COUPLING
BOLTS IN PLACE.

HUNTER

ALIGNMENT DIAGRAM GEN2619A

STORAGE/WINTERIZATION

IMPORTANT: Winter storage is recommended to be done in one of the following three ways, either: 1) by blocking the boat via a cradle; or 2) with chained stands on level ground; or 3) by storing the boat in the water with a bubble system to prevent icing. Damage to your boat, including engine misalignment caused by twisting, is not covered by the warranty.

SAILS

Sails should be properly folded and stowed in a dry, well ventilated place. Many sailboat owners send their sails back to the sail manufacturer at the end of each season. The sailmaker will check the stitching and sailcloth for wear and store the sails until the start of the next season.

ELECTRICAL

Remove battery from boat. (Refer to Engine Manual) and charge. It is a good idea to also to remove the electronics (Radio, Radar, etc.) and store in a safe place.

CUSHIONS

Cushions should be removed and stored at home if possible. If not, prop them vertically to promote airflow around each cushion. *Dry Clean Only!*

HATCHES

Tenting the deck during storage will help prevent ice from forming and damaging hatches and deck fittings. The installation of a passive vent will help with ventilation while the boat is in storage.

WATER SYSTEM - WATER HEATER

WATER SYSTEM:

Open a faucet and allow the pump to empty the tank. Then add approximately two gallons of non-toxic anti-freeze solution to the tank and repeat the pumping out procedure.

A second method is to disconnect the hoses at the pump, allowing them to drain. Find the lowest point in the system and disconnect the fitting. Open all faucets to allow the lines to drain. If possible, use a short piece of hose on the faucet to blow through the lines to clear all water. A diluted solution with baking soda will help freshen the system.

WATER HEATER:

Open valve and drain fully. Leave valve open during lay-up time.

TOILET AND HOLDING TANK

Drain and flush toilet. Using automatic anti-freeze (only/energy) in a 50/50 mixture with water, pump through toilet and into holding tank. Refer to (Valley/Head section for instructions.

STORAGE/WINTERIZATION CONTINUED.

ENGINE

1. Drain the cooling water completely out of the engine and flush the line thoroughly with fresh water. Don't use high pressure through the line.
2. Remove the fuel completely from all fuel lines.
3. Disconnect the main battery cables from the battery terminals.
4. To prevent corrosion inside the cylinders, pour a little lubricating oil into the suction pipe while turning the engine. Enough oil to reach the intake/exhaust valve is sufficient.
5. Put the piston at top dead center of compression stroke so that the intake/exhaust valves are completely closed.
6. Apply a thin anti-corrosion treatment to the plating and exposed painted surfaces.
7. The engine should be in a well ventilated area, and protected from any kind of dampness.
8. Put a dust cover over the engine.
9. Check your operation manual for engine diagram and for "Manufacturer's Recommended Winterizing Procedures."

OUTBOARD ENGINE

Take it home and store it in a safe place. Be very careful storing the gas tank as the gasoline is very flammable. Refer to "Engine Manual" for specific maintenance schedule.

DEPARTURE FROM THE BOAT

The check list for leaving a boat unattended is very important because items overlooked often will not be remembered until you are far from the boat and corrective actions are impractical or impossible. Primary checks for this list are items relating to the safety and security of the unattended craft-running off fuel valves, the proper settings for electrical switches, pumping out the bilge and leaving the switch on automatic (or arranging for periodic pumping out). Other departure check list items are securing ports, windows, hatches, and doors.


ROUTINE MAINTENANCE

Routine maintenance check lists should include items based on how much the boat is used (usually in terms of engine hours) and on calendar dates (weekly, monthly, or seasonal checks). Typical of the former are oil level checks and changes, and oil and fuel filter changes.

On a calendar basis the list should note such matters as electrolyte levels in storage-batteries, pressure gauges on dry-chemical fire extinguishers, and all navigation lights. Check the operation of automatic bilge alarms or pump switches by running water into the boat. Periodically close and open sea-cocks several times to ensure they are ready in an emergency. Equipment and supplies carried on board for emergencies should be inspected for any signs of deterioration.

PEDESTAL STEERING ASSEMBLY

As a further service to our customers we have an illustrated parts breakdown showing the design and construction of your Edson Pedestal Steerer. These parts drawings will assist you in the proper installation of your steering system.




DISASSEMBLY


1. With the wheel and brake assembly removed, remove the steering arm with any attached tie rod end.
2. Loosen the steering cables and strain by backing off the lock-up nuts at the junction of the cable (see Fig. 1) to clear off the sprocket and to the forward part of the bowl.
3. Put a steel foot under the sprocket and an iron drop down to the forward part of the bowl.
4. Align the eye of the oil system earlier with the "A" eye of the sprocket.
5. Carefully guide the pin out of the sprocket (remove from the second end toward the forward end).
6. With a piece of steel pipe (the 2" or 1 1/2" has nut, gently tap the wheel off from the housing) (see illustration) to prevent the drop the shaft components into a tray.
7. Remove the sprocket, two shaft washers and tapered roller bearings.
8. Remove all visible bearing and washers.
9. Wipe out any dirt or old grease before reassembly.
10. The assembly, however, in a new procedure, do not grease the cover rings until reassembly is completed.

NOTE: Work your way through the headlamp and

When working on a pedestal steerer, the pedestal is the main support for the steering gear. The pedestal will be filled properly when the main support is in the correct position. When working on a pedestal steerer, you will be filled properly when the main support is in the correct position. When working on a pedestal steerer, you will be filled properly when the main support is in the correct position.




ENGINE CONTROLS INSTALLATION



Installation must be checked after each and every 2000 mile interval. The operation of the steering control should be checked after each 2000 mile interval. The operation of the steering control should be checked after each 2000 mile interval.

ENGINE CONNECTIONS

NOTE: Before installation there is a guide for what engine and engine cable should be used. If there is any variation in cable, the cable should be changed before installation.




ENGINE CONTROLS MAINTENANCE

All the engine parts of the control system should be greased with a good grade of motor oil. Grease the control linkages at the pedestal end and the control linkages at the steering gear end.



PLEASE READ THESE INSTRUCTIONS
CAREFULLY AND THOROUGHLY BEFORE
INSTALLING OR OPERATING THIS CON-
TROL.



MV-2 CONTROL

FOR THE

MORSE MARINE PRODUCTS
OWNER'S MANUAL
INSTALLATION, OPERATION & MAINTENANCE INSTRUCTIONS



Morse Controls Division
31 Third Street
Hudson, Ohio 44202-2500
FAX 216-638-7700
318 869 7701

NORTHEAST
 Regional Office
 IRI Barient
 New Whitehall Street
 Guilford, CT 06437
 Tel: 203/453-4374
 FAX: 203/453-6109

SOUTHEAST
 Regional Office
 IRI Barient
 1355 126th Ave. N.
 Largo, FL 34643
 Tel: 813/536-6868
 FAX: 813/531-7187

WEST COAST
 Regional Office
 IRI Barient
 1600 E. St. Gerardo Place
 Santa Ana, CA 92705
 Tel: 714/557-8104
 FAX: 714/557-1394





MAINTENANCE & SERVICE INFORMATION

BARIENT



MODEL 77 1-SPEED SELF TAILING WINCH

MAINTENANCE & SERVICE INFORMATION



INSTALLATION INSTRUCTIONS

1. Lay a clean tarp out flat, remove the top ring and lay it on the tarp.
2. Lift the gear case and the tailer together from the top ring and lay it on the tarp.
3. Lay the gear case on the tarp with the tailer on the left side.
4. Lay the gear case on the tarp with the tailer on the left side.
5. Lay the gear case on the tarp with the tailer on the left side.

TO LUBRICATE & REASSEMBLE

1. Remove the top ring and lay it on the tarp.
2. Lay the gear case on the tarp with the tailer on the left side.
3. Lay the gear case on the tarp with the tailer on the left side.

1. Remove the top ring and lay it on the tarp.
2. Lay the gear case on the tarp with the tailer on the left side.
3. Lay the gear case on the tarp with the tailer on the left side.
4. Lay the gear case on the tarp with the tailer on the left side.
5. Lay the gear case on the tarp with the tailer on the left side.
6. Lay the gear case on the tarp with the tailer on the left side.
7. Lay the gear case on the tarp with the tailer on the left side.
8. Lay the gear case on the tarp with the tailer on the left side.
9. Lay the gear case on the tarp with the tailer on the left side.
10. Lay the gear case on the tarp with the tailer on the left side.

TOOLS REQUIRED

Remove the top ring and lay it on the tarp.

LUBRICANT

Remove the top ring and lay it on the tarp.

MOUNTING INFORMATION




Remove the top ring and lay it on the tarp.

ITEM	PART NO.	DESCRIPTION
1	88124	Gearcase
2	88125	Pin - 1/4" Dia.
3	88126	Output Gear
4	88127	Output Gear
5	88128	Pin - 1/4" Dia.
6	88129	Intermediate Gear
7	88130	Intermediate Gear
8	88131	Pin - 1/4" Dia.
9	88132	Main Gear
10	88133	Main Gear
11	88134	Pin - 1/4" Dia.
12	88135	Top Ring
13	88136	Top Ring
14	88137	Pin - 1/4" Dia.
15	88138	Bracket
16	88139	Bracket
17	88140	Bracket
18	88141	Bracket
19	88142	Bracket
20	88143	Bracket
21	88144	Bracket




MODEL 2-SPEED SELF- TAILING WINCH

21-30 21-33
22-35 22-39
24-41 24-45




MAINTENANCE & SERVICE INFORMATION

MODEL 28 2-SPEED WINCH S/T





RECOMMENDED LINE SIZES
 Minimum dia. 3/8" 7' min
 Maximum dia. 1 1/2" 15' min

	1st	2nd
GEAR RATIO	2.5:1	7.4:1
POWER RATIO	12.5:1	37.7:1
DRUM DIA.	102mm	5"
MAXIMUM DIA.	203mm	8"
HEIGHT	230mm	9 1/8"



PLACEMENT OF SPRING AGAINST SAW



MOUNTING INSTRUCTIONS:

1. Using a Rapient drum nut tool or deck plate key remove line drum nut (20) in the line lifter (29) & (30).
2. Lift the drum assembly and the line lifter together from the gearbox assembly (6). **CAUTION:** The drum bearings (1) may come off with drum — be careful not to let them fall out.
3. Remove the four capscrews (4) holding the gearbox assembly to the base (25). Keeping the gearbox assembly completed remove it from base (25). **NOTE:** The main shaft (5) may fall out when turning the gearbox assembly by careful not to drop.
4. Coat the base (25) in flat and smooth surface pulled to take six threaded bolts $\frac{3}{8}$ " (fluting dia. on $\frac{7}{8}$ " (19mm) bolts circle. Use base (25) as a template.) The screws adequate reinforcement is provided to take the loads produced by the winch. DO NOT knock the draw channels in the base (25) with bolt-tight (sealing) nut-pound.
5. To re-assemble winch — reverse dismantling procedure. Do sure the line lifter is re-attached towards the winch cranker's position (see fig. 1).

TO LUBRICATE & DISASSEMBLE:

1. As step 1, 2 and 3 above.
2. Remove the line lifter (29), the anchor sleeve (23) and the bearings (1) with spacer (35). **NOTE:** It is not necessary to disassemble self-tailing mechanism proceed to step 5.
3. Remove four capscrews (27) from anchor sleeve (28) and line lifter (29), separate them.
4. It is usually not necessary to remove the clamp ring (31) from the drum. If this is required push the spring guides (18) up from the inside of the drum to allow removal of the lock rings (31).
5. Carefully turn the gearbox assembly on side, making sure the main shaft (2) does not fall out. The drum can be used as a holder-stand for inverted gearbox assembly. (Insert the turn of the gearbox HSG. into the top of the drum).
6. Remove the three $\frac{1}{4}$ " capscrews (23) and (24) from gearbox cover (22) and remove the cover. (It may be necessary to gently lift the cover off with a screwdriver).
7. Remove the spacer (20) beneath the cover screw (24), the center pivot bearing (17) and thrust washer (17).
8. Lift out the final drive pinion (9) in assembly with its ratchet gear (12), ratchet pawls (10) and springs (11). **NOTE:** Keep this assembly together until you are ready to clean it, then re-assemble it immediately. This avoids confusion in the assembly procedure.
9. Remove the two bearings (34) and (8).
10. Remove the idler gear (15) and its bearing (3).
11. Lift up the center ratchet gear (14) — removing it in assembly with the center pinion (15), the pawls (10) and springs (11). Keep this assembly together until it can be cleaned and reassembled.
12. Remove the thrust washer (6), the main shaft (2) and its upper and lower bearings (7). The two gear spindles (9), (8) are pressed into the housing and should not be removed unless they are damaged.
13. Clean all parts in petroleum solvent. Replace any parts showing fatigue or excessive wear. During the assembly procedure, all gears and bearings should be liberally greased with Barient — Barlub.
14. Assemble winch in reverse order to that shown above.

TOOL REQUIRED:


$\frac{3}{8}$ " and $\frac{1}{2}$ " Allen key; Darent drum nut tool or deck plate key.

LUBRICANT: Non detergent Machine Oil (S&F 30); Barient Ballube.

INSPECTOR'S & LUBRICATOR'S:
Carefully inspect winch is recommended. Inspect more frequently in a racing situation. Regular oiling and lubrication of the aluminum drum winches is advisable.

Item	Part No.	Description	Qty
1	194272	Drum Bearing	2
2	29-408	Mainshaft	1
3	07-406	Bearing	2
4	01-794	Cap Screw $\frac{3}{8}$ " long x 1" L.C.	4
5	11738	Gearbox Housing	1
6	29-609	Gearbox Housing — Ultralight	1
7	03322	Thrust Washer — Main Shaft	1
8	11211	Gear Spindle	1
9	02421	Bearing	1
10	28-311	Final Drive Pinion 15T	1
11	25-403	Ratchet Saw.	1
12	01-905	Paul Spring	4
13	22-614	Ratchet Gear	1
14	07322	Thrust Washer — Final Drive	1
15	29-419	Center Pinion	1
16	29-412	Inner Gear	1
17	11-009	Bearing	1
18	00907	Spring Guide	1
19	08321	Using Spring	1
20	20066	Spacer	1
21	11217	Down Pin	2
22	14916	3/8" Box Cover	1
23	11709	Gear box Cover — Ultralight	1
24	28-401	Cap screw $\frac{1}{4}$ " long x $\frac{3}{8}$ " L.C.	2
25	01-308	Cap screw $\frac{1}{4}$ " long x $\frac{1}{2}$ "	1
26	11746	Base Aluminium	1
27	20037	Drum Nut	1
28	28037A	Drum Nut — Ultralight	1
29	01-225	Inscreew $\frac{1}{4}$ " long x $\frac{1}{4}$ " L.C.	4
30	28026	Anchor Sleeve	1
31	20026A	Anchor Sleeve — Ultralight	1
32	29216	Lock Ring	1
33	202-64	Line Lifter — Ultralight	1
34	28709	Spring Guide Lock	1
35	26078	Clamping Ring — Chrome	1
36	21010A	Clamping Ring — Aluminium	1
37	28-043E	Drum Stainless Steel 54T	1
38	28-043C	Drum — Chrome-54T	1
39	20-344A	Drum Aluminium 54T	1
40	20-344B	Drum — Bronze-54T	1
41	11211-2	Gear Spindle	1
42	01-537	Thrust Washer (Aluminium Drums Only)	1
43	01-537	Thrust Washer (Aluminium Winches Only)	2
44	01-537	Alternative Bearings	3


Fig. 1.







MAINTENANCE & SERVICE INFORMATION

MODEL 32 2-SPEED WINCH S/T

RECOMMENDED LIFT SIZES
Minimum dia. 1/2" 13mm
Maximum dia. 3/4" 19mm



GEAR RATIO	1:1	2:1
POWER RATIO	10:1	4:1
DRUM DIA.	118mm	4 1/2"
MAXIMUM DIA.	241mm	9 1/2"
HEIGHT	254mm	10"



MOUNTING INSTRUCTIONS:

- Using a flathead drum nutted or deck plate key remove the drum nut (25) in the line lifter (29) & (28).
 - Fill the drum assembly and the line lifter together from the gearbox assembly (6). **CAUTION:** The drum bearings (1) may come off with drum ... be careful not to let them fall out.
 - Remove the four cap screws (14), holding the gearbox assembly to the base (25). Keeping the gearbox assembly completely remove it from base (25). **NOTE:** The nut shaft (2) may fall out when turning the gearboxassy over by capulite nut to drop.
 - Hot the base (26) to a flat and smooth surface drill to take six flathead bolts $\frac{3}{8}$ " (Ident) dia on $7\frac{1}{2}$ " (18 Firm) bolts circle dia. (Use base (25) as a template.) Be sure adequate reinforcement is provided to take the loads produced by the wheel. **DO NOT** Block the main channels in the base (25) with bedding (30) (ring) compound.
 - To re-assemble which reverse dismantling procedure. Be sure the line lifter is orientated towards the winch cranks position (see fig. 11).
- ### TO LUBRICATE & DISASSEMBLE:
- As steps 1, 2 and 3 above.
 - Remove the line lifter (29), the anchor screws (23) and the bearings (1) with spacer (33). **NOTE:** If it is not necessary to disassemble self-lifting mechanism proceed to step 5.
 - Remove four cap screws (27) from anchor screw (28) and the lifter (29), separate them.
 - It is usually not necessary to remove the clamp ring (31) from the drum. If this is required push the spring guides (18) up from the inside of the drum to allow removal of the lock rings (30).
 - Carefully turn the gearbox assembly on side making sure the main shaft (2) does not lift out. This drum can be used as a hoist stand for inverted gearbox assembly. (Insert the stem of the gearbox housing into the top of the drum).
 - Remove the three $\frac{1}{4}$ " cap screws (23) and (24) from gearbox cover (22) and remove the cover (it may be necessary to gently lift the cover off with a screwdriver.)
 - Remove the spacer (20) beneath the cover screw (24), the center pinion bearing (17) and thrust washer (13).
 - Remove the final drive pinion (9) in assembly with its ratchet gear (12), ratchet jaws (11) and springs (11). **NOTE:** Keep this assembly together until you are ready to clean it, then re-assemble it immediately. This avoids confusion in the assembly-by procedure.
 - Remove the two bearings (4) and (6).
 - Remove the idler gear (16) and its bearing (3).
 - Lift up the center ratchet gear (14) covering it in assembly with the center pinion (15), the pawls (10) and springs (11). Keep this assembly together until it can be cleaned and re assembled.
 - Remove the thrust washer (6), the main shaft (2) and its upper and lower bearings (3). The two gear splines (7), (5) are pressed into the housing and should not be removed unless they are damaged.
 - Clean all parts in petroleum solvent. Replace any parts showing damage or excessive wear. During the assembly procedure, all gears and bearings should be liberally greased with Zarexol — Dardur.
 - Assemble wheels in reverse order to that shown above.

TOOL REQUIRED:

$\frac{3}{16}$ " and $\frac{1}{2}$ " Allen Key; Currier drum nut tool or deck plate key.

LUBRICANT:

Non detergent Machine Oil (SAE: 30); Barient Earline.

INSPECTION & LUBRICATION:

Quarterly ... is recommended. Inspect ... frequently in a racing sea ... and lubrication of the aluminium drum winches is advisable.

Item	Part No.	Description	Qty
1	5042Z	Drum Bearing	2
2	32 40B	Main Shaft	1
3	0241Z	Bearing	1
4	01 267	Cap screw $\frac{1}{2}$ " long x $\frac{3}{8}$ " I.C.	4
5	2265T	Gearbox Housing	1
6	3245X	Gearbox Housing	1
7	0039Z	Thrust Washer — Main Shaft	1
8	012-1	Gear Splines	1
9	1-240	Gearring	1
10	01 400	Final Drive Pinion	1
11	01 300	Final Drive Pinion	1
12	11250	Pinion Spring	4
13	00020	Thrust Washer — Final Drive	1
14	11240	Center Handle Gear	1
15	2E 019	Center Pinion	1
16	11240	Free Gear	1
17	02400	Hex Nut	1
18	29021	Spring Guide	2
19	23003	Clamp Spring	2
20	11277	Spacer	1
21	11216	Lower Pin	2
22	11251	Gearbox Cover	1
23	32-411	Anchor Cover — (Final Drive)	1
24	01-205	Cap screw $\frac{1}{2}$ " long x $\frac{1}{2}$ " I.C.	2
25	01-206	Cap screw $\frac{1}{2}$ " long x $1\frac{1}{4}$ " I.C.	1
26	32594	Locke Drum Nut	1
27	29037	Lock Nut	1
28	20037A	Lock Nut — (Final Drive)	1
29	01 365	Cap screw $\frac{1}{2}$ " long x $\frac{3}{8}$ " I.C.	4
30	29025	Anchor Sleeve	1
31	29026	Anchor Sleeve — (Final Drive)	1
32	32721	Line Lifter	1
33	32721A	Line Lifter — (Final Drive)	1
34	26020	Spring Guide Lock	4
35	58377C	Clipping Ring	4
36	32716	Clipping Ring	1
37	32716A	Clipping Ring — (Final Drive)	1
38	32719Z	Flange — Stainless Steel	1
39	32720C	Flange — Chrome	1
40	32722A	Flange — Alum. Nut	1
41	32722B	Flange — Alum. Nut	1
42	32722D	Flange — Alum. Nut	1
43	1121E	Spring Spacer	1
44	2E-153	Beating Spacer	1
45	11911-2	Base — Synthetic	1
46	01-507	Thrust Washer — (Main Drum)	1
47	01-507	Thrust Washer — (Final Drive)	1
48	01-021	Alternative Thrust Washer — (Main Drum)	1
49		Alternative Thrust Washer — (Final Drive)	1

TO ORIENT THE LINE LIFTER



Fig. 1.



When using the line lifter, the line lifter should be pointing down.

BARIENT'S AMAZING SELF-TAILING WINCHES No Other Design Even Comes Close

The Advantages Of Self-Tailing:

The advantages of self-tailing are important to rating and cruising sailors alike. With a standard winch, a crew member must wind with one hand and let the line coming off the drum with the other. When more speed or power is required, it often becomes a necessity to have a second crew member handle the baling while the other winds the winch.

BARIENT'S SELF-TAILING SYSTEMS



With self-tailing winches, one crew member can do it all in one continuous motion without assistance. If additional power or speed is required the winch is free to use both hands on one of Barient's double grip winch handles. With a Barient, while the line is slack, it can actually be let out right through the jaws.

How Do They Work And Why Is Barient's Design So Much Better?

The jaws of a Barient self-tailing winch actually take the place of a human hand, with three to five areas of line on the drum (depending on winch size), that is placed over the leader and into the jaws which grip gently and allow it to rotate with the jaws to the skipper's finger without guiding friction.

Constant Feed Rate
When a sailhailer works efficiently, the "lead foot" from the drum, through the rotating system, remains absolutely constant. The jaws, therefore, must be able to accept and forward the line at precisely the same rate that it comes off the drum. Should the crew feed the line faster than the jaws can take it up, the line will "spit" and the jaws take up the line faster than the drum can feed it, allowing the line to drop slackly and friction and the

winch increase. Constant "lead foot" can be achieved only if the line on the drum and the line in the self-tailing winch are in precise vertical alignment. Automatically Adjusts to Line Width
All Barient self-tailing winches are able to achieve this critical alignment with lines of many different diameters. This is accomplished through the utilization of our patented spring-loaded jaws. Small compressions on the jaws that reduce, as larger or smaller diameters are used, the spring-loaded jaw compresses for the difference automatically. You cannot load this feature on any other self-tailing winch out there. On both Barient and other winches, where one winch must serve multiple functions, which require a number of different line sizes, this feature is invaluable.

Hunter Marine Corporation
P.O. Box 1030, Route 40
Alachua, Florida 32015
904/462-3077



Committed to Better Engineering

THE EDSON CORP., 420 INDUSTRIAL PK., RD. 1, NEW BEDFORD, MA. 02745
TELEPHONE (508) 925-2711 FAX: (508) 225-5021

CHECK IF YOU ALREADY HAVE ONE (CIRCLE ONE)

EDSON SERIAL NO. LOCATED ON INSIDE OF PEDestal DOWN BENEATH COMPASS.

RECORD YOUR SERIAL NO. BELOW FOR YOUR RECORDS

OWNER'S NAME _____

STREET _____

CITY _____ STATE _____ ZIP _____

ROAD DEPT. _____

DEPT. ADDRESS _____

ROAD NUMBER _____

CLASS _____

YEAR BUILT _____

EDSON SERIAL # _____

LENGTH _____

PLEASE PRINT CLEARLY

THE EDSON CORP. 420 INDUSTRIAL PARK RD. NEW BEDFORD, MA. 02745 TEL: 508-925-2711 FAX: 508-225-5021

EDSON REGISTRATION CARD

In order to properly register Edson's new steering system, please fill out and return the Edson Registration Card below. The return mail I don't send the latest catalog/handbook

THE EDSON CORPORATION
Customer Service Dept.

Thank you.

Welcome to the World of Edson! So that we may properly register your new Edson Steering System, please fill out and return the attached Steer Registration Card to the Edson Corporation. We will register the serial number of your steerer so that if you ever have any questions, Edson's worldwide sales network will be ready to be of assistance. If you ever have any questions pertaining to your steering system, please be sure to contact Edson immediately. We are standing by ready to help you.

Upon receipt of the Edson Registration Card, we will not only register your Pedestal Serial number, but we will also send you the latest 60 page Edson catalog/handbook, showing Edson's complete line of accessories which can be purchased through your dealer.

Dear Edson Owner,



DEALER/OWNER CHECK LIST



For the best performance of your new steering system, engine control, or Edson accessories, Edson recommends that the owner and dealer carefully check over the steerer installation before the boat leaves the dock.

Our experience has shown that fasteners tend to be vibrated loose in delivery especially those boats delivered by truck, and we advise that the items on the check list be inspected. After the initial inspection this check list should be followed on a regular basis.

FASTENERS

USE AND LOCATION

- Quadrant at rudder post
- Radial Drive at rudder post
- Engine Controls at handles and cable holder

Screws

Nuts

- Wheel
- Pedestal Bolts
- Lower Shafts
- Wire Take Up Eyes on Quadrant or Radial Drive

Bolts

- Outer radius joint of Radial Drive
- Sheave housing
- Rudder stop on Radial Drive
- Chain ends
- Sheave Pins
- Engine Control Clevis Pins

Cutter Pins

For the best performance of the steering system, the roller chain, bearings, and sheave pins and bushings must be properly lubricated. Also check for proper wire tension. Please refer to the maintenance guide for the complete instructions.

Be sure that all crew members are familiar with the care and operation of the steering system as well as the location and use of the emergency tiller. This guide, the maintenance guide, and the catalog, should be kept on the boat for reference purposes.

Edson
SALES
-1-813-

Edson International

46 INDUSTRIAL PARK RD
NEW BEDFORD, MASS 02745

ATTN: CUSTOMER SERVICE DEPT.

U K SAILMAKERS HONG KONG
P. O. BOX 69527
KWUN TONG
KOWLOON
HONG KONG



STAMP
HERE





UK SAILS MADE IN HONG KONG ARE WARRANTED FOR A PERIOD OF ONE YEAR AGAINST DEFECTS IN MATERIALS OR WORKMANSHIP. THE WARRANTY COVERS SAILS THAT HAVE RECEIVED REASONABLE USE AND HAVE NOT BEEN DAMAGED DUE TO ABUSE OR NEGLIGENCE.

NOTICE OF DEFECT MUST BE GIVEN WITHIN 90 DAYS OF DISCOVERY TO UK SAILMAKERS HONG KONG, P. O. BOX 68527, KWUN TONG, KOWLOON, HONG KONG. PHONE NO.: (852) 775-7711. UK SAILMAKERS H.K. WILL ARRANGE TO HAVE THE SAIL REPAIRED OR REPLACED. THIS WARRANTY IS IN LIEU OF ANY OTHER WARRANTY EXPRESS OR IMPLIED AND DOES NOT COVER ANY INCIDENTAL DAMAGES AND DOES NOT COVER TRANSPORTATION COSTS.

SAILS WARRANTY REGISTRATION FORM

NAME _____

ADDRESS _____

CITY _____ STATE _____ ZIP _____

TELEPHONE (Home) _____ TYPE OF BOAT _____

FAX _____

DATE SAILS PURCHASED _____ SAIL SERIAL # _____

NAME OF DEALER _____

ADDRESS _____

CITY _____ STATE _____ ZIP _____

THIS WARRANTY FORM MUST BE RETURNED WITHIN 90 DAYS OF RECEIPT OF SAILS TO UK SAILMAKERS HONG KONG.

Installation and User's Guide For Sovonics Solar Chargers: MA-6, MA-12, MA-21, MA-33

simple and operation automatic, safe and reliable.
Please read these instructions carefully. Important procedures on how to install and use your Sovonics Solar Charger are covered. This manual also offers you a basic understanding of the Sovonics Solar Charger technology: "photovoltaics" (photo—from light, voltages—from voltage).

CONGRATULATIONS. You are the proud owner of a Sovonics Solar Charger. Welcome to the world of clean, silent, non-polluting, reliable solar electric power. The convenience and safety of boating with a Sovonics Solar Charger aboard is remarkable. It converts sunlight directly into electricity. No moving parts, fuel, maintenance or hassles. Sovonics Solar Chargers are designed to make installation

How They Work

silicon alloy materials placed on a flexible substrate (stainless steel) as the means to achieve low cost, high efficiency versatile photovoltaic modules. Mr. Ovshinsky's ideas from almost 20 years ago have been translated into the Sovonics Solar Chargers for marine batteries.




Sovonics Solar Systems is also making inroads on conventional electric utility power. Mr. Ovshinsky's visions of a cleaner, safer environment through advanced low cost amorphous technologies are rapidly becoming reality.

Sovonics Solar Chargers convert sunlight directly to DC electricity by the photovoltaic effect. A photovoltaic effect occurs when light energy causes electrons to become excited and flow between two materials, typically silicon alloy. Sovonics Solar Systems utilizes the unique world famous technology of its parent company Energy Conversion Devices (ECD), Sovonics photovoltaic modules are tandem junction thin film amorphous silicon alloy devices.

A pioneer in the field, Stanford Ovshinsky, founder of Energy Conversion Devices (parent company of Sovonics Solar Systems), identified tandem junction thin film amorphous


Battery Connections:

- Sonnics Solar Chargers contain a built-in blocking diode permitting a direct connection to the battery through an in-line fuse. Connection to the battery requires these simple steps:
1. Decide the mounting location for your solar charger.
 2. Mount solar charger (see above: Portable or Fixed Mount)
 3. Connect in-line Fuse Assembly to positive and negative terminal of the battery.
 4. Connect SAE Connector of In-line Fuse Assembly to the SAE Connector of the solar charger.
- You can check for charging by either connecting an ammeter in the circuit or by checking battery voltage over time.



Use of a Charge Regulator

When a regulator is used, it should be mounted as close to the battery as possible. Using the regulator as a template, mark the mounting holes. Remove the regulator, drill the holes and fill the holes with silicone. Secure the regulator using stainless screws or bolt/nut sets. Follow the wiring instructions with the regulator.



A charge regulator prevents overcharging of the battery. When the maximum charging current of the module is less than approximately 2% of the battery capacity (example: MA-21 producing 1.4 amps and a battery of 105 Ah capacity or more), a charge regulator is not required. A charge regulator is recommended when a battery and module do not meet the 2% criteria, or when the battery is to be left on charge unattended for extended period (5 months).

Quick Disconnect

Recommended for all modules. The SAE connector is supplied as part of the solar charger module and in-line fuse assembly.

Operating Performance

Multiply the panel peak charging rate in amperes times 6 for southern US, 5 for middle US, and 4 for northern US to estimate amperes-hours per day (summer) delivered to the battery by the respective panel. Match panel output (in amperes-hours/day) to your load requirements to determine which panel suits your needs. More than one panel may be connected to a battery. Consult battery manufacturer for maximum charging amperes allowed with your particular battery.

OWNERSHIP REGISTRATION
 (Please fill out and return with today)

NAME _____
 BOAT NAME OR BOAT _____
 ADDRESS _____
 CITY _____
 STATE _____ ZIP _____
 TYPE OF APPLANCE _____
 DEALER'S NAME _____
 LISTED NAME MICROWAVE
 ADDRESS _____
 CITY _____
 STATE _____ ZIP _____
 DATE PURCHASED _____
 PRODUCT SERIAL # _____
 MINKOT MODEL # _____

YOUR AGE: 20-30 31-40 41-50
 ANY COMMENTS: _____

Customer Service

Seward Products
 P.O. Box 566
 La Puente, CA 91747

PLACE
 STAMP
 HERE

From _____

SEAWARD PRODUCTS AUTHORIZED SERVICE CENTERS

CALIFORNIA

PROPER TIGHE MARINE
2927 Clement Avenue, Redwood City, CA 94061
(415) 823-0143
SAILING SUPPLY
3925 Ocean Street, San Diego, CA 92106
(619) 225-0158
SOUTHERN MARINE ENTERPRISES, INC.
2500 Alhambra Street, San Diego, CA 90701
(619) 452-1432
WEST BAY MARINE SUPPLIES
1945 Lincoln Blvd., Long Beach, CA 90717
(415) 534-8116

CANADA

RAVEN MARINE SUPPLIES
P.O. Box 25200 Vancouver Ave
8060 Capistrano Way, Richmond, B.C., Canada V6X 1R5
(604) 279-9125
SHORTWAVE MARINE SERVICE LTD.
81 Lakeshore Road East, Mississauga, Ontario, Canada L4Z 1R3
(416) 279-6541

CONNECTICUT

YACHT MARINE
7 Quoy Street, Norwalk, CT 06850
(203) 252-1100

FLORIDA

A.C. MARINE, INC.
2012 Whitehall Drive, Sarasota, FL 34235
(813) 752-8025
APPLIANCES OF PALM COAST
2 Hartwood Drive, Palm Coast, FL 32037
(904) 445-1430
D & S SERVICE
1320 S.W. 9th Lane, Miami, FL 33135
(305) 271-0841
SPACE COAST APPLIANCE INC.
2412 North Atlantic Lane, Cocoa, FL 32922
(407) 758-0022 • 800-930-0975
TAMPA MARINE
222 North Thirteenth Street, Tampa, FL 33602
(813) 252-2700

HAWAII

ALFA MARINE LTD.
1501 Ala Moana, Honolulu, HI 96816
(808) 946-4713

MARYLAND

YACHTING BOAT SUPPLY
202 South Street East, P.O. Box 1100, Annapolis, MD 21403
(410) 298-8501
1000 4th Street, Annapolis, MD 21403

MICHIGAN

NORTHLAND APPLIANCE SERVICE CO.
2231 Adams Road, Sterling, MI 48659
(517) 654-3160
TORRESSEN MARINE, INC.
3126 Lakeshore Drive, Muskegon, MI 49441
(616) 759-6398

MISSISSIPPI

GULFPORT MARINE SUPPLY
1315 27th Avenue, Gulfport, MS 39507
(601) 666-3559

NEW JERSEY

JAY MARINE
Rt. 30 & Hudsonway Ave., Little Ferry, NJ 07643
(609) 492-1971

NEW YORK

ACME SERVICE CO.
5 Davidson Plaza, East Rockaway, NY 11518
(516) 693-6929
SUNSHINE 3 MARINA
886 E. Wilmers, Rockaway, NY 11767
(516) 967-0988

OREGON

JIM PHINNEY'S RIG & REPAIR
30 North Oakdale, Medford, OR 97501
(503) 770-6104
SEXTONS CHANDLERY
303 N.E. Homestead Island Drive, Portland, OR 97217
(503) 289-9358

RHODE ISLAND

CORP BROS
41 Brook Street, Providence, RI 02903
(401) 331-8020
F & M SERVICE, INC.
2530 East Main Road, Pawtucket, RI 02861
(401) 853-5200
ISLAND RIG & FIX CO., INC.
27 East Main Road, Middletown, RI 02840
(401) 853-3341

UTAH

PETERSON MARINE SUPPLY
4432 South 900 West, Ogden, UT 84403
(801) 621-2570

WASHINGTON

MULTI-MONITOR, INC.
2000 Northwest 45th Street, Seattle, WA 98107
(206) 493-4434
SUNL MARINE SERVICES, INC.
5030 28th Avenue, NW, Seattle, WA 98107
(206) 789-1000

Seaward Products

P.O. BOX 586
LA PUENTE, CA 91747
(818) 986-2117

This Warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

This Warranty is extended to the original purchaser only, unless purchased for purposes of resale.

Some states do not allow limitation on how long an implied warranty lasts or for the exclusion or limitations of incidental or consequential damages, therefore, the above limitations may not apply to you.

Implied Warranties of merchantability and of the fitness of the product for any purpose are warranted for a period of two years on parts and labor, SEAWARD makes no warranties, expressed or implied after that time.

The foregoing Warranty and condition shall apply to any repaired, reworked, or replaced products, part or component supplied by SEAWARD. SEAWARD shall in no event be liable to BUYER or BUYER'S customers for any incidental or consequential damages, or loss of use, or other losses, however occasioned.

- (3) Routine Maintenance that may be required.
(2) Glass
(1) Porcelain Enamel

Items not covered under warranty are from purchase date. Transportation charges are the responsibility of the customer. factory or authorized service center and allow labor and parts for (2) two years determining problem to be under warranty, will either repair the product at their defective. SEAWARD, after establishing customer's purchase date and examination discloses to our satisfaction to have been nonconforming or or replacement, at SEAWARD'S option, any part or component thereof, which, The obligation of SEAWARD under this Warranty is limited to the repair, rework,

A. free from (1) encumbrances and (2) defects in material and workmanship under the normal use and service, and
B. will meet applicable specifications and descriptions at time of delivery to BUYER.
SEAWARD PRODUCTS warrants the products delivered will be:

LIMITED TWO YEAR WARRANTY

OWNERSHIP REGISTRATION
(Please fill out and return with 10 days)

NAME _____
ADDRESS _____
CITY _____
STATE _____ ZIP _____
DEALER'S NAME _____
ADDRESS _____
CITY _____
STATE _____ ZIP _____
TYPE OF APPLIANCE: _____
I STOVE () RANGE () MICROWAVE ()
ADDRESS _____
CITY _____
STATE _____ ZIP _____
DATE PURCHASED _____
PRODUCT SERIAL # _____
PRODUCT MODEL # _____

Customer Service

Seaward Products
P.O. Box 586
La Puente, CA 91747

PLACE
STAMP
HERE

SEAWARD PRODUCTS AUTHORIZED SERVICE CENTERS

CALIFORNIA

PROPER TIGHE MARINE
2427 Clement, Alameda, CA 94501
(415) 523-2143

SAILING SUPPLY
2022 Cannon Street, San Diego, CA 92106
(619) 225-0128

SOUTH BAY MARINE ENTERPRISES, INC.
2503 Alvar Street, San Pedro, CA 90731
(213) 933-1450

WESTLEY HEINMILLER CO.
1525 Lot 16 Blvd., Corona, CA 90717
(714) 534-9119

CANADA

RIVER MARINE SUPPLIES

5117 Box 2500, Fairview Ave
8000 Dufferin Way, Richmond, B.C., Canada V6X 1B1
(604) 271-8426

SHOULWAY MARINE SERVICE LTD.
81 Lakeshore Road East, Mississauga (Ontario), Canada L5H 1C4
(416) 278-2541

CONNECTICUT

YACHT MARINE
7 Ruddy Street, Norwich, CT 06250
(203) 259-1150

FLORIDA

A.C. MARINE, INC.
2012 Whiting Park Drive, Sarasota, FL 34233
(813) 755-0234

APPLIANCES OF PALM COAST
2 Hargrove Circle, Palm Coast, FL 32037
(904) 445-1439

D & S SERVICE
17055 SW 14th Street, FL 33173
(305) 271-9544

SPACE COAST APPLIANCE INC.
2412 North Atlantic Lane, Cocoa, FL 32920
(407) 784-2702 x 329-0973

TAMPA MARINE
503 North Fairbanks Street, Tampa, FL 33602
(813) 258-2734

HAWAII

ALA WAI MARINE LTD.
1621 Ala Moana Boulevard, HI 96813
(808) 940-4213

MARYLAND

WILKINS BOAT SUPPLY
100 South Street East Port, Annapolis, MD 21403
(410) 293-8000
PO Box 2, Annapolis

MICHIGAN

NORTHLAND APPLIANCE SERVICE CO.
2201 Adams Road, Sterling, MI 48658
(517) 854-3180

TORRESSEN MARINE, INC.
2126 Lakeshore Drive, Muskegon, MI 49441
(616) 787-2506

MISSISSIPPI

GULFPORT MARINE SUPPLY
1916 27th Avenue, Gulfport, MS 39507
(601) 568-0995

NEW JERSEY

JAY MARINE
70 33 & Oldcountry Avenue, Maple Shade, NJ 08052
(609) 482-1501

NEW YORK

ACME SERVICE CO.
8 Davidson Plaza, East Hockanay, NY 11079
(516) 503-8803

SEASIDE 3 MARINA
848 & Whitford, Larchmont, NY 10577
(914) 937-9288

OREGON

JIM PRINCIPLE'S BOAT REPAIR
20 North Central, Medford, OR 97501
(503) 750-6191

SEXTONS CHANDLERY

300 N.E. Posthawk Road, Medford, OR 97517
(503) 289-8328

RHODE ISLAND

COOP BROS
41 Brook Street, Providence, RI 02903
(401) 331-8201

F & M SERVICE, INC.
2500 East Main Road, Pawtucket, RI 02871
(401) 850-5223

UTAH

PETERSON MARINE SUPPLY
4432 South 200 West, Ogden, UT 84403
(801) 351-2333

WASHINGTON

MILITRONICS, INC.
2007 15th Street, Everett, WA 98201
(206) 608-4133

SUBT MARINE SERVICES, INC.
5020 26th Avenue, NW, Seattle, WA 98107
(206) 739-1541

LIMITED TWO YEAR WARRANTY

SEAWARD PRODUCTS warrants the products delivered will be:
A. free from (1) encumbrances and (2) defects in material and workmanship under the normal use and service; and
B. will meet applicable specifications and descriptions at time of delivery to BUYER.

The obligation of SEAWARD under this Warranty is limited to the repair, rework, or replacement, at SEAWARD'S option, any part or component thereof, which examination discloses to our satisfaction to have been nonconforming or defective. SEAWARD, after establishing customer's purchase date and determining problem to be under warranty, will either repair the product at their factory or authorized service center and allow labor and parts for (2) two years from purchase date. Transportation charges are the responsibility of the customer. Items not covered under warranty are

- (1) Porcelain Enamel
- (2) Glass
- (3) Routine Maintenance that may be required.

The foregoing Warranty and condition shall apply to any repaired, reworked, or replaced products, part or component supplied by SEAWARD. SEAWARD shall in no event be liable to BUYER or BUYER'S customers for any incidental or consequential damages, or loss of use, or other losses, however occasional. Implied Warranties of merchantability and of the fitness of the product for any purpose are warranted for a period of two years on parts and labor, SEAWARD makes no warranties, expressed or implied after that time. Some states do not allow limitation on how long an implied warranty lasts or for the exclusion or limitations of incidental or consequential damages, therefore, the above limitations may not apply to you.

This Warranty is extended to the original purchaser only, unless purchased for purposes of resale. This Warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Seaward Products

P.O. BOX 566
LA PUENTE, CA 91747
(818) 968-2117

HUNTER MARINE LIMITED WARRANTY

The following warranties apply to all 1993 Model Year boats produced by HUNTER MARINE CORP.

RATION:

LIMITED ONE YEAR WARRANTY

Hunter Marine warrants to the first-use purchaser and any subsequent owner during the warranty period that any part manufactured by Hunter will be free of defects caused by faulty workmanship or materials for a period of twelve (12) months from the date of delivery to the first-use purchaser under normal use and service. During this period, Hunter will repair or replace any part judged to be defective by Hunter.

LIMITED FIVE YEAR HULL STRUCTURE AND BOTTOM BLISTER WARRANTY

Hunter warrants to the first-use purchaser and any subsequent owner during the warranty period that the hull of each boat will be free from structural defects in materials and workmanship for a period of five (5) years from the date of delivery to the first-use purchaser under normal use and service.

This limited warranty applies only to the structural integrity of the hull and the supporting part/fit or stringer systems. Hulls, part/fit or stringers modified in any way or powered with engines other than the type and size installed or specified by Hunter are not covered by this limited warranty. The obligation of Hunter under this limited warranty is limited to the repair or replacement of hulls, but it determines to be structurally defective. This is your sole and exclusive remedy.

Hunter also warrants to the first-use purchaser and any subsequent owner during the warranty period that the boat will be free from gel-coat blistering on underwater surfaces of the hull, excluding the keel and rudder, for a period of five (5) years from the date of delivery to the first-use purchaser under normal use and service. During this period, Hunter will supply or reimburse an authorized Hunter dealer for all of the parts and labor required to repair a blistered underwater surface of the hull. The labor cost reimbursement will be based on the Labor Allowance Schedule established by Hunter from time to time, however if the repair is performed by a non-Hunter dealer, the repair cost must be authorized by Hunter in advance and be based on a reasonable number of hours as determined by Hunter. Transportation, hauling, launching, bottom paint, storage, dockage, cranking, venting, rigging and de-rigging, or other special costs will not be paid by Hunter. It is recommended that the repair be done during a seasonal dry out for service or storage.

The following circumstances will void the bottom blister limited warranty:

(1) If the gel-coat has been sanded, sandblasted, or subjected to abrasion or impact.

(2) If the instructions provided in the Hunter Owner's Manual are not followed according to Hunter's required bottom preparation procedures.

HUNTER MARINE

LIMITED WARRANTY

RESTRICTIONS APPLICABLE TO WARRANTIES

These limited warranties do not cover:

- (1) Paint, window glass, gelcoat, upholstery, damage, plastic finishes, engines, engine parts, air/gear pumps, hoses, blowers, pressure water pumps, propellers, shafts, rubbers, controls, instruments, keels and equipment not manufactured by HUNTER. Any warranty made by the manufacturer of such items will be, if possible, given on to the first use purchaser.
- (2) Problems caused by improper maintenance, storage, cradling, blocking, normal wear and tear, misuse, neglect, accident, corrosion, electrolysis or improper operation.
- (3) Boats used for commercial activities including charter.

THIS WARRANTY IS EXPRESSLY IN LIEU OF ANY AND ALL OTHER REMEDIES AND WARRANTIES EXPRESSED AND IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THE PURCHASER ACKNOWLEDGES THAT NO OTHER REPRESENTATIONS WERE MADE TO HIM OR HER WITH RESPECT TO THE QUALITY AND FUNCTION OF THE BOAT. ANY CONSEQUENTIAL DAMAGES WHICH MAY BE INCURRED ARE EXCLUDED AND PURCHASER'S REMEDY IS LIMITED TO REPAIRS OR REPLACEMENT OF ANY PART(S) JUDGED DEFECTIVE BY HUNTER. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

WARRANTY REGISTRATION

These limited warranties shall not be effective unless the HUNTER Warranty Registration Form and Pre-Delivery Service Record, which are furnished with each new boat, are filled out completely and returned to HUNTER within fifteen (15) days of delivery. Responsibility for sending the completed Registration Form remains with the dealer.

Return of the Warranty Registration Form to HUNTER, signed by both Dealer and Owner, is critical. Warranty coverage cannot be initiated until the completed form is received at HUNTER.

All repairs and/or replacements will be made by an authorized Hunter dealer, or at the option of Hunter, at the Hunter plant. If the repairs are of such nature that the warranty work must be performed at the HUNTER plant, transportation costs to and from the HUNTER plant shall be paid by the owner. The labor cost related to a reasonable number of hours as determined by HUNTER. Any repairs and replacements must be approved in advance by an authorized HUNTER service representative.

HUNTER MARINE LIMITED WARRANTY

TRANSFER OF LIMITED WARRANTIES

Effective with 1993 hull numbers, the limited warranties will be transferred to a subsequent purchaser of the boat if:

(1) A notice of the transfer of ownership of the boat is given by the subsequent purchaser in writing to Hunter within thirty (30) days of the transfer.

(2) The notice shall include the name, address and telephone number of the subsequent purchaser, the date of purchase, the hull number and the name of the seller of the boat.

Hunter will mail to the subsequent purchaser notice of the expiration dates of the limited warranties. (see form letter, attached) The transfer of the ownership of the boat will not extend the expiration dates of the limited warranties.

CUSTOMER SATISFACTION SURVEYS

During the first year of ownership, the first purchaser will receive two Customer Satisfaction Surveys - the first (CSS#1) will be received shortly after taking delivery and focuses on the dealer's ability to sell and commission the boat, and the Owner's initial satisfaction. The second survey (CSS#2), time to sea words into ownership, "measures" dealer service capability and allows the owner to evaluate most of the boat's functional systems and characteristics. Both surveys are dependent upon receipt of the first purchaser's Warranty Registration Form.

Cat. No. 493 Series Standard Intake Water Strainers
 Cat. No. 500 Series Heavy Duty Intake Water Strainers
INSTALLATION AND OPERATING INSTRUCTIONS

NOTE: Prior to installation, consult your Engine Manual for recommended pipe size and strainer location. For proper protection, A.S.Y.C. Standards E-1 (Bonding of Direct Current Systems) and E-2 (Corrosion Protection) must be achieved first.

- 1) The PERKO Water Strainers have been designed to be installed on the intake side of the water cooling system.
- 2) Mount strainer on a flat surface in a vertical position. Allow clearance above strainer to remove basket for cleaning.
- 3) For correct installation, note that the inlet and outlet fittings are marked on the top casting. For convenience in piping, there are mounting lugs on both sides of the strainer.
- 4) Drill mounting holes, using threaded lugs on strainer as a template. Strainer should be mounted to ensure correct support from bulkhead to eliminate any strain on the pipe.
- 5) PERKO strainers are designed to give 100% full flow, without restriction (see Note No. 7). The use of reducers may cause engine damage and therefore is not recommended. The following table shows the rated strainer open area to pipe cross-section, ratios:

CASTING	PIECE SIZE	RATIO
493-003-PL3	3/8	2:1
493-004-PL3	1/2	3:1
493-005-PL3	3/4	2:1
493-006-PL3	1	2:1
493-007-PL3	1-1/4	1:1
493-008-PL3	1-1/2	1:1
493-009-PL3	2	1:1
493-010-PL3	2-1/2	1:1
500-000-PL3	2	2:1
500-010-PL3	2-1/2	1:1
500-011-PL3	3	1:1

- 6) After all connections are complete, start engine and check entire system for leaks.
- 7) **IMPORTANT:** Periodic inspection and removal of foreign matter is essential for safe operation. This requirement will vary, depending on amount of use and local operating conditions. Quick clearing of strainer is accomplished by removal of basket through access plate in top of casting.
- 8) **IMPORTANT:** Periodic inspection of connections is also essential for safe operation. Make sure to check engine, bearings, cover gaskets, plug, tie rods, etc. for damage or deterioration on a regular schedule.
- 9) **WINTER ZONE:** To prevent damage by freezing, drain the strainer cylinder prior to storage in freezing temperatures.

SPARE PARTS

Specify part no., of strainer, size and Part No. below
 (For Example: 493-005-PL3 Operates a cover gasket for a 3/4 inch strainer)

- 36A - Top Casting
- 36B - Bottom Casting
- 36C - Transparent Cylinder
- 36D - Basket Strainer
- 36E - Cover with Gasket
- 36F - Hinged Bolt for Cover with Pin Nut and Washer
- 36M - Gasket Kit Consists of:
 - 1 - Cover Gasket and
 - 2 - Gasket Washers (2 per set)
- 36N - Cover Washers (2 per set)

Above standards can be obtained from:

American Boat & Yacht Council, Inc.
 405 Headquarters Drive Suite 2
 Millersville, MD 21108

PERKO, INC.
 15450 N.W. 13th Avenue
 Miami, FL 33189-5707



Over time, the rudder has been producing surface rudders for over twenty five years for most major boat companies. The fiberglass slide with its rigid urethane core has proven to be an extremely strong and durable rudder.

The core material buoyancy of your rudder helps the performance of your boat by reducing total weight, as well as reducing the moment of inertia at the stern. Near neutral buoyancy also is helpful should the rudder ever need to be removed for steering system repairs. The boat does not need to be hauled out of the water to be moved to the rudder.

Tough fiberglass and urethane plastics used in the construction of your rudder is nearly indestructible. The urethane core is composed of a strong rigid fibreglass woven cell structure. Water, grease, solvent or marine borers will not damage your rudder slide, even if the fibreglass coating has been damaged.

The edge seam should not be ground flush unless you re-glass the seam. If it is ground flush without re-glassing it will cause it to separate.

When you paint your rudder the first time, particular attention should be paid to the paint manufacturer's instructions for preparing the surface. Solvent washing is not enough. The rudder must be sanded heavily to remove a heavy coating of mold release. We recommend white paint be used. White is a popular color as it is easy to see weeds and other debris which can catch on your rudder.

Cosmetic surface repairs may be performed by cleaning, drying and roughing up the damaged area and applying marine grade epoxy. It may be filled with a putty knife. Should a small blister appear, it may be filled with epoxy and sanded smooth and painted correctly with bottom paint or any coating you desire.

We do not recommend the use of dark colors on your rudder, as they generate heat when the boat is out of the water in the sun. Since the rudder is made of cellular material this heat can cause dimensional changes and cosmetic damage. If the rudder is painted with a dark color it should be shielded from the sun with a white wrapping when the boat is out of the water. The rudder naturally excludes damage caused by heat.

You should make periodic inspections of your rudder and look for possible damage from grounding or electricals. Slight bends or slight erosion often are not noticed until the shaft fails in heavy sea conditions.

Should you have any questions about your rudder, feel free to call us at (613) 577-0478

YOUR BOSS FIBREGLASS AND URETHANE RUDDER

FOSS FORM, INC. // POLYURETHANE FORM

4400 - 180th Avenue North
 Glenview, IL 60025
 Phone: (613) 577-0478
 FAX: (613) 577-0478




LEWMAR PORTLIGHT - FITTING INSTRUCTIONS FOR OPENING VERSIONS

R7071 Mk VII

- 1) Check that Portlight can be fitted in the planned position. Hold the outer frame at the intended position and check that a flat surface (to +/- 1mm) exists to 12mm beyond the edge of the planned cutout. Hold the inner frame on the inside at the intended position and check that all fastenings will be clear of any deck moulding radius in the hull etc, and that a flat bearing surface exists over the surface of the inner frame to ensure a good bolting down seal. (See sketch of Typical Cross Section.)

- 2) With a pencil mark out the cutout to the recommended dimensions shown.



size	PORTLIGHT SIZE	DIMENSION A	DIMENSION B
0	4" x 30"	150mm	304mm
1	5" x 12"	171mm	347mm
2	4" x 14"	135mm	106mm
3	5" x 15"	171mm	428mm
4	6" x 23"	171mm	627mm

- 3) Cut out to just inside of the pencil line using a suitable jig saw. It is important to make an accurate cut within the line. It may be necessary to ease/rasp out beyond this size to achieve the best possible fit of your Portlight. As production tolerances exist we advise that you measure your Portlight to check exactly the cutout sizing before you cut. (Remember the old adage; Measure twice, cut once).

- 4) Measure thickness of skin (and inner trim if fitted).

- 5) Clear away sawdust, supply bedding compound to outer frame. Fit outer frame unit and with inner frame in place (such that the butt joint is at the lower edge to allow for water drainage), bolt firmly up to a maximum torque of 25 in.lb (0.113 Nm.) from the centre working out to the edges using the bolts supplied. Make sure compound spreads out evenly on the outside of outer frame. Clean off surplus sealant compound.

Caution
MS screws supplied are for hull thickness 15-19mm. It is important that you use the correct length screw otherwise you will damage the portlight. Check depth of hull and select correct length of screw from table overleaf.

- 6) Adjust the trim moulding by cutting the inner edge only to suit, using fine toothed saw or tin snips, such that when in place the trim ring fixes to the dual lock pads. Snap the trim mouldings into final position making sure the trim ring picks up the top dual lock pads and that the trim is fully home all around its perimeter. It is a simple matter to remove the trim ring by prising it away and refitting by snapping back onto the dual lock pads. On craft with considerably wrap/curvature or difficult inner trim it may be necessary to use more dual lock fixing in which case use our spacers kit. Alternatively, in extreme cases, it may be necessary to use screw fixings through the trim into the inner lining.

Warning: Cleaning of portlight with all solvents could cause damage.

11) Deadlight
 If a deadlight is required we suggest that the trim moulding be removed. A plywood/aluminium/fibreglass plate be cut to cover the port (notched to clear hinges and locking handles), and drilled such that by using longer bolts it may be bolted on top of the aluminium frame.


Portlight Size	Replacement Trim Mouldings	Replacement Fibreglass	Replacement Seals
4 x 10	8973	8980	8985
5 x 12	8974	8981	8986
4 x 14	8975	8982	8987
5 x 16	8970	8983	8988
6 x 23	8978	8984	8989

10) Spares: Spares are available, should damage occur. These include:
 Min. hull thickness .6mm. Max hull thickness 32mm.

9) M5 fixing screws
 For hull thickness

6 - 13mm	Use M5 x 16, Cat. 8991
11 - 14mm	Use M5 x 20, Cat. 8992
15 - 18mm	Use M5 x 25, Cat. 8993
20 - 24mm	Use M5 x 30, Cat. 8994
25 - 29mm	Use M5 x 35, Cat. 8995
30 - 34mm	Use M5 x 40, Cat. 8996

(supplied as standard)



Sketch (Cross section)

8) Fitting Flyscreen
 Showing flyscreen in position - behind outer frame and in front of seal. Fit the seal and the outer frame all the way around its perimeter. Flyscreen from the inside by first locating each end, and then easing it between the

18 MONTH LIMITED PUMP WARRANTY

Johnson Pumps of America of 3700 North Shore Street, Schaumburg, Illinois 60196 warrants to the original consumer purchaser that this Bilge Pump will be free from defects in material and workmanship, provided that the case is not opened or the pump otherwise abused for a period of eighteen (18) months from the date of direct purchase.

The exclusive remedy of the consumer shall be in the event the product does not meet the express limited warranty to return the pump to Johnson at the above address, freight prepaid with your sales receipt, and \$2.00 to help offset the cost of postage and handling. IMPORANT! HOW THIS WARRANTY TO BE EFFECTIVE, JOHNSON MUST BE SUPPLIED WITH PROOF OF THE ORIGINAL PURCHASE DATE OF THE PUMP. THE ACCEPTANCE BY JOHNSON OF ANY PUMP RETURNED SHALL NOT BE DEEMED AN ADMISSION THAT SUCH PUMP IS DEFECTIVE OR IN VIOLATION OF ANY WARRANTY. THE COMPANY RESERVES THE RIGHT TO RETRAILOR REPAIR THE PUMP.

NO OTHER PERSON IS AUTHORIZED TO ASSUME FOR JOHNSON ANY ADDITIONAL LIABILITY IN CONNECTION WITH THE SALE OF ITS PRODUCTS OR TO ALTER THE WARRANTY IN ANY WAY.

IN NO EVENT WILL JOHNSON PUMPS OF AMERICA BE LIABLE FOR MORE THAN THE SALES PRICE OF THE PUMP. UNDER NO CIRCUMSTANCES WILL JOHNSON BE LIABLE FOR ANY LOSS PRO- IS INCIDENTAL ON CONSEQUENTIAL COSTS, EXPENSES, OR DAMAGES. THE LIMITATION ON LIABILITY FOR LOSS PROFITS, INCIDENTAL OR CONSEQUENTIAL COSTS, EXPENSES OR DAMAGES SHALL SURVIVE ANY FAILURE OF ESSENTIAL PURPOSE OF THIS LIMITED WARRANTY. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation may not apply to you.

NO EXPRESS OR IMPLIED WARRANTY, INCLUDING WARRANTY OF MERCHANTABILITY AND FITNESS SHOWN, EXTEND FOR ANY PERIOD OF TIME GREATER THAN 18 MONTHS FROM THE DATE OF ORIGINAL PURCHASE OF THIS PRODUCT. Some states do not allow limitation on how long an implied warranty lasts so the above limitation may not apply to you.

CAUTION - Warranty void if seal on pump is broken. If any electric wire is not back from the 3 wires, electric splices become adjoined, or if pump is installed contrary to instruction or warnings.

Bilge Pumps are designed to extract standing water only. These pumps are not intended for drainage control. Bilge pump capacities may not be sufficient to prevent flooding from rapid accumulation of water due to storms, rough weather and/or rapid leaks caused by air damages or unsafe navigational conditions.

JOHNSON PUMPS OF AMERICA

Mayfair Marine Division

3700 N. HOSE STREET

30311 LHM PARK, ILLINOIS 60196

PH 62213



Submersible

Bilge

Pumps

INSTALLATION INSTRUCTIONS



MUSTER ENGINEERING LIMITED
 ENGINEERING LIMITED
 10 D'Arbelle Road, Esplanade,
 Co. Sligo, Northern Ireland
 BT19 1LT
 Telephone: +44 (0) 287 270531
 Telex: 747366
 Fax: +44 (0) 287 418421

WHALE GUSHER® 10 MK3 PUMP

Models: EP2708 and UP2740

READ CAREFULLY BEFORE INSTALLATION AND USE

To the Fitter: Check that the product is suitable for the intended application. When installation instructions are secure operating instructions are passed on to the end user.

To the User: Read the following instructions carefully. (See parts diagram).

APPLICATION

This high pump is designed to extract standing water. Output capacity depends on installation conditions and pumping rate. Users should be aware that capacity may not be sufficient to cope with severe flood of water.

It is intended for use for any other purpose or with any other liquid, as the user is responsible to ensure that the pump is suitable for the intended use and, in particular, that the materials are fully compatible with the fluids to be used. With all applications it is important that a system of safe working practice is applied to installation, use and maintenance.

INSTALLATION

The Gusher 10 is designed for mounting on or through deck, or on a vertical bulkhead. The hand can be fixed in the tiller rail position relative to the tiller wheel (see Fig. 1).




Fig. 1 Some of the many mounting arrangements possible with the standard pump.

To Reposition Handle:

- Detach wooden cleat and remove diaphragm.
- Undo the bolts from bracket and rotate body to new position relative to the fork and diaphragm. (Note: this one only use always at 90° to each other).
- Reassemble both washers and securing bushes in bracket and tighten.

Select a suitable position for the discharge where the pump can be operated efficiently and comfortably.



Avoid installations which require a working location to be opened in order to operate the pump.



To minimize pumping effort, fit the pump handle in the highest position the structure allows and full stroke.



To ensure good priming and flow, avoid sharp bends in pipework; make a 90° return drum bend rather than a 180° return; use a non-return valve which prevents the end of the hose sucking against a flat surface and allows the water level to be reduced to a minimum.

Ensure that the pump is installed to allow easy access for servicing.

For Mounting On Deck/Bulkhead:

- Using pump as template, mark off and drill four 1/2" (6mm) holes.

Fig. 2



- Check that the hole and secure the pump with 1/2" (6mm) nuts.

- Attach 1 1/2" (38mm) smooth bore rubber hose with clutches about 10cm drive hose edge. (Tension clips to prevent air leaks).



- With uncut discharge, make sure that the discharge pipe is level above the water line.

- Check the installation for air leaks, correct priming and discharge.

For Mounting Underdeck or Through Bulkhead:

Three deck plates are available see ACCESSORIES.

- Using template mark off the 8 holes for the mounting and cut the hole for the pump handle. Round off top edge of large hole as shown in fig. 3.

DECK PLATING FOR GUSHER PUMP'S

USE STANDARD DIMENSIONS UNLESS OTHERWISE SPECIFIED




Fig. 3.

- When on deck thickness required is 1/2" (5mm). For 11mm deck use a backing plate of similar thickness so that the backing plate plus the deck is at least the minimum thickness and no greater than 1 1/2" (32mm). Drill the backing plate to the deck.

Note: If using deck plate DP29804 on minimum deck thickness is 1/2" (5mm).

- Position pump under deck and check flow direction. Mark the rubber gasket up through the hole and its flange rests on the deck. Secure the 8 x 1/2" (6mm) countersunk mounting screws provided.
- As points 3 & 4 and 5 of previous instructions.

OPERATION

The Gusher 10 ensures efficient throughput with an easy pumping action. Full even strokes will obtain the best results. The detachable handle is fitted with a lanyard and should be safely secured clean to the pump.

Performance Table

WHALE GUSHER 10 MK3
OUTPUT AT 1m LIFT AND 0.5m HEAD

OUTPUT	AT 60 STROKES/MIN.	STROKES/MIN.	AT 60 STROKES/MIN.
GALLONS/MIN	15.8		18.7
LITRES/MIN.	71.8		85.0

Performance data is based on factory tests and is typical of what may reasonably be achieved. Actual performance may vary depending on installation and operating conditions.

MAINTENANCE

Inspection

Regular inspection of the pump is recommended. Rubber components should be replaced if worn or every five years regardless of condition.

Replacement components and Service Kits (SK3708 for clean high water and SK3714 for oily high water) are available from dealers or direct from the manufacturer. It is recommended that a service kit is kept on hand.

Wintering

At the end of the season, drain all the water in the pressure and pump elements.

Changing The Diaphragm and Valves

1. Stricken and remove the mounting clip to release the diaphragm.
2. Flatten diaphragm nut and remove diaphragm plates and diaphragm.
3. Remove old inlet and outlet valves. Note: Inlet and outlet valves are square shape. The Service Kits contain two sets of valves, the round shaped valves are for the MK2 pump and the square shaped valves are for the MK3 pump. UO ND Press the valve type arm for the MK3 pump. UO ND Press the valve type arm for the MK2 pump.
4. Replace diaphragm, and tighten mounting clip in position and test for correct pumping and discharge.

ACCESSORIES:

- *DP3804 - Alloy deck plate with lid.
- *DP3020 - Polished zinc cook plate.
- *DP8803 - Plastic deck plate.
- *9F5425 - Skirting.
- *855865 - Top entry strumbowstrainer.
- *880222 - Side entry strumbowstrainer.
- *2V6808 - 2-way diverter valve.
- *883488 - 90 degree (angle) fitting.
- *LV1215 - In-line non-return valve.
- *SK3708 - Service Kit (Highwater).
- *SK3714 - Service Kit (Lowwater).

HELPFUL HINTS

1. Pump fails to prime or chokes:
 - Check inlet hose connection is airtight, free from blockages, and does not collapse during the suction stroke.
 - Inspect inlet and outlet valves for blockages.
 - Clean valves or screwdriver and test.
 - Inspect diaphragms - replace if damaged.
 - Solid objects in the body of the pump may prevent its operation but should be removed to prevent damage.

WARRANTY


Whale pumps are guaranteed for one year from date of purchase against defects in materials and workmanship. If the unit proves faulty, return it to your supplier with proof of purchase and purchase date.

The manufacturer retains the right to repair or replace the unit.

The manufacturer cannot be held responsible for claims arising from incorrect installation, unauthorised modification or misuse of the product.

This above does not affect your statutory rights.

WHALE and Gusher are registered trade marks of Munster Seams Engineering Ltd.



Whale and Gusher are registered marks of
MUNSTER SEAMS ENGINEERING LIMITED
100,07 V6/90

Installation

Secure the plate to the bulkhead using the #6 sheet metal screws provided.

Plug the microphone into the connector just installed and place the microphone into the hang-er on the plate.

Electrical Wiring

Power Input

The 12 VDC power is supplied to the RT-80 through RED and BLACK #12 AWG wires permanently attached to the RT 80. The RED wire should be connected to the ship's power circuit breaker/fuse panel. It should be protected by using either a 10 ampere circuit breaker or fuse.

The BLACK wire should be connected to the ship's negative power buss. Both of these wires should be cut as short as possible to minimize the voltage drop.

RF Output

The RF output to the antenna is supplied through a coaxial cable/connector that is permanently attached to the RT-80. This cable is approximately one foot in length and is black in color.

The coaxial cable from the antenna should be terminated with a PL-259 coaxial connector. This connector from the antenna should be screwed onto the RF output connector of the RT-80 and secured to prevent damage from vibration and chaffing.

Speaker Wiring

There are three different speakers that can be connected to the RT-80.

The VIGIL Panel Speaker (supplied) is used for all normal communications and for hearing the intercom audio from the remote speaker.

An optional Hall Speaker can be installed for Hailing and is only used in the Hall Mode.

The optional remote VIGIL Intercom Speaker is used as the remote intercom and is used only in the COM mode as both a speaker and microphone for the remote station.

is where the wire from the speaker will go through the bulkhead.

Feed the wire coming from the back of the speaker through the Redline gasket, through the spacer and then through the 1/4" hole in the panel. Apply a thin film of non-corrosive Silicone Bedding (GE Silicone II or equal) to the back of the mounting spacer.

Secure the speaker to the mounting surface with the four stainless screws provided. Do not over-tighten.

After the speaker is mounted by either of the above methods, press the four plastic plugs (provided) into the screw holes on its face. This will hide the screws and provide a clean look to the speaker.

Microphone Mounting Plate

Select a convenient location on the instrument panel for the mounting of the microphone and connect it to the RT-80. The microphone connector cable is permanently attached to the back of the RT-80. This cable is approximately 10 feet in length and has an eight pin male connector attached to it. This connector is designed to mount onto the Microphone Mounting Plate (supplied) and to mate with the eight pin female connector on the end of the cable attached to the microphone.

A single 3/8" hole and four 1/16" holes must be drilled through the panel where the microphone will be connected to the RT-80.

A full size drilling template is provided in the back of this manual. This 3/4" hole must be located in such a position that the connector attached to the RT-80 cable will reach (remember it's about 10 feet long), and pass through the hole. A brushed Stainless Steel plate is provided to which the connector from the RT-80 is attached.

Remove the nut and the washer from the connector, pass the connector through the hole in the supplied plate from the back of the plate, and first place the washer and then the thread the nut onto the connector. Gently tighten the nut to secure the connector to the plate using a speaker wrench or long nose pliers. Do not over-tighten.

Call any excess wire. Do Not Cut the Cable!!!

Installation

All speaker wiring permanently attached to the RT-80 is contained in a multi-conductor cable that contains six color coded wires. They are connected as follows:

The Panel Speaker, previously installed, should be connected to the Red and Black wires within the multi-conductor cable coming from the RT-80. The leads coming from the speaker are also Red and Black. Connect red to red and black to black.

Warning!!!

Do not connect these leads to the RED and BLACK heavy (#12 AWG) Power Cable previously connected to either the Radio or Speaker could result.


If you are using the optional Hall Speaker it should be connected to the White and Green leads in the multi-conductor cable.

If you are using the optional Intercom Speaker it should be connected to the Brown and Blue leads in the multi-conductor cable.

The microphone connector comes prewired and only needs to be mounted in a convenient location as previously described. The following wiring information is provided only for reference.

Pin No.	Function
1	Privacy
2	DO
3	DI
4	SCL
5	Microphone Audio
6	Ground
7	+8 VDC
8	Microphone Audio and Push to Talk

A full wiring diagram is shown in figure 2. This completes the installation of the RT-80.



Wiring Diagram
Figure 2

General

The VIGIL RT-80 is an easy to operate, full function VHF Radio with many features unavailable in any competitive unit. After you learn the purpose of each knob and button you will find the RT-80 operation truly functional and straightforward. Please refer to Figure 3.

Power On

Rotate the Function knob to NORM to apply power to the radio. The radio will power up to it's previous operational channel.

Normal Mode

The NORM mode is used for all normal communications. This is the mode that is used for simple two-way radio communications.

Volume


Rotate the Volume knob clockwise to increase the audio volume. Rotating the Volume knob counter-clockwise will decrease the volume.

Squelch

Rotating the Squelch knob clockwise will increase the squelch threshold, decreasing the receiver sensitivity. This will cause the receiver to be quieted until a signal of sufficient strength is received.

Rotating the Squelch knob counter-clockwise will decrease the squelch threshold, increasing the receiver sensitivity. At the lowest squelch setting (fully counterclockwise) the receiver sensitivity will be maximum, the audio will be turned on (even with no signal being received) and the receiver noise will be heard.

The squelch should normally be increased until the background noise just disappears when no

**Figure 3**

signal is present. If you are trying to receive an extremely weak signal, the squelch should be set at its minimum position (fully counterclockwise).

Channel Selection

The RT-80 will power on with the last used channel displayed. Rotate the Channel Select knob either clockwise to increase the channel number or counterclockwise to decrease the channel number. The selected channel will be displayed in the left side of the Liquid Crystal Display (LCD).

Channels that cannot be skipped automatically as the channel knob is rotated.

The relative strength of the received signal will be indicated by the horizontal bars on the LCD. The more bars seen, the stronger the signal.

Transmitting

Pressing the microphone Push-to-Talk button will place the RT-80 into the transmit mode. The TX annunciator will be displayed on the LCD. Pressing the H.L. button prior to transmitting will change the power to either 1 or 25 watts and will be discussed fully in a later section.

The RT-80 has a built in Antenna Fault detector. If the connection to the Antenna is either open or shorted, or if the antenna is defective, the AFT Fault Annunciator will be displayed. Note that this functions only when transmitting.

Before transmitting, please read the OPERATING TECHNIQUES section of this manual carefully.

Memory Mode

The MEM mode will probably be your most used mode of operation. Turn the Function Knob to the MEM position. The MEM Annunciator will be dis-

played. When the RT-80 is first used, the 20 memories available will be empty and must be programmed by the user. An empty memory is indicated by "--" in the LCD display.

Programming the Memory

To program a memory, first select the desired memory number (1-20) in the arrow/ right most digit pair. This is done by turning the Channel Select knob either CW or CCW until the desired memory number is indicated. Then press the button below the Left Arrow (<) to activate the "left window". The display will indicate "00" and flash indicating that the "Program Mode" is active and input by the user is anticipated.

Then rotate the Channel Select knob until the desired channel is indicated in the Left Window. If it is desired, an International Channel may be programmed by pressing the UI (US/ International) Button (Same as Left Arrow <). When the desired channel is set into the left window, press the button below the Right Arrow (>). The will install the channel selected into the memory number selected and return you to the Memory Number Mode. To program additional channels into memory, repeat the above procedure for each of the 20 available memories.

After programming the memories, whenever the MEM mode is selected, these channels will be recalled in the corresponding memory number. Pressing the SCAN button while in the MEM mode will initiate Memory Scan. This is described in full detail in the SCAN section of the manual. Pressing the HL button will change the transmit power (1 or 25 watts) just as in the NORM mode. Pressing the Mic Push-to-Talk button will cause the RT-80 to TRANSMIT.

In short, the MEM mode will do everything that can be done in the NORM mode, but it is done more conveniently. The MEM mode allows the most often used channels to be more quickly selected and scanned.

Priority Mode

The PRI mode allows simultaneous monitoring of any two channels programmed by the user. After they have been programmed, these two channels are monitored automatically when the PRI Scan mode is selected. With both channels displayed

on the LCD, it is always simple to see what channels are being monitored.

To program the channels, turn the Function Knob to PRI. The PRI Annunciator will be displayed. To change the Priority Channel turn the Channel Select Knob as usual. To change the Normal Channel, press the button below the Left Arrow (<). The Left Display will flash. Rotating the Channel Select Knob will change the channel indicated (and thus selected). Pressing the UI button will allow the user to select either a US or International Channel.

Pressing it again will change the US/NITL in the Normal display. Another press will change the Normal back to its previous state. Pressing it again will change the Priority channel back to its previous state.

This can be continued until both the Normal and Priority displays indicate US or INTL as desired.

After the two channels are programmed as desired, pressing the button below the Right Arrow (>) will Exit the Setup mode and will return the Channel Select back to the right most display.

Pressing the SCAN button will begin the Normal/Priority scan.

16 Mode

The 16 mode is intended as a quick way to immediately select channel 16 as the active channel. To get to the Call and Distress channel simply turn the Function Knob to 16. In this mode the Channel Select is disabled. Transmitter operation is the same as normal.

WX Mode

To receive a weather broadcast, turn the Function Knob to WX. Rotate the Channel Select Knob till the Weather Channel desired (0-9) is displayed on the LCD. In addition, the LCD will display the WX Annunciator below the channel selected. Pressing the SCAN button will begin a scanning of all weather channels.

HALL Mode

Selecting the HALL function, by turning the Function Knob to HALL, allows the microphone to be used as a power hailer. The display will indicate HALL when the RT-80 is in this mode.